

CRANE-M3 Camera Compatibility List

(Standard Quick Release Plate)



Update Date: March 23th, 2022 (Firmware Version: V1.72)

V1.40

Camera Brand	Model	Lens Model	Balance Adjustment	Installation Remark	Note
Sony	α7M2	FE 24mm F2.8 G	√	No need to remove eyepiece cap	-
		FE 28mm F2	√	No need to remove eyepiece cap	-
		FE 35mm F1.8	√	Need to remove eyepiece cap	-
		Sonnar T* FE 35mm F2.8 ZA	√	No need to remove eyepiece cap	-
		FE 40mm F2.5 G	√	No need to remove eyepiece cap	-
		Sigma45mm f/2.8 DG DN	√	No need to remove eyepiece cap	-
		FE 50mm F1.8	√	No need to remove eyepiece cap	-
		FE 50mm F2.5 G	√	No need to remove eyepiece cap	-
		FE 28-60mm F4-5.6	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	α7R2	FE 24mm F2.8 G	√	No need to remove eyepiece cap	-
		FE 28mm F2	√	No need to remove eyepiece cap	-
		FE 35mm F1.8	√	Need to remove eyepiece cap	-
		Sonnar T* FE 35mm F2.8 ZA	√	No need to remove eyepiece cap	-
		FE 40mm F2.5 G	√	No need to remove eyepiece cap	-
		Sigma45mm f/2.8 DG DN	√	No need to remove eyepiece cap	-
		FE 50mm F1.8	√	No need to remove eyepiece cap	-
		FE 50mm F2.5 G	√	No need to remove eyepiece cap	-
		FE 28-60mm F4-5.6	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	α7S2	FE 24mm F2.8 G	√	No need to remove eyepiece cap	-
		FE 28mm F2	√	No need to remove eyepiece cap	-
		FE 35mm F1.8	√	Need to remove eyepiece cap	-
		Sonnar T* FE 35mm F2.8 ZA	√	No need to remove eyepiece cap	-
		FE 40mm F2.5 G	√	No need to remove eyepiece cap	-
		Sigma45mm f/2.8 DG DN	√	No need to remove eyepiece cap	-



Camera Brand	Model	Lens Model	Balance Adjustment	Installation Remark	Note
Sony	α7S2	FE 50mm F1.8	√	No need to remove eyepiece cap	-
		FE 50mm F2.5 G	√	No need to remove eyepiece cap	-
		FE 28-60mm F4-5.6	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	α7M3	FE 24mm F2.8 G	√	No need to remove eyepiece cap	-
		FE 28mm F2	√	No need to remove eyepiece cap	-
		FE 35mm F1.8	√	Need to remove eyepiece cap	-
		Sonnar T* FE 35mm F2.8 ZA	√	No need to remove eyepiece cap	-
		FE 40mm F2.5 G	√	No need to remove eyepiece cap	-
		Sigma45mm f/2.8 DG DN	√	No need to remove eyepiece cap	-
		FE 50mm F1.8	√	No need to remove eyepiece cap	-
		FE 50mm F2.5 G	√	No need to remove eyepiece cap	-
		FE 28-60mm F4-5.6	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	α7R3	FE 24mm F2.8 G	√	No need to remove eyepiece cap	-
		FE 28mm F2	√	No need to remove eyepiece cap	-
		FE 35mm F1.8	√	Need to remove eyepiece cap	-
		Sonnar T* FE 35mm F2.8 ZA	√	No need to remove eyepiece cap	-
		FE 40mm F2.5 G	√	No need to remove eyepiece cap	-
		Sigma45mm f/2.8 DG DN	√	No need to remove eyepiece cap	-
		FE 50mm F1.8	√	No need to remove eyepiece cap	-
		FE 50mm F2.5 G	√	No need to remove eyepiece cap	-
		FE 28-60mm F4-5.6	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	α7S3	FE 24mm F2.8 G	√	No need to remove eyepiece cap	-
		FE 28mm F2	√	No need to remove eyepiece cap	-
		Sonnar T* FE 35mm F2.8 ZA	√	No need to remove eyepiece cap	-
		FE 40mm F2.5 G	√	No need to remove eyepiece cap	-



Camera Brand	Model	Lens Model	Balance Adjustment	Installation Remark	Note
Sony	α7S3	FE 50mm F1.8	√	No need to remove eyepiece cap	-
		Sigma45mm f/2.8 DG DN	√	No need to remove eyepiece cap	-
		FE 50mm F2.5 G	√	No need to remove eyepiece cap	-
		FE 28-60mm F4-5.6	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	α7M4	FE 24mm F2.8 G	√	No need to remove eyepiece cap	-
		FE 28mm F2	√	No need to remove eyepiece cap	-
		Sonnar T* FE 35mm F2.8 ZA	√	No need to remove eyepiece cap	-
		FE 40mm F2.5 G	√	No need to remove eyepiece cap	-
		FE 50mm F1.8	√	No need to remove eyepiece cap	-
		Sigma45mm f/2.8 DG DN	√	No need to remove eyepiece cap	-
		FE 50mm F2.5 G	√	No need to remove eyepiece cap	-
		FE 28-60mm F4-5.6	√	Can be balanced at any focal length, no need to remove eyepiece cap	-



Camera Brand	Model	Lens Model	Balance Adjustment	Installation Remark	Note
Sony	α7R4	FE 24mm F2.8 G	√	No need to remove eyepiece cap	-
		FE 28mm F2	√	No need to remove eyepiece cap	-
		FE 35mm F1.8	√	Need to remove eyepiece cap	-
		Sonnar T* FE 35mm F2.8 ZA	√	No need to remove eyepiece cap	-
		FE 40mm F2.5 G	√	No need to remove eyepiece cap	-
		Sigma45mm f/2.8 DG DN	√	No need to remove eyepiece cap	-
		FE 50mm F1.8	√	No need to remove eyepiece cap	-
		FE 50mm F2.5 G	√	No need to remove eyepiece cap	-
		FE 28-60mm F4-5.6	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	FX3	FE 24mm F2.8 G	√	No need to remove eyepiece cap	-
		FE 28mm F2	√	No need to remove eyepiece cap	-
		Sonnar T* FE 35mm F2.8 ZA	√	No need to remove eyepiece cap	-
		FE 40mm F2.5 G	√	No need to remove eyepiece cap	-
		FE 50mm F1.8	√	No need to remove eyepiece cap	-
		FE 50mm F2.5 G	√	No need to remove eyepiece cap	-
		FE 28-60mm F4-5.6	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
Sigma45mm f/2.8 DG DN		√	No need to remove eyepiece cap	-	



Camera Brand	Model	Lens Model	Balance Adjustment	Installation Remark	Note
Sony	α7C	FE 20mm F1.8 G	√	No need to remove eyepiece cap	-
		FE 24mm F2.8 G	√	No need to remove eyepiece cap	-
		FE 28mm F2	√	No need to remove eyepiece cap	-
		FE 35mm F1.8	√	No need to remove eyepiece cap	-
		Sonnar T* FE 35mm F2.8 ZA	√	No need to remove eyepiece cap	-
		FE 40mm F2.5 G	√	No need to remove eyepiece cap	-
		Sigma45mm f/2.8 DG DN	√	No need to remove eyepiece cap	-
		FE 50mm F1.8	√	No need to remove eyepiece cap	-
		FE 50mm F2.5 G	√	No need to remove eyepiece cap	-
		FE 50mm F2.8	√	No need to remove eyepiece cap	-
		Sonnar® T* FE 55mm F1.8 ZA	√	No need to remove eyepiece cap	-
		FE 28-60mm F4-5.6	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		FE 28-70mm F3.5-5.6 OSS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	α6600	FE 14mm F1.8 GM	√	No need to remove eyepiece cap	-
		FE 20mm F1.8 G	√	No need to remove eyepiece cap	-
		Sonnar T* E 24mm F1.8 ZA	√	No need to remove eyepiece cap	-
		FE 24mm F2.8 G	√	No need to remove eyepiece cap	-
		FE 28mm F2	√	No need to remove eyepiece cap	-
		Sigma 30mm f/1.4 DC DN	√	No need to remove eyepiece cap	-
		FE 35mm F1.8	√	No need to remove eyepiece cap	-
		Sonnar T* FE 35mm F2.8 ZA	√	No need to remove eyepiece cap	-
		FE 40mm F2.5 G	√	No need to remove eyepiece cap	-
		Sigma45mm f/2.8 DG DN	√	No need to remove eyepiece cap	-
FE 50mm F1.8	√	No need to remove eyepiece cap	-		
FE 50mm F2.5 G	√	No need to remove eyepiece cap	-		
FE 50mm F2.8	√	No need to remove eyepiece cap	-		



Camera Brand	Model	Lens Model	Balance Adjustment	Installation Remark	Note
Sony	α6600	Sonnar® T* FE 55mm F1.8 ZA	√	No need to remove eyepiece cap	-
		FE 85mm f/1.8	√	No need to remove eyepiece cap	-
		E 10-18mm F4 OSS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		E 16-70mm F4 ZA OSS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		FE 28-60mm F4-5.6	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		Sigma28-70mm f/2.8 DG DN	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		FE 28-70mm F3.5-5.6 OSS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	α6500	FE 14mm F1.8 GM	√	No need to remove eyepiece cap	-
		FE 20mm F1.8 G	√	No need to remove eyepiece cap	-
		Sonnar T* E 24mm F1.8 ZA	√	No need to remove eyepiece cap	-
		FE 24mm F2.8 G	√	No need to remove eyepiece cap	-
		FE 28mm F2	√	No need to remove eyepiece cap	-
		Sigma 30mm f/1.4 DC DN	√	No need to remove eyepiece cap	-
		FE 35mm F1.8	√	No need to remove eyepiece cap	-
		Sonnar T* FE 35mm F2.8 ZA	√	No need to remove eyepiece cap	-
		FE 40mm F2.5 G	√	No need to remove eyepiece cap	-
		Sigma45mm f/2.8 DG DN	√	No need to remove eyepiece cap	-
		FE 50mm F1.8	√	No need to remove eyepiece cap	-
		FE 50mm F2.5 G	√	No need to remove eyepiece cap	-
		FE 50mm F2.8	√	No need to remove eyepiece cap	-
		Sonnar® T* FE 55mm F1.8 ZA	√	No need to remove eyepiece cap	-
		FE 85mm f/1.8	√	No need to remove eyepiece cap	-
		E 10-18mm F4 OSS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		E 16-70mm F4 ZA OSS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-



Camera Brand	Model	Lens Model	Balance Adjustment	Installation Remark	Note
Sony	α6500	FE 28-60mm F4-5.6	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		Sigma28-70mm f/2.8 DG DN	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		FE 28-70mm F3.5-5.6 OSS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	α6400	FE 14mm F1.8 GM	√	No need to remove eyepiece cap	-
		FE 20mm F1.8 G	√	No need to remove eyepiece cap	-
		Sonnar T* E 24mm F1.8 ZA	√	No need to remove eyepiece cap	-
		FE 24mm F2.8 G	√	No need to remove eyepiece cap	-
		FE 28mm F2	√	No need to remove eyepiece cap	-
		Sigma 30mm f/1.4 DC DN	√	No need to remove eyepiece cap	-
		FE 35mm F1.8	√	No need to remove eyepiece cap	-
		Sonnar T* FE 35mm F2.8 ZA	√	No need to remove eyepiece cap	-
		FE 40mm F2.5 G	√	No need to remove eyepiece cap	-
		Sigma45mm f/2.8 DG DN	√	No need to remove eyepiece cap	-
		FE 50mm F1.8	√	No need to remove eyepiece cap	-
		FE 50mm F2.5 G	√	No need to remove eyepiece cap	-
		FE 50mm F2.8	√	No need to remove eyepiece cap	-
		Sonnar® T* FE 55mm F1.8 ZA	√	No need to remove eyepiece cap	-
		FE 85mm f/1.8	√	No need to remove eyepiece cap	-
		E 10-18mm F4 OSS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		E 16-70mm F4 ZA OSS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		FE 28-60mm F4-5.6	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		Sigma28-70mm f/2.8 DG DN	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		FE 28-70mm F3.5-5.6 OSS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-



Camera Brand	Model	Lens Model	Balance Adjustment	Installation Remark	Note
Sony	α6300	FE 14mm F1.8 GM	√	No need to remove eyepiece cap	-
		FE 20mm F1.8 G	√	No need to remove eyepiece cap	-
		Sonnar T* E 24mm F1.8 ZA	√	No need to remove eyepiece cap	-
		FE 24mm F2.8 G	√	No need to remove eyepiece cap	-
		FE 28mm F2	√	No need to remove eyepiece cap	-
		Sigma 30mm f/1.4 DC DN	√	No need to remove eyepiece cap	-
		FE 35mm F1.8	√	No need to remove eyepiece cap	-
		Sonnar T* FE 35mm F2.8 ZA	√	No need to remove eyepiece cap	-
		FE 40mm F2.5 G	√	No need to remove eyepiece cap	-
		Sigma45mm f/2.8 DG DN	√	No need to remove eyepiece cap	-
		FE 50mm F1.8	√	No need to remove eyepiece cap	-
		FE 50mm F2.5 G	√	No need to remove eyepiece cap	-
		FE 50mm F2.8	√	No need to remove eyepiece cap	-
		Sonnar® T* FE 55mm F1.8 ZA	√	No need to remove eyepiece cap	-
		FE 85mm f/1.8	√	No need to remove eyepiece cap	-
		E 10-18mm F4 OSS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		E 16-70mm F4 ZA OSS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		FE 28-60mm F4-5.6	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		Sigma28-70mm f/2.8 DG DN	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		FE 28-70mm F3.5-5.6 OSS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-



Camera Brand	Model	Lens Model	Balance Adjustment	Installation Remark	Note
Sony	α6100	FE 14mm F1.8 GM	√	No need to remove eyepiece cap	-
		FE 20mm F1.8 G	√	No need to remove eyepiece cap	-
		Sonnar T* E 24mm F1.8 ZA	√	No need to remove eyepiece cap	-
		FE 24mm F2.8 G	√	No need to remove eyepiece cap	-
		FE 28mm F2	√	No need to remove eyepiece cap	-
		Sigma 30mm f/1.4 DC DN	√	No need to remove eyepiece cap	-
		FE 35mm F1.8	√	No need to remove eyepiece cap	-
		Sonnar T* FE 35mm F2.8 ZA	√	No need to remove eyepiece cap	-
		FE 40mm F2.5 G	√	No need to remove eyepiece cap	-
		Sigma45mm f/2.8 DG DN	√	No need to remove eyepiece cap	-
		FE 50mm F1.8	√	No need to remove eyepiece cap	-
		FE 50mm F2.5 G	√	No need to remove eyepiece cap	-
		FE 50mm F2.8	√	No need to remove eyepiece cap	-
		Sonnar® T* FE 55mm F1.8 ZA	√	No need to remove eyepiece cap	-
		FE 85mm f/1.8	√	No need to remove eyepiece cap	-
		E 10-18mm F4 OSS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		E 16-70mm F4 ZA OSS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		FE 28-60mm F4-5.6	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		Sigma28-70mm f/2.8 DG DN	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		FE 28-70mm F3.5-5.6 OSS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-



Camera Brand	Model	Lens Model	Balance Adjustment	Installation Remark	Note
Sony	ZV-E10	FE 14mm F1.8 GM	√	No need to remove eyepiece cap	-
		FE 20mm F1.8 G	√	No need to remove eyepiece cap	-
		Sonnar T* E 24mm F1.8 ZA	√	No need to remove eyepiece cap	-
		FE 24mm F2.8 G	√	No need to remove eyepiece cap	-
		FE 28mm F2	√	No need to remove eyepiece cap	-
		Sigma 30mm f/1.4 DC DN	√	No need to remove eyepiece cap	-
		FE 35mm F1.8	√	No need to remove eyepiece cap	-
		Sonnar T* FE 35mm F2.8 ZA	√	No need to remove eyepiece cap	-
		FE 40mm F2.5 G	√	No need to remove eyepiece cap	-
		Sigma45mm f/2.8 DG DN	√	No need to remove eyepiece cap	-
		FE 50mm F1.8	√	No need to remove eyepiece cap	-
		FE 50mm F2.5 G	√	No need to remove eyepiece cap	-
		FE 50mm F2.8	√	No need to remove eyepiece cap	-
		Sonnar® T* FE 55mm F1.8 ZA	√	No need to remove eyepiece cap	-
		FE 85mm f/1.8	√	No need to remove eyepiece cap	-
		E 10-18mm F4 OSS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		E 16-70mm F4 ZA OSS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		FE 28-60mm F4-5.6	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		Sigma28-70mm f/2.8 DG DN	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		FE 28-70mm F3.5-5.6 OSS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	DSC-RX100M5A	Comes with the lens	√	-	Should be powered on to balance
	DSC-RX100M5	Comes with the lens	√	-	Should be powered on to balance
	DSC-RX100M6	Comes with the lens	√	-	Should be powered on to balance
	DSC-RX100M7	Comes with the lens	√	-	Should be powered on to balance
	DSC-WX350	Comes with the lens	√	-	Should be powered on to balance



Camera Brand	Model	Lens Model	Balance Adjustment	Installation Remark	Note
Sony	DSC-HX90	Comes with the lens	√	-	Should be powered on to balance
	ZV-1	Comes with the lens	√	-	Should be powered on to balance
Canon	EOS R	RF50mm F1.8 STM	√	Do not remove eyepiece cap	-
	EOS RP	EF 50mm f/1.4 USM (adapter)	√	Do not remove eyepiece cap	-
		EF 85mm f/1.8 USM (adapter)	√	Do not remove eyepiece cap	-
		EF 50mm f/1.8 USM (adapter)	√	Do not remove eyepiece cap	-
		RF35mm F1.8 MACRO IS STM	√	Do not remove eyepiece cap	-
		RF50mm F1.8 STM	√	Do not remove eyepiece cap	-
	EOS R5	RF50mm F1.8 STM	√	Do not remove eyepiece cap	-
	EOS R6	RF50mm F1.8 STM	√	Do not remove eyepiece cap	-
	EOS M50	EF-M 22mm f/2 STM	√	Do not remove eyepiece cap	-
		EF-M 28mm f/3.5 IS STM	√	Do not remove eyepiece cap	-
		EF-M 32mm f/1.4 STM	√	Do not remove eyepiece cap	-
		EF-M 11-22mm f/4-5.6 IS STM	√	Can be balanced at any focal length, do not remove eyepiece cap	-
		EF-M 15-45mm f/3.5-6.3 IS STM	√	Can be balanced at any focal length, do not remove eyepiece cap	-
		EF-M 18-55mm f/3.5-5.6 IS STM	√	Can be balanced at any focal length, do not remove eyepiece cap	-
		EF-M 18-150mm f/3.5-6.3 IS STM	√	Can be balanced at 18-50mm, Do not remove eyepiece cap	Interference exists between eyepiece cap and roll axis motor at 50-105mm
	M50 Mark II	EF-M 22mm f/2 STM	√	Do not remove eyepiece cap	-
		EF-M 28mm f/3.5 IS STM	√	Do not remove eyepiece cap	-
		EF-M 32mm f/1.4 STM	√	Do not remove eyepiece cap	-
		EF-M 11-22mm f/4-5.6 IS STM	√	Can be balanced at any focal length, do not remove eyepiece cap	-
		EF-M 15-45mm f/3.5-6.3 IS STM	√	Can be balanced at any focal length, do not remove eyepiece cap	-
		EF-M 18-55mm f/3.5-5.6 IS STM	√	Can be balanced at any focal length, do not remove eyepiece cap	-
EF-M 18-150mm f/3.5-6.3 IS STM		√	Can be balanced at 18-50mm, Do not remove eyepiece cap	Interference exists between eyepiece cap and roll axis motor at 50-105mm	



Camera Brand	Model	Lens Model	Balance Adjustment	Installation Remark	Note
Canon	EOS M6	EF-M 22mm f/2 STM	√	-	-
		EF-M 28mm f/3.5 IS STM	√	-	-
		EF-M 32mm f/1.4 STM	√	-	-
		EF-M 11-22mm f/4-5.6 IS STM	√	Can be balanced at any focal length;	-
		EF-M 15-45mm f/3.5-6.3 IS STM	√	Can be balanced at any focal length;	-
		EF-M 18-55mm f/3.5-5.6 IS STM	√	Can be balanced at any focal length;	-
		EF-M 18-150mm f/3.5-6.3 IS STM	√	Can be balanced at any focal length;	-
	EOS M6 Mark II	EF-M 22mm f/2 STM	√	-	-
		EF-M 28mm f/3.5 IS STM	√	-	-
		EF-M 32mm f/1.4 STM	√	-	-
		EF-M 11-22mm f/4-5.6 IS STM	√	Can be balanced at any focal length;	-
		EF-M 15-45mm f/3.5-6.3 IS STM	√	Can be balanced at any focal length;	-
		EF-M 18-55mm f/3.5-5.6 IS STM	√	Can be balanced at any focal length;	-
		EF-M 18-150mm f/3.5-6.3 IS STM	√	Can be balanced at any focal length;	-



Camera Brand	Model	Lens Model	Balance Adjustment	Installation Remark	Note
Canon	EOS 200D	EF 24mm f/2.8 IS USM	√	No need to remove eyepiece cap	-
		EF-S 24mm f/2.8 STM	√	No need to remove eyepiece cap	-
		EF 35mm f/2 IS USM	√	No need to remove eyepiece cap	-
		EF-S 35mm f/2.8 IS STM MC	√	No need to remove eyepiece cap	-
		EF 50mm f/1.4 USM	√	No need to remove eyepiece cap	-
		EF 50mm f/1.8 STM	√	No need to remove eyepiece cap	-
		EF-S 10-18mm f/4.5-5.6 IS STM	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		EF-S 18-55mm f/3.5-5.6 IS STM	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		EF-S 18-55mm f/4-5.6 IS STM	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	EOS 200D Mark II	EF 24mm f/2.8 IS USM	√	No need to remove eyepiece cap	-
		EF-S 24mm f/2.8 STM	√	No need to remove eyepiece cap	-
		EF 35mm f/2 IS USM	√	No need to remove eyepiece cap	-
		EF-S 35mm f/2.8 IS STM MC	√	No need to remove eyepiece cap	-
		EF 50mm f/1.4 USM	√	No need to remove eyepiece cap	-
		EF 50mm f/1.8 STM	√	No need to remove eyepiece cap	-
		EF-S 10-18mm f/4.5-5.6 IS STM	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		EF-S 18-55mm f/3.5-5.6 IS STM	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		EF-S 18-55mm f/4-5.6 IS STM	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	PowerShot G1X Mark II	Comes with the lens	√	Should be powered on to balance	-
	PowerShot G7X Mark III	Comes with the lens	√	Should be powered on to balance	-
	PowerShot SX720 HS	Comes with the lens	√	Should be powered on to balance	-
Nikon	Z50	NIKKOR Z 28mm f/2.8 (SE)	√	-	-
		NIKKOR Z 35mm f/1.8S	√	-	-
		NIKKOR Z 40mm f/2	√	-	-
		NIKKOR Z 50mm f/1.8	√	-	-



Camera Brand	Model	Lens Model	Balance Adjustment	Installation Remark	Note
Nikon	Z50	NIKKOR Z MC 50mm f/2.8	√	-	-
		NIKKOR Z DX 16-50mm f/3.5-6.3 VR	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		NIKKOR Z 24-50mm f/4-6.3	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	Z5	NIKKOR Z 28mm f/2.8 (SE)	√	-	-
		NIKKOR Z 40mm f/2	√	-	-
		NIKKOR Z MC 50mm f/2.8	√	-	-
		NIKKOR Z DX 16-50mm f/3.5-6.3 VR	√	Can be balanced at any focal length, need to remove eyepiece cap	-
		NIKKOR Z 24-50mm f/4-6.3	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	Z6	NIKKOR Z 28mm f/2.8 (SE)	√	-	-
		NIKKOR Z 40mm f/2	√	-	-
		NIKKOR Z DX 16-50mm f/3.5-6.3 VR	√	Can be balanced at any focal length, need to remove eyepiece cap	-
		NIKKOR Z 24-50mm f/4-6.3	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	Z6 II	NIKKOR Z 28mm f/2.8 (SE)	√	-	-
		NIKKOR Z 40mm f/2	√	-	-
		NIKKOR Z DX 16-50mm f/3.5-6.3 VR	√	Can be balanced at any focal length, need to remove eyepiece cap	-
		NIKKOR Z 24-50mm f/4-6.3	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	Z7	NIKKOR Z 28mm f/2.8 (SE)	√	-	-
		NIKKOR Z 40mm f/2	√	-	-
		NIKKOR Z DX 16-50mm f/3.5-6.3 VR	√	Can be balanced at any focal length, need to remove eyepiece cap	-
		NIKKOR Z 24-50mm f/4-6.3	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	Z7 II	NIKKOR Z 28mm f/2.8 (SE)	√	-	-
		NIKKOR Z 40mm f/2	√	-	-
		NIKKOR Z DX 16-50mm f/3.5-6.3 VR	√	Can be balanced at any focal length, need to remove eyepiece cap	-
		NIKKOR Z 24-50mm f/4-6.3	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	Zfc	NIKKOR Z 35mm f/1.8S	√	-	-
		NIKKOR Z 28mm f/2.8 (SE)	√	-	-



Camera Brand	Model	Lens Model	Balance Adjustment	Installation Remark	Note
Nikon	Zfc	NIKKOR Z 40mm f/2	√	-	-
		NIKKOR Z 50mm f/1.8	√	-	-
		NIKKOR Z MC 50mm f/2.8	√	-	-
		NIKKOR Z DX 16-50mm f/3.5-6.3 VR	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		NIKKOR Z 24-50mm f/4-6.3	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
FUJIFILM	X-T20	XF14mmF2.8 R	√	No need to remove eyepiece cap	-
		XF16mmF2.8 R WR	√	No need to remove eyepiece cap	-
		XF18mmF1.4 R	√	No need to remove eyepiece cap	-
		XF18mmF2 R	√	No need to remove eyepiece cap	-
		Super EBC XF 23mm f/1.4 R	√	No need to remove eyepiece cap	-
		XF23mmF2 R WR	√	No need to remove eyepiece cap	-
		XF27mmF2.8	√	No need to remove eyepiece cap	-
		XF 35mm f/1.4 R	√	No need to remove eyepiece cap	-
		XF 35mm f/2 R WR	√	No need to remove eyepiece cap	-
		XF56mmF1.2 R	√	No need to remove eyepiece cap	-
		XF60mmF2.4 R Macro	√	No need to remove eyepiece cap	-
		XC 15-45mm f/3.5-5.6 OIS	√	Can be balanced at any focal length, no need to remove eyepiece cap	Should be powered on to balance
		XF 18-55mm f/2.8-4 R OIS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	X-A7	XF14mmF2.8 R	√	No need to remove eyepiece cap	-
		XF16mmF2.8 R WR	√	No need to remove eyepiece cap	-
		XF18mmF1.4 R	√	No need to remove eyepiece cap	-
		XF18mmF2 R	√	No need to remove eyepiece cap	-
		Super EBC XF 23mm f/1.4 R	√	No need to remove eyepiece cap	-
		XF23mmF2 R WR	√	No need to remove eyepiece cap	-
		XF27mmF2.8	√	No need to remove eyepiece cap	-



Camera Brand	Model	Lens Model	Balance Adjustment	Installation Remark	Note
FUJIFILM	X-A7	XF 35mm f/1.4 R	√	No need to remove eyepiece cap	-
		XF 35mm f/2 R WR	√	No need to remove eyepiece cap	-
		XF56mmF1.2 R	√	No need to remove eyepiece cap	-
		XF60mmF2.4 R Macro	√	No need to remove eyepiece cap	-
		XC 15-45mm f/3.5-5.6 OIS	√	Can be balanced at any focal length, no need to remove eyepiece cap	Should be powered on to balance
		XF 18-55mm f/2.8-4 R OIS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	X-T2	XF14mmF2.8 R	√	No need to remove eyepiece cap	-
		XF16mmF2.8 R WR	√	No need to remove eyepiece cap	-
		XF18mmF1.4 R	√	No need to remove eyepiece cap	-
		XF18mmF2 R	√	No need to remove eyepiece cap	-
		Super EBC XF 23mm f/1.4 R	√	No need to remove eyepiece cap	-
		XF23mmF2 R WR	√	No need to remove eyepiece cap	-
		XF27mmF2.8	√	No need to remove eyepiece cap	-
		XF 35mm f/1.4 R	√	No need to remove eyepiece cap	-
		XF 35mm f/2 R WR	√	No need to remove eyepiece cap	-
		XF56mmF1.2 R	√	No need to remove eyepiece cap	-
		XF60mmF2.4 R Macro	√	No need to remove eyepiece cap	-
		XC 15-45mm f/3.5-5.6 OIS	√	Can be balanced at any focal length, no need to remove eyepiece cap	Should be powered on to balance
		XF 18-55mm f/2.8-4 R OIS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-



Camera Brand	Model	Lens Model	Balance Adjustment	Installation Remark	Note
FUJIFILM	X-T3	XF14mmF2.8 R	√	No need to remove eyepiece cap	-
		XF16mmF2.8 R WR	√	No need to remove eyepiece cap	-
		XF18mmF1.4 R	√	No need to remove eyepiece cap	-
		XF18mmF2 R	√	No need to remove eyepiece cap	-
		Super EBC XF 23mm f/1.4 R	√	No need to remove eyepiece cap	-
		XF23mmF2 R WR	√	No need to remove eyepiece cap	-
		XF27mmF2.8	√	No need to remove eyepiece cap	-
		XF 35mm f/1.4 R	√	No need to remove eyepiece cap	-
		XF 35mm f/2 R WR	√	No need to remove eyepiece cap	-
		XF60mmF2.4 R Macro	√	No need to remove eyepiece cap	-
		XC 15-45mm f/3.5-5.6 OIS	√	Can be balanced at any focal length, no need to remove eyepiece cap	Should be powered on to balance
		XF 18-55mm f/2.8-4 R OIS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-



Camera Brand	Model	Lens Model	Balance Adjustment	Installation Remark	Note
FUJIFILM	X-T4	XF14mmF2.8 R	√	No need to remove eyepiece cap	-
		XF16mmF2.8 R WR	√	No need to remove eyepiece cap	-
		XF18mmF2 R	√	No need to remove eyepiece cap	-
		Super EBC XF 23mm f/1.4 R	√	Need to remove eyepiece cap	-
		XF23mmF2 R WR	√	No need to remove eyepiece cap	-
		XF27mmF2.8	√	No need to remove eyepiece cap	-
		XF 35mm f/1.4 R	√	No need to remove eyepiece cap	-
		XF 35mm f/2 R WR	√	No need to remove eyepiece cap	-
		XF60mmF2.4 R Macro	√	No need to remove eyepiece cap	-
		XC 15-45mm f/3.5-5.6 OIS	√	Can be balanced at any focal length, no need to remove eyepiece cap	Should be powered on to balance
		XF 18-55mm f/2.8-4 R OIS	√	Can be balanced at any focal length, need to remove eyepiece cap	-
	X-S10	XF14mmF2.8 R	√	No need to remove eyepiece cap	-
		XF16mmF2.8 R WR	√	No need to remove eyepiece cap	-
		XF18mmF1.4 R	√	No need to remove eyepiece cap	-
		Super EBC XF 23mm f/1.4 R	√	Need to remove eyepiece cap	-
		XF18mmF2 R	√	No need to remove eyepiece cap	-
		XF23mmF2 R WR	√	No need to remove eyepiece cap	-
		XF27mmF2.8	√	No need to remove eyepiece cap	-
		XF 35mm f/1.4 R	√	No need to remove eyepiece cap	-
		XF 35mm f/2 R WR	√	No need to remove eyepiece cap	-
		XF56mmF1.2 R	√	No need to remove eyepiece cap	-
		XF60mmF2.4 R Macro	√	No need to remove eyepiece cap	-
XC 15-45mm f/3.5-5.6 OIS	√	Can be balanced at any focal length, no need to remove eyepiece cap	Should be powered on to balance		
XF 18-55mm f/2.8-4 R OIS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-		



Camera Brand	Model	Lens Model	Balance Adjustment	Installation Remark	Note
FUJIFILM	X-T30	XF14mmF2.8 R	√	No need to remove eyepiece cap	-
		XF16mmF2.8 R WR	√	No need to remove eyepiece cap	-
		XF18mmF1.4 R	√	No need to remove eyepiece cap	-
		XF18mmF2 R	√	No need to remove eyepiece cap	-
		Super EBC XF 23mm f/1.4 R	√	No need to remove eyepiece cap	-
		XF23mmF2 R WR	√	No need to remove eyepiece cap	-
		XF27mmF2.8	√	No need to remove eyepiece cap	-
		XF 35mm f/1.4 R	√	No need to remove eyepiece cap	-
		XF 35mm f/2 R WR	√	No need to remove eyepiece cap	-
		XF56mmF1.2 R	√	No need to remove eyepiece cap	-
		XF60mmF2.4 R Macro	√	No need to remove eyepiece cap	-
		XC 15-45mm f/3.5-5.6 OIS	√	Can be balanced at any focal length, no need to remove eyepiece cap	Should be powered on to balance
XF 18-55mm f/2.8-4 R OIS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-		
Panasonic	DC-G100	LEICA DG SUMMILUX 15mm f/1.7 ASPH	√	No need to remove eyepiece cap	-
		Lumix G 25mm f/1.4	√	No need to remove eyepiece cap	-
		Lumix G 25mm f/1.7	√	No need to remove eyepiece cap	-
		LUMIX G MACRO 30mm f/2.8 ASPH MEGA OIS	√	No need to remove eyepiece cap	-
		LEICA DG Vario-Elmarit 8-18mm f/2.8-4.0 ASPH	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		12-32 0.2m/0.66ft	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	Lumix G X Vario 12-35mm f/2.8 II ASPH POWER OIS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-	
	DMC-GH4	LEICA DG SUMMILUX 15mm f/1.7 ASPH	√	No need to remove eyepiece cap	-
		Lumix G 25mm f/1.4	√	No need to remove eyepiece cap	-
		Lumix G 25mm f/1.7	√	No need to remove eyepiece cap	-
LUMIX G MACRO 30mm f/2.8 ASPH MEGA OIS		√	No need to remove eyepiece cap	-	
		12-32 0.2m/0.66ft	√	Can be balanced at any focal length, no need to remove eyepiece cap	-



Camera Brand	Model	Lens Model	Balance Adjustment	Installation Remark	Note
Panasonic	DMC-GH5	LEICA DG SUMMILUX 15mm f/1.7 ASPH	√	No need to remove eyepiece cap	-
		Lumix G 25mm f/1.4	√	No need to remove eyepiece cap	-
		Lumix G 25mm f/1.7	√	No need to remove eyepiece cap	-
		LUMIX G MACRO 30mm f/2.8 ASPH MEGA OIS	√	No need to remove eyepiece cap	-
		12-32 0.2m/0.66ft	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	DMC-GH5S	LEICA DG SUMMILUX 15mm f/1.7 ASPH	√	No need to remove eyepiece cap	-
		Lumix G 25mm f/1.4	√	No need to remove eyepiece cap	-
		Lumix G 25mm f/1.7	√	No need to remove eyepiece cap	-
		LUMIX G MACRO 30mm f/2.8 ASPH MEGA OIS	√	No need to remove eyepiece cap	-
		12-32 0.2m/0.66ft	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	DMC-LX100M2	Comes with the lens	√	-	Should be powered on to balance
	DMC-LX10	Comes with the lens	√	-	Should be powered on to balance
	DMC-ZS110	Comes with the lens	√	-	Should be powered on to balance
SIGMA	fp	45mm F2.8	√	-	-

CRANE-M3 Camera Compatibility List (Quick Release Plate)

Camera Brand	Model	Lens Model	Balance Adjustment	Installation Remark	Note
Sony	α7M2	FE 24mm F2.8 G	√	No need to remove eyepiece cap	-
		FE 28mm F2	√	No need to remove eyepiece cap	-
		FE 35mm F1.8	√	Need to remove eyepiece cap	-
		Sonnar T* FE 35mm F2.8 ZA	√	No need to remove eyepiece cap	-
		FE 40mm F2.5 G	√	No need to remove eyepiece cap	-
		Sigma45mm f/2.8 DG DN	√	No need to remove eyepiece cap	-
		FE 50mm F1.8	√	No need to remove eyepiece cap	-
		FE 50mm F2.5 G	√	No need to remove eyepiece cap	-
	α7R2	FE 24mm F2.8 G	√	No need to remove eyepiece cap	-
		FE 28mm F2	√	No need to remove eyepiece cap	-
		FE 35mm F1.8	√	Need to remove eyepiece cap	-
		Sonnar T* FE 35mm F2.8 ZA	√	No need to remove eyepiece cap	-
		FE 40mm F2.5 G	√	No need to remove eyepiece cap	-
		Sigma45mm f/2.8 DG DN	√	No need to remove eyepiece cap	-
		FE 50mm F1.8	√	No need to remove eyepiece cap	-
		FE 50mm F2.5 G	√	No need to remove eyepiece cap	-
	α7S2	FE 24mm F2.8 G	√	No need to remove eyepiece cap	-
		FE 28mm F2	√	No need to remove eyepiece cap	-
		FE 35mm F1.8	√	Need to remove eyepiece cap	-
		Sonnar T* FE 35mm F2.8 ZA	√	No need to remove eyepiece cap	-
		FE 40mm F2.5 G	√	No need to remove eyepiece cap	-
		Sigma45mm f/2.8 DG DN	√	No need to remove eyepiece cap	-
		FE 50mm F1.8	√	No need to remove eyepiece cap	-
		FE 50mm F2.5 G	√	No need to remove eyepiece cap	-



Camera Brand	Model	Lens Model	Balance Adjustment	Installation Remark	Note
Sony	α7M3	FE 24mm F2.8 G	√	No need to remove eyepiece cap	-
		FE 28mm F2	√	No need to remove eyepiece cap	-
		FE 35mm F1.8	√	Need to remove eyepiece cap	-
		Sonnar T* FE 35mm F2.8 ZA	√	No need to remove eyepiece cap	-
		FE 40mm F2.5 G	√	No need to remove eyepiece cap	-
		Sigma45mm f/2.8 DG DN	√	No need to remove eyepiece cap	-
		FE 50mm F1.8	√	No need to remove eyepiece cap	-
		FE 50mm F2.5 G	√	No need to remove eyepiece cap	-
	α7R3	FE 24mm F2.8 G	√	No need to remove eyepiece cap	-
		FE 28mm F2	√	No need to remove eyepiece cap	-
		FE 35mm F1.8	√	Need to remove eyepiece cap	-
		Sonnar T* FE 35mm F2.8 ZA	√	No need to remove eyepiece cap	-
		FE 40mm F2.5 G	√	No need to remove eyepiece cap	-
		Sigma45mm f/2.8 DG DN	√	No need to remove eyepiece cap	-
		FE 50mm F1.8	√	No need to remove eyepiece cap	-
		FE 50mm F2.5 G	√	No need to remove eyepiece cap	-
	α7S3	FE 24mm F2.8 G	√	No need to remove eyepiece cap	-
		FE 28mm F2	√	No need to remove eyepiece cap	-
		Sonnar T* FE 35mm F2.8 ZA	√	No need to remove eyepiece cap	-
		FE 40mm F2.5 G	√	No need to remove eyepiece cap	-
		Sigma45mm f/2.8 DG DN	√	No need to remove eyepiece cap	-
		FE 50mm F1.8	√	No need to remove eyepiece cap	-
		FE 50mm F2.5 G	√	No need to remove eyepiece cap	-



Camera Brand	Model	Lens Model	Balance Adjustment	Installation Remark	Note
Sony	α7R4	FE 24mm F2.8 G	√	No need to remove eyepiece cap	-
		FE 28mm F2	√	No need to remove eyepiece cap	-
		FE 35mm F1.8	√	Need to remove eyepiece cap	-
		Sonnar T* FE 35mm F2.8 ZA	√	No need to remove eyepiece cap	-
		FE 40mm F2.5 G	√	No need to remove eyepiece cap	-
		Sigma45mm f/2.8 DG DN	√	No need to remove eyepiece cap	-
		FE 50mm F1.8	√	No need to remove eyepiece cap	-
		FE 50mm F2.5 G	√	No need to remove eyepiece cap	-
	FX3	FE 24mm F2.8 G	√	No need to remove eyepiece cap	-
		FE 28mm F2	√	No need to remove eyepiece cap	-
		Sonnar T* FE 35mm F2.8 ZA	√	No need to remove eyepiece cap	-
		FE 40mm F2.5 G	√	No need to remove eyepiece cap	-
		Sigma45mm f/2.8 DG DN	√	No need to remove eyepiece cap	-
		FE 50mm F1.8	√	No need to remove eyepiece cap	-
		FE 50mm F2.5 G	√	No need to remove eyepiece cap	-
	α7C	FE 20mm F1.8 G	√	No need to remove eyepiece cap	-
		FE 24mm F2.8 G	√	No need to remove eyepiece cap	-
		FE 28mm F2	√	No need to remove eyepiece cap	-
		FE 35mm F1.8	√	No need to remove eyepiece cap	-
		Sonnar T* FE 35mm F2.8 ZA	√	No need to remove eyepiece cap	-
		FE 40mm F2.5 G	√	No need to remove eyepiece cap	-
		Sigma45mm f/2.8 DG DN	√	No need to remove eyepiece cap	-
		FE 50mm F1.8	√	No need to remove eyepiece cap	-
		FE 50mm F2.5 G	√	No need to remove eyepiece cap	-
		FE 50mm F2.8	√	No need to remove eyepiece cap	-



Camera Brand	Model	Lens Model	Balance Adjustment	Installation Remark	Note
Sony	α7C	Sonnar® T* FE 55mm F1.8 ZA	√	No need to remove eyepiece cap	-
		FE 28-60mm F4-5.6	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		FE 28-70mm F3.5-5.6 OSS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	α6600	FE 14mm F1.8 GM	√	No need to remove eyepiece cap	-
		FE 20mm F1.8 G	√	No need to remove eyepiece cap	-
		Sonnar T* E 24mm F1.8 ZA	√	No need to remove eyepiece cap	-
		FE 24mm F2.8 G	√	No need to remove eyepiece cap	-
		FE 28mm F2	√	No need to remove eyepiece cap	-
		Sigma 30mm f/1.4 DC DN	√	No need to remove eyepiece cap	-
		FE 35mm F1.8	√	No need to remove eyepiece cap	-
		Sonnar T* FE 35mm F2.8 ZA	√	No need to remove eyepiece cap	-
		FE 40mm F2.5 G	√	No need to remove eyepiece cap	-
		Sigma45mm f/2.8 DG DN	√	No need to remove eyepiece cap	-
		FE 50mm F1.8	√	No need to remove eyepiece cap	-
		FE 50mm F2.5 G	√	No need to remove eyepiece cap	-
		FE 50mm F2.8	√	No need to remove eyepiece cap	-
		Sonnar® T* FE 55mm F1.8 ZA	√	No need to remove eyepiece cap	-
		FE 85mm f/1.8	√	No need to remove eyepiece cap	-
		E 10-18mm F4 OSS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		E 16-70mm F4 ZA OSS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		FE 28-60mm F4-5.6	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		Sigma28-70mm f/2.8 DG DN	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		FE 28-70mm F3.5-5.6 OSS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		α6500	FE 14mm F1.8 GM	√	No need to remove eyepiece cap
	FE 20mm F1.8 G		√	No need to remove eyepiece cap	-



Camera Brand	Model	Lens Model	Balance Adjustment	Installation Remark	Note
Sony	α6500	Sonnar T* E 24mm F1.8 ZA	√	No need to remove eyepiece cap	-
		FE 24mm F2.8 G	√	No need to remove eyepiece cap	-
		FE 28mm F2	√	No need to remove eyepiece cap	-
		Sigma 30mm f/1.4 DC DN	√	No need to remove eyepiece cap	-
		FE 35mm F1.8	√	No need to remove eyepiece cap	-
		Sonnar T* FE 35mm F2.8 ZA	√	No need to remove eyepiece cap	-
		FE 40mm F2.5 G	√	No need to remove eyepiece cap	-
		Sigma45mm f/2.8 DG DN	√	No need to remove eyepiece cap	-
		FE 50mm F1.8	√	No need to remove eyepiece cap	-
		FE 50mm F2.5 G	√	No need to remove eyepiece cap	-
		FE 50mm F2.8	√	No need to remove eyepiece cap	-
		Sonnar® T* FE 55mm F1.8 ZA	√	No need to remove eyepiece cap	-
		FE 85mm f/1.8	√	No need to remove eyepiece cap	-
		E 10-18mm F4 OSS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		E 16-70mm F4 ZA OSS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		FE 28-60mm F4-5.6	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		Sigma28-70mm f/2.8 DG DN	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		FE 28-70mm F3.5-5.6 OSS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-



Camera Brand	Model	Lens Model	Balance Adjustment	Installation Remark	Note
Sony	α6400	FE 14mm F1.8 GM	√	No need to remove eyepiece cap	-
		FE 20mm F1.8 G	√	No need to remove eyepiece cap	-
		Sonnar T* E 24mm F1.8 ZA	√	No need to remove eyepiece cap	-
		FE 24mm F2.8 G	√	No need to remove eyepiece cap	-
		FE 28mm F2	√	No need to remove eyepiece cap	-
		Sigma 30mm f/1.4 DC DN	√	No need to remove eyepiece cap	-
		FE 35mm F1.8	√	No need to remove eyepiece cap	-
		Sonnar T* FE 35mm F2.8 ZA	√	No need to remove eyepiece cap	-
		FE 40mm F2.5 G	√	No need to remove eyepiece cap	-
		Sigma45mm f/2.8 DG DN	√	No need to remove eyepiece cap	-
		FE 50mm F1.8	√	No need to remove eyepiece cap	-
		FE 50mm F2.5 G	√	No need to remove eyepiece cap	-
		FE 50mm F2.8	√	No need to remove eyepiece cap	-
		Sonnar® T* FE 55mm F1.8 ZA	√	No need to remove eyepiece cap	-
		FE 85mm f/1.8	√	No need to remove eyepiece cap	-
		E 10-18mm F4 OSS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		E 16-70mm F4 ZA OSS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		FE 28-60mm F4-5.6	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		Sigma28-70mm f/2.8 DG DN	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		FE 28-70mm F3.5-5.6 OSS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-



Camera Brand	Model	Lens Model	Balance Adjustment	Installation Remark	Note
Sony	α6300	FE 14mm F1.8 GM	√	No need to remove eyepiece cap	-
		FE 20mm F1.8 G	√	No need to remove eyepiece cap	-
		Sonnar T* E 24mm F1.8 ZA	√	No need to remove eyepiece cap	-
		FE 24mm F2.8 G	√	No need to remove eyepiece cap	-
		FE 28mm F2	√	No need to remove eyepiece cap	-
		Sigma 30mm f/1.4 DC DN	√	No need to remove eyepiece cap	-
		FE 35mm F1.8	√	No need to remove eyepiece cap	-
		Sonnar T* FE 35mm F2.8 ZA	√	No need to remove eyepiece cap	-
		FE 40mm F2.5 G	√	No need to remove eyepiece cap	-
		Sigma45mm f/2.8 DG DN	√	No need to remove eyepiece cap	-
		FE 50mm F1.8	√	No need to remove eyepiece cap	-
		FE 50mm F2.5 G	√	No need to remove eyepiece cap	-
		FE 50mm F2.8	√	No need to remove eyepiece cap	-
		Sonnar® T* FE 55mm F1.8 ZA	√	No need to remove eyepiece cap	-
		FE 85mm f/1.8	√	No need to remove eyepiece cap	-
		E 10-18mm F4 OSS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		E 16-70mm F4 ZA OSS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		FE 28-60mm F4-5.6	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		Sigma28-70mm f/2.8 DG DN	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		FE 28-70mm F3.5-5.6 OSS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	α6100	FE 14mm F1.8 GM	√	No need to remove eyepiece cap	-
		FE 20mm F1.8 G	√	No need to remove eyepiece cap	-
		Sonnar T* E 24mm F1.8 ZA	√	No need to remove eyepiece cap	-
		FE 24mm F2.8 G	√	No need to remove eyepiece cap	-
		FE 28mm F2	√	No need to remove eyepiece cap	-



Camera Brand	Model	Lens Model	Balance Adjustment	Installation Remark	Note
Sony	α6100	Sigma 30mm f/1.4 DC DN	√	No need to remove eyepiece cap	-
		FE 35mm F1.8	√	No need to remove eyepiece cap	-
		Sonnar T* FE 35mm F2.8 ZA	√	No need to remove eyepiece cap	-
		FE 40mm F2.5 G	√	No need to remove eyepiece cap	-
		Sigma45mm f/2.8 DG DN	√	No need to remove eyepiece cap	-
		FE 50mm F1.8	√	No need to remove eyepiece cap	-
		FE 50mm F2.5 G	√	No need to remove eyepiece cap	-
		FE 50mm F2.8	√	No need to remove eyepiece cap	-
		Sonnar® T* FE 55mm F1.8 ZA	√	No need to remove eyepiece cap	-
		FE 85mm f/1.8	√	No need to remove eyepiece cap	-
		E 10-18mm F4 OSS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		E 16-70mm F4 ZA OSS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		FE 28-60mm F4-5.6	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		Sigma28-70mm f/2.8 DG DN	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	FE 28-70mm F3.5-5.6 OSS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-	
	ZV-E10	FE 14mm F1.8 GM	√	No need to remove eyepiece cap	-
		FE 20mm F1.8 G	√	No need to remove eyepiece cap	-
		Sonnar T* E 24mm F1.8 ZA	√	No need to remove eyepiece cap	-
		FE 24mm F2.8 G	√	No need to remove eyepiece cap	-
		FE 28mm F2	√	No need to remove eyepiece cap	-
		Sigma 30mm f/1.4 DC DN	√	No need to remove eyepiece cap	-
		FE 35mm F1.8	√	No need to remove eyepiece cap	-
		Sonnar T* FE 35mm F2.8 ZA	√	No need to remove eyepiece cap	-
		FE 40mm F2.5 G	√	No need to remove eyepiece cap	-
Sigma45mm f/2.8 DG DN		√	No need to remove eyepiece cap	-	



Camera Brand	Model	Lens Model	Balance Adjustment	Installation Remark	Note
Sony	ZV-E10	FE 50mm F1.8	√	No need to remove eyepiece cap	-
		FE 50mm F2.5 G	√	No need to remove eyepiece cap	-
		FE 50mm F2.8	√	No need to remove eyepiece cap	-
		Sonnar® T* FE 55mm F1.8 ZA	√	No need to remove eyepiece cap	-
		FE 85mm f/1.8	√	No need to remove eyepiece cap	-
		E 10-18mm F4 OSS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		E 16-70mm F4 ZA OSS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		FE 28-60mm F4-5.6	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		Sigma28-70mm f/2.8 DG DN	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		FE 28-70mm F3.5-5.6 OSS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
Canon	EOS R	RF50mm F1.8 STM	√	Do not remove eyepiece cap	-
	EOS RP	RF35mm F1.8 MACRO IS STM	√	Do not remove eyepiece cap	-
		RF50mm F1.8 STM	√	Do not remove eyepiece cap	-
	EOS R5	RF50mm F1.8 STM	√	Do not remove eyepiece cap	-
	EOS R6	RF50mm F1.8 STM	√	Do not remove eyepiece cap	-
	EOS M50	EF-M 22mm f/2 STM	√	Do not remove eyepiece cap	-
		EF-M 28mm f/3.5 IS STM	√	Do not remove eyepiece cap	-
		EF-M 32mm f/1.4 STM	√	Do not remove eyepiece cap	-
		EF-M 11-22mm f/4-5.6 IS STM	√	Can be balanced at any focal length, do not remove eyepiece cap	-
		EF-M 15-45mm f/3.5-6.3 IS STM	√	Can be balanced at any focal length, do not remove eyepiece cap	-
EF-M 18-55mm f/3.5-5.6 IS STM		√	Can be balanced at any focal length, do not remove eyepiece cap	-	

Camera Brand	Model	Lens Model	Balance Adjustment	Installation Remark	Note
Canon	EOS M50	EF-M 18-150mm f/3.5-6.3 IS STM	√	Can be balanced at 18-50mm, Do not remove eyepiece cap	Interference exists between eyepiece cap and roll axis motor at 50-105mm
	M50 Mark II	EF-M 22mm f/2 STM	√	Do not remove eyepiece cap	-
		EF-M 28mm f/3.5 IS STM	√	Do not remove eyepiece cap	-
		EF-M 32mm f/1.4 STM	√	Do not remove eyepiece cap	-
		EF-M 11-22mm f/4-5.6 IS STM	√	Can be balanced at any focal length, do not remove eyepiece cap	-
		EF-M 15-45mm f/3.5-6.3 IS STM	√	Can be balanced at any focal length, do not remove eyepiece cap	-
		EF-M 18-55mm f/3.5-5.6 IS STM	√	Can be balanced at any focal length, do not remove eyepiece cap	-
		EF-M 18-150mm f/3.5-6.3 IS STM	√	Can be balanced at 18-50mm, Do not remove eyepiece cap	Interference exists between eyepiece cap and roll axis motor at 50-105mm
		EOS M6	EF-M 22mm f/2 STM	√	-
	EF-M 28mm f/3.5 IS STM		√	-	-
	EF-M 32mm f/1.4 STM		√	-	-
	EF-M 11-22mm f/4-5.6 IS STM		√	Can be balanced at any focal length;	-
	EF-M 15-45mm f/3.5-6.3 IS STM		√	Can be balanced at any focal length;	-
	EF-M 18-55mm f/3.5-5.6 IS STM		√	Can be balanced at any focal length;	-
	EF-M 18-150mm f/3.5-6.3 IS STM		√	Can be balanced at any focal length;	-
	EOS M6 Mark II	EF-M 22mm f/2 STM	√	-	-
		EF-M 28mm f/3.5 IS STM	√	-	-
		EF-M 32mm f/1.4 STM	√	-	-
		EF-M 11-22mm f/4-5.6 IS STM	√	Can be balanced at any focal length;	-
		EF-M 15-45mm f/3.5-6.3 IS STM	√	Can be balanced at any focal length;	-
		EF-M 18-55mm f/3.5-5.6 IS STM	√	Can be balanced at any focal length;	-
		EF-M 18-150mm f/3.5-6.3 IS STM	√	Can be balanced at any focal length;	-

Camera Brand	Model	Lens Model	Balance Adjustment	Installation Remark	Note
Canon	EOS 200D	EF 24mm f/2.8 IS USM	√	No need to remove eyepiece cap	-
		EF-S 24mm f/2.8 STM	√	No need to remove eyepiece cap	-
		EF 35mm f/2 IS USM	√	No need to remove eyepiece cap	-
		EF-S 35mm f/2.8 IS STM MC	√	No need to remove eyepiece cap	-
		EF 50mm f/1.4 USM	√	No need to remove eyepiece cap	-
		EF 50mm f/1.8 STM	√	No need to remove eyepiece cap	-
		EF-S 10-18mm f/4.5-5.6 IS STM	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		EF-S 18-55mm f/3.5-5.6 IS STM	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		EF-S 18-55mm f/4-5.6 IS STM	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	EOS 200D Mark II	EF 24mm f/2.8 IS USM	√	No need to remove eyepiece cap	-
		EF-S 24mm f/2.8 STM	√	No need to remove eyepiece cap	-
		EF 35mm f/2 IS USM	√	No need to remove eyepiece cap	-
		EF-S 35mm f/2.8 IS STM MC	√	No need to remove eyepiece cap	-
		EF 50mm f/1.4 USM	√	No need to remove eyepiece cap	-
		EF 50mm f/1.8 STM	√	No need to remove eyepiece cap	-
		EF-S 10-18mm f/4.5-5.6 IS STM	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
EF-S 18-55mm f/3.5-5.6 IS STM		√	Can be balanced at any focal length, no need to remove eyepiece cap	-	
EF-S 18-55mm f/4-5.6 IS STM		√	Can be balanced at any focal length, no need to remove eyepiece cap	-	



Camera Brand	Model	Lens Model	Balance Adjustment	Installation Remark	Note
Nikon	Z50	NIKKOR Z 28mm f/2.8 (SE)	√	-	-
		NIKKOR Z 35mm f/1.8S	√	-	-
		NIKKOR Z 40mm f/2	√	-	-
		NIKKOR Z 50mm f/1.8	√	-	-
		NIKKOR Z MC 50mm f/2.8	√	-	-
		NIKKOR Z DX 16-50mm f/3.5-6.3 VR	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		NIKKOR Z 24-50mm f/4-6.3	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	Z5	NIKKOR Z 28mm f/2.8 (SE)	√	-	-
		NIKKOR Z 40mm f/2	√	-	-
		NIKKOR Z DX 16-50mm f/3.5-6.3 VR	√	Can be balanced at any focal length, need to remove eyepiece cap	-
	Z6	NIKKOR Z 28mm f/2.8 (SE)	√	-	-
		NIKKOR Z 40mm f/2	√	-	-
		NIKKOR Z DX 16-50mm f/3.5-6.3 VR	√	Can be balanced at any focal length, need to remove eyepiece cap	-
	Z6 II	NIKKOR Z 28mm f/2.8 (SE)	√	-	-
		NIKKOR Z 40mm f/2	√	-	-
		NIKKOR Z DX 16-50mm f/3.5-6.3 VR	√	Can be balanced at any focal length, need to remove eyepiece cap	-
	Z7	NIKKOR Z 28mm f/2.8 (SE)	√	-	-
		NIKKOR Z 40mm f/2	√	-	-
		NIKKOR Z DX 16-50mm f/3.5-6.3 VR	√	Can be balanced at any focal length, need to remove eyepiece cap	-
	Z7 II	NIKKOR Z 28mm f/2.8 (SE)	√	-	-
		NIKKOR Z 40mm f/2	√	-	-
		NIKKOR Z DX 16-50mm f/3.5-6.3 VR	√	Can be balanced at any focal length, need to remove eyepiece cap	-
	Zfc	NIKKOR Z 28mm f/2.8 (SE)	√	-	-



Camera Brand	Model	Lens Model	Balance Adjustment	Installation Remark	Note
Nikon	Zfc	NIKKOR Z 40mm f/2	√	-	-
		NIKKOR Z 50mm f/1.8	√	-	-
		NIKKOR Z MC 50mm f/2.8	√	-	-
		NIKKOR Z DX 16-50mm f/3.5-6.3 VR	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		NIKKOR Z 24-50mm f/4-6.3	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
FUJIFILM	X-T2	XF14mmF2.8 R	√	No need to remove eyepiece cap	-
		XF16mmF2.8 R WR	√	No need to remove eyepiece cap	-
		XF18mmF1.4 R	√	No need to remove eyepiece cap	-
		XF18mmF2 R	√	No need to remove eyepiece cap	-
		Super EBC XF 23mm f/1.4 R	√	No need to remove eyepiece cap	-
		XF23mmF2 R WR	√	No need to remove eyepiece cap	-
		XF27mmF2.8	√	No need to remove eyepiece cap	-
		XF 35mm f/1.4 R	√	No need to remove eyepiece cap	-
		XF 35mm f/2 R WR	√	No need to remove eyepiece cap	-
		XF60mmF2.4 R Macro	√	No need to remove eyepiece cap	-
		XC 15-45mm f/3.5-5.6 OIS	√	Can be balanced at any focal length, no need to remove eyepiece cap	Should be powered on to balance
		XF 18-55mm f/2.8-4 R OIS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-



Camera Brand	Model	Lens Model	Balance Adjustment	Installation Remark	Note
FUJIFILM	X-T3	XF14mmF2.8 R	√	No need to remove eyepiece cap	-
		XF16mmF2.8 R WR	√	No need to remove eyepiece cap	-
		XF18mmF1.4 R	√	No need to remove eyepiece cap	-
		XF18mmF2 R	√	No need to remove eyepiece cap	-
		Super EBC XF 23mm f/1.4 R	√	No need to remove eyepiece cap	-
		XF23mmF2 R WR	√	No need to remove eyepiece cap	-
		XF27mmF2.8	√	No need to remove eyepiece cap	-
		XF 35mm f/1.4 R	√	No need to remove eyepiece cap	-
		XF 35mm f/2 R WR	√	No need to remove eyepiece cap	-
		XF60mmF2.4 R Macro	√	No need to remove eyepiece cap	-
		XC 15-45mm f/3.5-5.6 OIS	√	Can be balanced at any focal length, no need to remove eyepiece cap	Should be powered on to balance
		XF 18-55mm f/2.8-4 R OIS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	X-T4	XF14mmF2.8 R	√	No need to remove eyepiece cap	-
		XF16mmF2.8 R WR	√	No need to remove eyepiece cap	-
		XF18mmF2 R	√	No need to remove eyepiece cap	-
		XF27mmF2.8	√	No need to remove eyepiece cap	-
		XF 35mm f/2 R WR	√	No need to remove eyepiece cap	-
		XF60mmF2.4 R Macro	√	No need to remove eyepiece cap	-
		XC 15-45mm f/3.5-5.6 OIS	√	Can be balanced at any focal length, no need to remove eyepiece cap	Should be powered on to balance

Camera Brand	Model	Lens Model	Balance Adjustment	Installation Remark	Note
FUJIFILM	X-S10	XF14mmF2.8 R	√	No need to remove eyepiece cap	-
		XF16mmF2.8 R WR	√	No need to remove eyepiece cap	-
		XF18mmF1.4 R	√	No need to remove eyepiece cap	-
		XF18mmF2 R	√	No need to remove eyepiece cap	-
		Super EBC XF 23mm f/1.4 R	√	No need to remove eyepiece cap	-
		XF23mmF2 R WR	√	No need to remove eyepiece cap	-
		XF27mmF2.8	√	No need to remove eyepiece cap	-
		XF 35mm f/1.4 R	√	No need to remove eyepiece cap	-
		XF 35mm f/2 R WR	√	No need to remove eyepiece cap	-
		XF56mmF1.2 R	√	No need to remove eyepiece cap	-
		XF60mmF2.4 R Macro	√	No need to remove eyepiece cap	-
		XC 15-45mm f/3.5-5.6 OIS	√	Can be balanced at any focal length, no need to remove eyepiece cap	Should be powered on to balance
		XF 18-55mm f/2.8-4 R OIS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
Panasonic	DC-G100	LEICA DG SUMMILUX 15mm f/1.7 ASPH	√	No need to remove eyepiece cap	-
		Lumix G 25mm f/1.4	√	No need to remove eyepiece cap	-
		Lumix G 25mm f/1.7	√	No need to remove eyepiece cap	-
		LUMIX G MACRO 30mm f/2.8 ASPH MEGA OIS	√	No need to remove eyepiece cap	-
		LEICA DG Vario-Elmarit 8-18mm f/2.8-4.0 ASPH	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		12-32 0.2m/0.66ft	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		Lumix G X Vario 12-35mm f/2.8 II ASPH POWER OIS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-



Camera Brand	Model	Lens Model	Balance Adjustment	Installation Remark	Note
Panasonic	DMC-GH4	LEICA DG SUMMILUX 15mm f/1.7 ASPH	√	No need to remove eyepiece cap	-
		Lumix G 25mm f/1.4	√	No need to remove eyepiece cap	-
		Lumix G 25mm f/1.7	√	No need to remove eyepiece cap	-
		LUMIX G MACRO 30mm f/2.8 ASPH MEGA OIS	√	No need to remove eyepiece cap	-
		12-32 0.2m/0.66ft	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	DMC-GH5	Lumix G 25mm f/1.7	√	No need to remove eyepiece cap	-
	DMC-GH5S	Lumix G 25mm f/1.7	√	No need to remove eyepiece cap	-
SIGMA	fp	45mm F2.8	√	-	-