

# CRANE-M 3S Camera Compatibility List



Update on November 29, 2023 (Firmware version V1.72)

V1.40

| Camera Brand              | Model                                | Lens Model                            | Mounting Status                       | Balance Adjustment |          | Camera Backing Base |  | Servo Zoom/<br>Focus Motor     | Installation Remark   |
|---------------------------|--------------------------------------|---------------------------------------|---------------------------------------|--------------------|----------|---------------------|--|--------------------------------|---|
|                           |                                      |                                       |                                       | Horizontal         | Vertical | Horizontal          | Vertical   |                                |   |
| Sony                      | α7M2                                 | FE 20mm F1.8 G                        | Standard quick release plate provided | √                  | -        | -                   | -  | -                              | No need to remove eyepiece cap                                      |
|                           |                                      | FE 24mm F2.8 G                        |                                       | √                  | -        | -                   | -  | -                              | No need to remove eyepiece cap                                      |
|                           |                                      | FE 24mm F1.4 GM                       |                                       | √                  | -        | -                   | -  | -                              | Need to remove eyepiece cap   |
|                           |                                      | FE 28mm F2                            |                                       | √                  | -        | -                   | -  | -                              | No need to remove eyepiece cap                                      |
|                           |                                      | FE 35mm F1.8                          |                                       | √                  | -        | -                   | -  | -                              | Need to remove eyepiece cap   |
|                           |                                      | Sonnar T* FE 35mm F2.8 ZA             |                                       | √                  | -        | -                   | -  | -                              | No need to remove eyepiece cap                                      |
|                           |                                      | FE 40mm F2.5 G                        |                                       | √                  | -        | -                   | -  | -                              | No need to remove eyepiece cap                                      |
|                           |                                      | Sigma 45mm f/2.8 DG DN                |                                       | √                  | -        | -                   | -  | -                              | No need to remove eyepiece cap                                      |
|                           |                                      | FE 50mm F1.8                          |                                       | √                  | -        | -                   | -  | -                              | No need to remove eyepiece cap                                      |
|                           |                                      | FE 50mm F2.5 G                        |                                       | √                  | -        | -                   | -  | -                              | No need to remove eyepiece cap                                      |
|                           |                                      | Sonnar T* FE 55mm F1.8 ZA             |                                       | √                  | -        | -                   | -  | -                              | No need to remove eyepiece cap                                      |
|                           |                                      | FE PZ 16-35mm F4 G                    |                                       | √                  | -        | -                   | -  | -                              | Can be balanced at any focal length, no need to remove eyepiece cap |
|                           |                                      | FE 28-60mm F4-5.6                     |                                       | √                  | -        | -                   | -  | -                              | Can be balanced at any focal length, no need to remove eyepiece cap |
|                           |                                      | FE 28-70mm F3.5-5.6 OSS               |                                       | √                  | -        | -                   | -  | -                              | Can be balanced at any focal length, no need to remove eyepiece cap |
|                           | Vario-Tessar T* E 16-70mm F4 ZA OSS  | √                                     | -                                     | -                  | -        | -                   | Can be balanced at any focal length, need to remove eyepiece cap |                                |   |
|                           | Vario-Tessar T* FE 24-70mm F4 ZA OSS | √                                     | -                                     | -                  | -        | -                   | Can be balanced at 24-50mm, need to remove eyepiece cap          |                                |   |
|                           | α7R2                                 | Standard quick release plate provided | FE 20mm F1.8 G                        | √                  | -        | -                   | -  | -                              | No need to remove eyepiece cap                                      |
|                           |                                      |                                       | FE 24mm F2.8 G                        | √                  | -        | -                   | -  | -                              | No need to remove eyepiece cap                                      |
|                           |                                      |                                       | FE 24mm F1.4 GM                       | √                  | -        | -                   | -  | -                              | Need to remove eyepiece cap   |
|                           |                                      |                                       | FE 28mm F2                            | √                  | -        | -                   | -  | -                              | No need to remove eyepiece cap                                      |
| FE 35mm F1.8              |                                      |                                       | √                                     | -                  | -        | -                   | -  | Need to remove eyepiece cap    |   |
| Sonnar T* FE 35mm F2.8 ZA |                                      |                                       | √                                     | -                  | -        | -                   | -  | No need to remove eyepiece cap |   |



| Camera Brand                        | Model | Lens Model                           | Mounting Status                       | Balance Adjustment |          | Camera Backing Base  |          | Servo Zoom/<br>Focus Motor  | Installation Remark   |
|-------------------------------------|-------|--------------------------------------|---------------------------------------|--------------------|----------|--|----------|---|---|
|                                     |       |                                      |                                       | Horizontal         | Vertical | Horizontal   | Vertical |   |   |
| Sony                                | α7R2  | FE 40mm F2.5 G                       | Standard quick release plate provided | √                  | -        | -  | -        | -   | No need to remove eyepiece cap                                      |
|                                     |       | Sigma 45mm f/2.8 DG DN               |                                       | √                  | -        | -  | -        | -   | No need to remove eyepiece cap                                      |
|                                     |       | FE 50mm F1.8                         |                                       | √                  | -        | -  | -        | -   | No need to remove eyepiece cap                                      |
|                                     |       | FE 50mm F2.5 G                       |                                       | √                  | -        | -  | -        | -   | No need to remove eyepiece cap                                      |
|                                     |       | Sonnar T* FE 55mm F1.8 ZA            |                                       | √                  | -        | -  | -        | -   | No need to remove eyepiece cap                                      |
|                                     |       | FE PZ 16-35mm F4 G                   |                                       | √                  | -        | -  | -        | -   | Can be balanced at any focal length, no need to remove eyepiece cap |
|                                     |       | FE 28-60mm F4-5.6                    |                                       | √                  | -        | -  | -        | -   | Can be balanced at any focal length, no need to remove eyepiece cap |
|                                     |       | FE 28-70mm F3.5-5.6 OSS              |                                       | √                  | -        | -  | -        | -   | Can be balanced at any focal length, no need to remove eyepiece cap |
|                                     |       | Vario-Tessar T* E 16-70mm F4 ZA OSS  |                                       | √                  | -        | -  | -        | -   | Can be balanced at any focal length, need to remove eyepiece cap    |
|                                     |       | Vario-Tessar T* FE 24-70mm F4 ZA OSS |                                       | √                  | -        | -  | -        | -   | Can be balanced at 24-50mm, need to remove eyepiece cap             |
|                                     | α7S2  | FE 20mm F1.8 G                       | Standard quick release plate provided | √                  | -        | -  | -        | -   | No need to remove eyepiece cap                                      |
|                                     |       | FE 24mm F2.8 G                       |                                       | √                  | -        | -  | -        | -   | No need to remove eyepiece cap                                      |
|                                     |       | FE 24mm F1.4 GM                      |                                       | √                  | -        | -  | -        | -   | Need to remove eyepiece cap   |
|                                     |       | FE 28mm F2                           |                                       | √                  | -        | -  | -        | -   | No need to remove eyepiece cap                                      |
|                                     |       | FE 35mm F1.8                         |                                       | √                  | -        | -  | -        | -   | Need to remove eyepiece cap   |
|                                     |       | Sonnar T* FE 35mm F2.8 ZA            |                                       | √                  | -        | -  | -        | -   | No need to remove eyepiece cap                                      |
|                                     |       | FE 40mm F2.5 G                       |                                       | √                  | -        | -  | -        | -   | No need to remove eyepiece cap                                      |
|                                     |       | Sigma 45mm f/2.8 DG DN               |                                       | √                  | -        | -  | -        | -   | No need to remove eyepiece cap                                      |
|                                     |       | FE 50mm F1.8                         |                                       | √                  | -        | -  | -        | -   | No need to remove eyepiece cap                                      |
|                                     |       | FE 50mm F2.5 G                       |                                       | √                  | -        | -  | -        | -   | No need to remove eyepiece cap                                      |
| Sonnar T* FE 55mm F1.8 ZA           |       | √                                    |                                       | -                  | -        | -  | -        | No need to remove eyepiece cap                                      |   |
| FE PZ 16-35mm F4 G                  |       | √                                    |                                       | -                  | -        | -  | -        | Can be balanced at any focal length, no need to remove eyepiece cap |   |
| FE 28-60mm F4-5.6                   |       | √                                    |                                       | -                  | -        | -  | -        | Can be balanced at any focal length, no need to remove eyepiece cap |   |
| FE 28-70mm F3.5-5.6 OSS             |       | √                                    |                                       | -                  | -        | -  | -        | Can be balanced at any focal length, no need to remove eyepiece cap |   |
| Vario-Tessar T* E 16-70mm F4 ZA OSS | √     | -                                    | -                                     | -                  | -        | Can be balanced at any focal length, need to remove eyepiece cap |          |   |   |



| Camera Brand              | Model                                | Lens Model                           | Mounting Status                       | Balance Adjustment |          | Camera Backing Base |   | Servo Zoom/<br>Focus Motor     | Installation Remark   |
|---------------------------|--------------------------------------|--------------------------------------|---------------------------------------|--------------------|----------|---------------------|---|--------------------------------|---|
|                           |                                      |                                      |                                       | Horizontal         | Vertical | Horizontal          | Vertical  |                                |   |
| Sony                      | α7S2                                 | Vario-Tessar T* FE 24-70mm F4 ZA OSS | Standard quick release plate provided | √                  | -        | -                   | -   | -                              | Can be balanced at 24-50mm, need to remove eyepiece cap             |
|                           | α7M3                                 | FE 20mm F1.8 G                       | Standard quick release plate provided | √                  | -        | -                   | -   | -                              | No need to remove eyepiece cap                                      |
|                           |                                      | FE 24mm F2.8 G                       |                                       | √                  | -        | -                   | -   | -                              | No need to remove eyepiece cap                                      |
|                           |                                      | FE 24mm F1.4 GM                      |                                       | √                  | -        | -                   | -   | -                              | Need to remove eyepiece cap   |
|                           |                                      | FE 28mm F2                           |                                       | √                  | -        | -                   | -   | -                              | No need to remove eyepiece cap                                      |
|                           |                                      | FE 35mm F1.8                         |                                       | √                  | -        | -                   | -   | -                              | Need to remove eyepiece cap   |
|                           |                                      | Sonnar T* FE 35mm F2.8 ZA            |                                       | √                  | -        | -                   | -   | -                              | No need to remove eyepiece cap                                      |
|                           |                                      | FE 40mm F2.5 G                       |                                       | √                  | -        | -                   | -   | -                              | No need to remove eyepiece cap                                      |
|                           |                                      | Sigma 45mm f/2.8 DG DN               |                                       | √                  | -        | -                   | -   | -                              | No need to remove eyepiece cap                                      |
|                           |                                      | FE 50mm F1.8                         |                                       | √                  | -        | -                   | -   | -                              | No need to remove eyepiece cap                                      |
|                           |                                      | FE 50mm F2.5 G                       |                                       | √                  | -        | -                   | -   | -                              | No need to remove eyepiece cap                                      |
|                           |                                      | Sonnar T* FE 55mm F1.8 ZA            |                                       | √                  | -        | -                   | -   | -                              | No need to remove eyepiece cap                                      |
|                           |                                      | FE PZ 16-35mm F4 G                   |                                       | √                  | -        | -                   | -   | -                              | Can be balanced at any focal length, no need to remove eyepiece cap |
|                           |                                      | FE 28-60mm F4-5.6                    |                                       | √                  | -        | -                   | -   | -                              | Can be balanced at any focal length, no need to remove eyepiece cap |
|                           |                                      | FE 28-70mm F3.5-5.6 OSS              |                                       | √                  | -        | -                   | -   | -                              | Can be balanced at any focal length, no need to remove eyepiece cap |
|                           |                                      | Vario-Tessar T* E 16-70mm F4 ZA OSS  |                                       | √                  | -        | -                   | -   | -                              | Can be balanced at any focal length, need to remove eyepiece cap    |
|                           | Vario-Tessar T* FE 24-70mm F4 ZA OSS | √                                    | -                                     | -                  | -        | -                   | Can be balanced at 24-50mm, need to remove eyepiece cap |                                |   |
|                           | α7M4                                 | FE 20mm F1.8 G                       | Standard quick release plate provided | √                  | -        | -                   | -   | -                              | No need to remove eyepiece cap                                      |
|                           |                                      | FE 24mm F2.8 G                       |                                       | √                  | -        | -                   | -   | -                              | No need to remove eyepiece cap                                      |
|                           |                                      | FE 24mm F1.4 GM                      |                                       | √                  | -        | -                   | -   | -                              | Need to remove eyepiece cap   |
| FE 28mm F2                |                                      | √                                    |                                       | -                  | -        | -                   | -   | No need to remove eyepiece cap |   |
| FE 35mm F1.8              |                                      | √                                    |                                       | -                  | -        | -                   | -   | Need to remove eyepiece cap    |   |
| Sonnar T* FE 35mm F2.8 ZA |                                      | √                                    |                                       | -                  | -        | -                   | -   | No need to remove eyepiece cap |   |



| Camera Brand | Model | Lens Model                           | Mounting Status                       | Balance Adjustment |          | Camera Backing Base |          | Servo Zoom/<br>Focus Motor | Installation Remark   |
|--------------|-------|--------------------------------------|---------------------------------------|--------------------|----------|---------------------|----------|----------------------------|---|
|              |       |                                      |                                       | Horizontal         | Vertical | Horizontal          | Vertical |                            |   |
| Sony         | α7M4  | FE 40mm F2.5 G                       | Standard quick release plate provided | √                  | -        | -                   | -        | -                          | No need to remove eyepiece cap                                      |
|              |       | Sigma 45mm f/2.8 DG DN               |                                       | √                  | -        | -                   | -        | -                          | No need to remove eyepiece cap                                      |
|              |       | FE 50mm F1.8                         |                                       | √                  | -        | -                   | -        | -                          | No need to remove eyepiece cap                                      |
|              |       | FE 50mm F2.5 G                       |                                       | √                  | -        | -                   | -        | -                          | No need to remove eyepiece cap                                      |
|              |       | Sonnar T* FE 55mm F1.8 ZA            |                                       | √                  | -        | -                   | -        | -                          | No need to remove eyepiece cap                                      |
|              |       | FE PZ 16-35mm F4 G                   |                                       | √                  | -        | -                   | -        | -                          | Can be balanced at any focal length, no need to remove eyepiece cap |
|              |       | FE 28-60mm F4-5.6                    |                                       | √                  | -        | -                   | -        | -                          | Can be balanced at any focal length, no need to remove eyepiece cap |
|              |       | FE 28-70mm F3.5-5.6 OSS              |                                       | √                  | -        | -                   | -        | -                          | Can be balanced at any focal length, no need to remove eyepiece cap |
|              |       | Vario-Tessar T* E 16-70mm F4 ZA OSS  |                                       | √                  | -        | -                   | -        | -                          | Can be balanced at any focal length, need to remove eyepiece cap    |
|              |       | Vario-Tessar T* FE 24-70mm F4 ZA OSS |                                       | √                  | -        | -                   | -        | -                          | Can be balanced at 24-50mm, need to remove eyepiece cap             |
|              | α7R3  | FE 20mm F1.8 G                       | Standard quick release plate provided | √                  | -        | -                   | -        | -                          | No need to remove eyepiece cap                                      |
|              |       | FE 24mm F2.8 G                       |                                       | √                  | -        | -                   | -        | -                          | No need to remove eyepiece cap                                      |
|              |       | FE 24mm F1.4 GM                      |                                       | √                  | -        | -                   | -        | -                          | Need to remove eyepiece cap   |
|              |       | FE 28mm F2                           |                                       | √                  | -        | -                   | -        | -                          | No need to remove eyepiece cap                                      |
|              |       | FE 35mm F1.8                         |                                       | √                  | -        | -                   | -        | -                          | Need to remove eyepiece cap   |
|              |       | Sonnar T* FE 35mm F2.8 ZA            |                                       | √                  | -        | -                   | -        | -                          | No need to remove eyepiece cap                                      |
|              |       | FE 40mm F2.5 G                       |                                       | √                  | -        | -                   | -        | -                          | No need to remove eyepiece cap                                      |
|              |       | Sigma 45mm f/2.8 DG DN               |                                       | √                  | -        | -                   | -        | -                          | No need to remove eyepiece cap                                      |
|              |       | FE 50mm F1.8                         |                                       | √                  | -        | -                   | -        | -                          | No need to remove eyepiece cap                                      |
|              |       | FE 50mm F2.5 G                       |                                       | √                  | -        | -                   | -        | -                          | No need to remove eyepiece cap                                      |
|              |       | Sonnar T* FE 55mm F1.8 ZA            |                                       | √                  | -        | -                   | -        | -                          | No need to remove eyepiece cap                                      |
|              |       | FE PZ 16-35mm F4 G                   |                                       | √                  | -        | -                   | -        | -                          | Can be balanced at any focal length, no need to remove eyepiece cap |
|              |       | FE 28-60mm F4-5.6                    |                                       | √                  | -        | -                   | -        | -                          | Can be balanced at any focal length, no need to remove eyepiece cap |
|              |       | FE 28-70mm F3.5-5.6 OSS              |                                       | √                  | -        | -                   | -        | -                          | Can be balanced at any focal length, no need to remove eyepiece cap |
|              |       | Vario-Tessar T* E 16-70mm F4 ZA OSS  |                                       | √                  | -        | -                   | -        | -                          | Can be balanced at any focal length, need to remove eyepiece cap    |
|              |       | Vario-Tessar T* FE 24-70mm F4 ZA OSS |                                       | √                  | -        | -                   | -        | -                          | Can be balanced at 24-50mm, need to remove eyepiece cap             |



| Camera Brand              | Model                                | Lens Model                            | Mounting Status                       | Balance Adjustment |          | Camera Backing Base |  | Servo Zoom/<br>Focus Motor     | Installation Remark   |
|---------------------------|--------------------------------------|---------------------------------------|---------------------------------------|--------------------|----------|---------------------|--|--------------------------------|---|
|                           |                                      |                                       |                                       | Horizontal         | Vertical | Horizontal          | Vertical   |                                |   |
| Sony                      | α7S3                                 | FE 20mm F1.8 G                        | Standard quick release plate provided | √                  | -        | -                   | -  | -                              | No need to remove eyepiece cap                                      |
|                           |                                      | FE 24mm F2.8 G                        |                                       | √                  | -        | -                   | -  | -                              | No need to remove eyepiece cap                                      |
|                           |                                      | FE 24mm F1.4 GM                       |                                       | √                  | -        | -                   | -  | -                              | Need to remove eyepiece cap   |
|                           |                                      | FE 28mm F2                            |                                       | √                  | -        | -                   | -  | -                              | No need to remove eyepiece cap                                      |
|                           |                                      | FE 35mm F1.8                          |                                       | √                  | -        | -                   | -  | -                              | Need to remove eyepiece cap   |
|                           |                                      | Sonnar T* FE 35mm F2.8 ZA             |                                       | √                  | -        | -                   | -  | -                              | No need to remove eyepiece cap                                      |
|                           |                                      | FE 40mm F2.5 G                        |                                       | √                  | -        | -                   | -  | -                              | No need to remove eyepiece cap                                      |
|                           |                                      | Sigma 45mm f/2.8 DG DN                |                                       | √                  | -        | -                   | -  | -                              | No need to remove eyepiece cap                                      |
|                           |                                      | FE 50mm F1.8                          |                                       | √                  | -        | -                   | -  | -                              | No need to remove eyepiece cap                                      |
|                           |                                      | FE 50mm F2.5 G                        |                                       | √                  | -        | -                   | -  | -                              | No need to remove eyepiece cap                                      |
|                           |                                      | Sonnar T* FE 55mm F1.8 ZA             |                                       | √                  | -        | -                   | -  | -                              | No need to remove eyepiece cap                                      |
|                           |                                      | FE PZ 16-35mm F4 G                    |                                       | √                  | -        | -                   | -  | -                              | Can be balanced at any focal length, no need to remove eyepiece cap |
|                           |                                      | FE 28-60mm F4-5.6                     |                                       | √                  | -        | -                   | -  | -                              | Can be balanced at any focal length, no need to remove eyepiece cap |
|                           |                                      | FE 28-70mm F3.5-5.6 OSS               |                                       | √                  | -        | -                   | -  | -                              | Can be balanced at any focal length, no need to remove eyepiece cap |
|                           | Vario-Tessar T* E 16-70mm F4 ZA OSS  | √                                     | -                                     | -                  | -        | -                   | Can be balanced at any focal length, need to remove eyepiece cap |                                |   |
|                           | Vario-Tessar T* FE 24-70mm F4 ZA OSS | √                                     | -                                     | -                  | -        | -                   | Can be balanced at 24-50mm, need to remove eyepiece cap          |                                |   |
|                           | α7R4                                 | Standard quick release plate provided | FE 20mm F1.8 G                        | √                  | -        | -                   | -  | -                              | No need to remove eyepiece cap                                      |
|                           |                                      |                                       | FE 24mm F2.8 G                        | √                  | -        | -                   | -  | -                              | No need to remove eyepiece cap                                      |
|                           |                                      |                                       | FE 24mm F1.4 GM                       | √                  | -        | -                   | -  | -                              | Need to remove eyepiece cap   |
|                           |                                      |                                       | FE 28mm F2                            | √                  | -        | -                   | -  | -                              | No need to remove eyepiece cap                                      |
| FE 35mm F1.8              |                                      |                                       | √                                     | -                  | -        | -                   | -  | Need to remove eyepiece cap    |   |
| Sonnar T* FE 35mm F2.8 ZA |                                      |                                       | √                                     | -                  | -        | -                   | -  | No need to remove eyepiece cap |   |
| FE 40mm F2.5 G            |                                      |                                       | √                                     | -                  | -        | -                   | -  | No need to remove eyepiece cap |   |
| Sigma 45mm f/2.8 DG DN    |                                      |                                       | √                                     | -                  | -        | -                   | -  | No need to remove eyepiece cap |   |



| Camera Brand                         | Model | Lens Model                           | Mounting Status                       | Balance Adjustment |          | Camera Backing Base   |          | Servo Zoom/<br>Focus Motor | Installation Remark   |
|--------------------------------------|-------|--------------------------------------|---------------------------------------|--------------------|----------|---|----------|----------------------------|---|
|                                      |       |                                      |                                       | Horizontal         | Vertical | Horizontal  | Vertical |                            |   |
| Sony                                 | α7R4  | FE 50mm F1.8                         | Standard quick release plate provided | √                  | -        | -   | -        | -                          | No need to remove eyepiece cap                                      |
|                                      |       | FE 50mm F2.5 G                       |                                       | √                  | -        | -   | -        | -                          | No need to remove eyepiece cap                                      |
|                                      |       | Sonnar T* FE 55mm F1.8 ZA            |                                       | √                  | -        | -   | -        | -                          | No need to remove eyepiece cap                                      |
|                                      |       | FE PZ 16-35mm F4 G                   |                                       | √                  | -        | -   | -        | -                          | Can be balanced at any focal length, no need to remove eyepiece cap |
|                                      |       | FE 28-60mm F4-5.6                    |                                       | √                  | -        | -   | -        | -                          | Can be balanced at any focal length, no need to remove eyepiece cap |
|                                      |       | FE 28-70mm F3.5-5.6 OSS              |                                       | √                  | -        | -   | -        | -                          | Can be balanced at any focal length, no need to remove eyepiece cap |
|                                      |       | Vario-Tessar T* E 16-70mm F4 ZA OSS  |                                       | √                  | -        | -   | -        | -                          | Can be balanced at any focal length, need to remove eyepiece cap    |
|                                      |       | Vario-Tessar T* FE 24-70mm F4 ZA OSS |                                       | √                  | -        | -   | -        | -                          | Can be balanced at 24-50mm, need to remove eyepiece cap             |
|                                      | α7R5  | FE 20mm F1.8 G                       | Standard quick release plate provided | √                  | -        | -   | -        | -                          | No need to remove eyepiece cap                                      |
|                                      |       | FE 24mm F2.8 G                       |                                       | √                  | -        | -   | -        | -                          | No need to remove eyepiece cap                                      |
|                                      |       | FE 24mm F1.4 GM                      |                                       | √                  | -        | -   | -        | -                          | Need to remove eyepiece cap   |
|                                      |       | FE 28mm F2                           |                                       | √                  | -        | -   | -        | -                          | No need to remove eyepiece cap                                      |
|                                      |       | FE 35mm F1.8                         |                                       | √                  | -        | -   | -        | -                          | Need to remove eyepiece cap   |
|                                      |       | Sonnar T* FE 35mm F2.8 ZA            |                                       | √                  | -        | -   | -        | -                          | No need to remove eyepiece cap                                      |
|                                      |       | FE 40mm F2.5 G                       |                                       | √                  | -        | -   | -        | -                          | No need to remove eyepiece cap                                      |
|                                      |       | Sigma 45mm f/2.8 DG DN               |                                       | √                  | -        | -   | -        | -                          | No need to remove eyepiece cap                                      |
|                                      |       | FE 50mm F1.8                         |                                       | √                  | -        | -   | -        | -                          | No need to remove eyepiece cap                                      |
|                                      |       | FE 50mm F2.5 G                       |                                       | √                  | -        | -   | -        | -                          | No need to remove eyepiece cap                                      |
|                                      |       | Sonnar T* FE 55mm F1.8 ZA            |                                       | √                  | -        | -   | -        | -                          | No need to remove eyepiece cap                                      |
|                                      |       | FE PZ 16-35mm F4 G                   |                                       | √                  | -        | -   | -        | -                          | Can be balanced at any focal length, no need to remove eyepiece cap |
| FE 28-60mm F4-5.6                    | √     | -                                    | -                                     | -                  | -        | Can be balanced at any focal length, no need to remove eyepiece cap |          |                            |   |
| FE 28-70mm F3.5-5.6 OSS              | √     | -                                    | -                                     | -                  | -        | Can be balanced at any focal length, no need to remove eyepiece cap |          |                            |   |
| Vario-Tessar T* E 16-70mm F4 ZA OSS  | √     | -                                    | -                                     | -                  | -        | Can be balanced at any focal length, need to remove eyepiece cap    |          |                            |   |
| Vario-Tessar T* FE 24-70mm F4 ZA OSS | √     | -                                    | -                                     | -                  | -        | Can be balanced at 24-50mm, need to remove eyepiece cap             |          |                            |   |



| Camera Brand              | Model                                | Lens Model                               | Mounting Status                          | Balance Adjustment |          | Camera Backing Base |  | Servo Zoom/<br>Focus Motor     | Installation Remark   |
|---------------------------|--------------------------------------|--|--|--------------------|----------|---------------------|--|--------------------------------|---|
|                           |                                      |  |  | Horizontal         | Vertical | Horizontal          | Vertical   |                                |   |
| Sony                      | FX3,<br>FX30                         | FE 20mm F1.8 G                           | Standard quick release<br>plate provided | √                  | -        | -                   | -  | -                              | No need to remove eyepiece cap                                      |
|                           |                                      | FE 24mm F2.8 G                           |  | √                  | -        | -                   | -  | -                              | No need to remove eyepiece cap                                      |
|                           |                                      | FE 24mm F1.4 GM                          |  | √                  | -        | -                   | -  | -                              | Need to remove eyepiece cap   |
|                           |                                      | FE 28mm F2                               |  | √                  | -        | -                   | -  | -                              | No need to remove eyepiece cap                                      |
|                           |                                      | FE 35mm F1.8                             |  | √                  | -        | -                   | -  | -                              | Need to remove eyepiece cap   |
|                           |                                      | Sonnar T* FE 35mm F2.8 ZA                |  | √                  | -        | -                   | -  | -                              | No need to remove eyepiece cap                                      |
|                           |                                      | FE 40mm F2.5 G                           |  | √                  | -        | -                   | -  | -                              | No need to remove eyepiece cap                                      |
|                           |                                      | Sigma 45mm f/2.8 DG DN                   |  | √                  | -        | -                   | -  | -                              | No need to remove eyepiece cap                                      |
|                           |                                      | FE 50mm F1.8                             |  | √                  | -        | -                   | -  | -                              | No need to remove eyepiece cap                                      |
|                           |                                      | FE 50mm F2.5 G                           |  | √                  | -        | -                   | -  | -                              | No need to remove eyepiece cap                                      |
|                           |                                      | Sonnar T* FE 55mm F1.8 ZA                |  | √                  | -        | -                   | -  | -                              | No need to remove eyepiece cap                                      |
|                           |                                      | FE PZ 16-35mm F4 G                       |  | √                  | -        | -                   | -  | -                              | Can be balanced at any focal length, no need to remove eyepiece cap |
|                           |                                      | FE 28-60mm F4-5.6                        |  | √                  | -        | -                   | -  | -                              | Can be balanced at any focal length, no need to remove eyepiece cap |
|                           |                                      | FE 28-70mm F3.5-5.6 OSS                  |  | √                  | -        | -                   | -  | -                              | Can be balanced at any focal length, no need to remove eyepiece cap |
|                           | Vario-Tessar T* E 16-70mm F4 ZA OSS  | √  | -  | -                  | -        | -                   | Can be balanced at any focal length, need to remove eyepiece cap |                                |   |
|                           | Vario-Tessar T* FE 24-70mm F4 ZA OSS | √  | -  | -                  | -        | -                   | Can be balanced at 24-50mm, need to remove eyepiece cap          |                                |   |
|                           | a7C                                  | Standard quick release<br>plate provided | FE 20mm F1.8 G                           | √                  | -        | -                   | -  | -                              | No need to remove eyepiece cap                                      |
|                           |                                      |  | FE 24mm F2.8 G                           | √                  | -        | -                   | -  | -                              | No need to remove eyepiece cap                                      |
|                           |                                      |  | FE 24mm F1.4 GM                          | √                  | -        | -                   | -  | -                              | Need to remove eyepiece cap   |
|                           |                                      |  | FE 28mm F2                               | √                  | -        | -                   | -  | -                              | No need to remove eyepiece cap                                      |
| FE 35mm F1.8              |                                      |  | √  | -                  | -        | -                   | -  | No need to remove eyepiece cap |   |
| Sonnar T* FE 35mm F2.8 ZA |                                      |  | √  | -                  | -        | -                   | -  | No need to remove eyepiece cap |   |
| FE 40mm F2.5 G            |                                      |  | √  | -                  | -        | -                   | -  | No need to remove eyepiece cap |   |
| Sigma 45mm f/2.8 DG DN    |                                      |  | √  | -                  | -        | -                   | -  | No need to remove eyepiece cap |   |



| Camera Brand               | Model                                | Lens Model                          | Mounting Status                       | Balance Adjustment |          | Camera Backing Base |   | Servo Zoom/<br>Focus Motor  | Installation Remark   |
|----------------------------|--------------------------------------|-------------------------------------|---------------------------------------|--------------------|----------|---------------------|---|---|---|
|                            |                                      |                                     |                                       | Horizontal         | Vertical | Horizontal          | Vertical  |   |   |
| Sony                       | α7C                                  | FE 50mm F1.8                        | Standard quick release plate provided | √                  | -        | -                   | -   | -   | No need to remove eyepiece cap                                      |
|                            |                                      | FE 50mm F2.5 G                      |                                       | √                  | -        | -                   | -   | -   | No need to remove eyepiece cap                                      |
|                            |                                      | FE 50mm F2.8                        |                                       | √                  | -        | -                   | -   | -   | No need to remove eyepiece cap                                      |
|                            |                                      | Sonnar® T* FE 55mm F1.8 ZA          |                                       | √                  | -        | -                   | -   | -   | No need to remove eyepiece cap                                      |
|                            |                                      | E 10-18mm F4 OSS                    |                                       | √                  | -        | -                   | -   | -   | Can be balanced at any focal length, no need to remove eyepiece cap |
|                            |                                      | E PZ 18-105mm F4 G OSS              |                                       | √                  | -        | -                   | -   | -   | Can be balanced at any focal length, no need to remove eyepiece cap |
|                            |                                      | FE PZ 16-35mm F4 G                  |                                       | √                  | -        | -                   | -   | -   | Can be balanced at any focal length, no need to remove eyepiece cap |
|                            |                                      | FE 28-60mm F4-5.6                   |                                       | √                  | -        | -                   | -   | -   | Can be balanced at any focal length, no need to remove eyepiece cap |
|                            |                                      | FE 28-70mm F3.5-5.6 OSS             |                                       | √                  | -        | -                   | -   | -   | Can be balanced at any focal length, no need to remove eyepiece cap |
|                            |                                      | Vario-Tessar T* E 16-70mm F4 ZA OSS |                                       | √                  | -        | -                   | -   | -   | Can be balanced at any focal length, need to remove eyepiece cap    |
|                            | Vario-Tessar T* FE 24-70mm F4 ZA OSS | √                                   | -                                     | -                  | -        | -                   | Can be balanced at 24-50mm, need to remove eyepiece cap |   |   |
|                            | ZV-E1                                | FE 20mm F1.8 G                      | Standard quick release plate provided | √                  | -        | -                   | -   | -   | No need to remove eyepiece cap                                      |
|                            |                                      | FE 24mm F2.8 G                      |                                       | √                  | -        | -                   | -   | -   | No need to remove eyepiece cap                                      |
|                            |                                      | FE 24mm F1.4 GM                     |                                       | √                  | -        | -                   | -   | -   | Need to remove eyepiece cap   |
|                            |                                      | FE 28mm F2                          |                                       | √                  | -        | -                   | -   | -   | No need to remove eyepiece cap                                      |
|                            |                                      | FE 35mm F1.8                        |                                       | √                  | -        | -                   | -   | -   | No need to remove eyepiece cap                                      |
|                            |                                      | Sonnar T* FE 35mm F2.8 ZA           |                                       | √                  | -        | -                   | -   | -   | No need to remove eyepiece cap                                      |
|                            |                                      | FE 40mm F2.5 G                      |                                       | √                  | -        | -                   | -   | -   | No need to remove eyepiece cap                                      |
|                            |                                      | Sigma 45mm f/2.8 DG DN              |                                       | √                  | -        | -                   | -   | -   | No need to remove eyepiece cap                                      |
|                            |                                      | FE 50mm F1.8                        |                                       | √                  | -        | -                   | -   | -   | No need to remove eyepiece cap                                      |
| FE 50mm F2.5 G             |                                      | √                                   |                                       | -                  | -        | -                   | -   | No need to remove eyepiece cap                                      |   |
| FE 50mm F2.8               |                                      | √                                   |                                       | -                  | -        | -                   | -   | No need to remove eyepiece cap                                      |   |
| Sonnar® T* FE 55mm F1.8 ZA |                                      | √                                   |                                       | -                  | -        | -                   | -   | No need to remove eyepiece cap                                      |   |
| E 10-18mm F4 OSS           |                                      | √                                   |                                       | -                  | -        | -                   | -   | Can be balanced at any focal length, no need to remove eyepiece cap |   |
| E PZ 18-105mm F4 G OSS     |                                      | √                                   |                                       | -                  | -        | -                   | -   | Can be balanced at any focal length, no need to remove eyepiece cap |   |





| Camera Brand                         | Model  | Lens Model                           | Mounting Status                       | Balance Adjustment |          | Camera Backing Base   |          | Servo Zoom/<br>Focus Motor | Installation Remark   |
|--------------------------------------|--------|--------------------------------------|---------------------------------------|--------------------|----------|---|----------|----------------------------|---|
|                                      |        |                                      |                                       | Horizontal         | Vertical | Horizontal  | Vertical |                            |   |
| Sony                                 | ZV-E1  | FE PZ 16-35mm F4 G                   | Standard quick release plate provided | √                  | -        | -   | -        | -                          | Can be balanced at any focal length, no need to remove eyepiece cap |
|                                      |        | FE 28-60mm F4-5.6                    |                                       | √                  | -        | -   | -        | -                          | Can be balanced at any focal length, no need to remove eyepiece cap |
|                                      |        | FE 28-70mm F3.5-5.6 OSS              |                                       | √                  | -        | -   | -        | -                          | Can be balanced at any focal length, no need to remove eyepiece cap |
|                                      |        | Vario-Tessar T* E 16-70mm F4 ZA OSS  |                                       | √                  | -        | -   | -        | -                          | Can be balanced at any focal length, need to remove eyepiece cap    |
|                                      |        | Vario-Tessar T* FE 24-70mm F4 ZA OSS |                                       | √                  | -        | -   | -        | -                          | Can be balanced at 24-50mm, need to remove eyepiece cap             |
|                                      | α7C II | FE 20mm F1.8 G                       | Standard quick release plate provided | √                  | -        | -   | -        | -                          | No need to remove eyepiece cap                                      |
|                                      |        | FE 24mm F2.8 G                       |                                       | √                  | -        | -   | -        | -                          | No need to remove eyepiece cap                                      |
|                                      |        | FE 24mm F1.4 GM                      |                                       | √                  | -        | -   | -        | -                          | Need to remove eyepiece cap   |
|                                      |        | FE 28mm F2                           |                                       | √                  | -        | -   | -        | -                          | No need to remove eyepiece cap                                      |
|                                      |        | FE 35mm F1.8                         |                                       | √                  | -        | -   | -        | -                          | No need to remove eyepiece cap                                      |
|                                      |        | Sonnar T* FE 35mm F2.8 ZA            |                                       | √                  | -        | -   | -        | -                          | No need to remove eyepiece cap                                      |
|                                      |        | FE 40mm F2.5 G                       |                                       | √                  | -        | -   | -        | -                          | No need to remove eyepiece cap                                      |
|                                      |        | Sigma 45mm f/2.8 DG DN               |                                       | √                  | -        | -   | -        | -                          | No need to remove eyepiece cap                                      |
|                                      |        | FE 50mm F1.8                         |                                       | √                  | -        | -   | -        | -                          | No need to remove eyepiece cap                                      |
|                                      |        | FE 50mm F2.5 G                       |                                       | √                  | -        | -   | -        | -                          | No need to remove eyepiece cap                                      |
|                                      |        | FE 50mm F2.8                         |                                       | √                  | -        | -   | -        | -                          | No need to remove eyepiece cap                                      |
|                                      |        | Sonnar® T* FE 55mm F1.8 ZA           |                                       | √                  | -        | -   | -        | -                          | No need to remove eyepiece cap                                      |
|                                      |        | E 10-18mm F4 OSS                     |                                       | √                  | -        | -   | -        | -                          | Can be balanced at any focal length, no need to remove eyepiece cap |
|                                      |        | FE PZ 16-35mm F4 G                   |                                       | √                  | -        | -   | -        | -                          | Can be balanced at any focal length, no need to remove eyepiece cap |
|                                      |        | FE 28-60mm F4-5.6                    |                                       | √                  | -        | -   | -        | -                          | Can be balanced at any focal length, no need to remove eyepiece cap |
| FE 28-70mm F3.5-5.6 OSS              | √      | -                                    | -                                     | -                  | -        | Can be balanced at any focal length, no need to remove eyepiece cap |          |                            |   |
| Vario-Tessar T* E 16-70mm F4 ZA OSS  | √      | -                                    | -                                     | -                  | -        | Can be balanced at any focal length, need to remove eyepiece cap    |          |                            |   |
| Vario-Tessar T* FE 24-70mm F4 ZA OSS | √      | -                                    | -                                     | -                  | -        | Can be balanced at 24-50mm, need to remove eyepiece cap             |          |                            |   |
| E PZ 18-105mm F4 G OSS               | √      | -                                    | -                                     | -                  | -        | Can be balanced at any focal length, need to remove eyepiece cap    |          |                            |   |



| Camera Brand                       | Model | Lens Model                           | Mounting Status                       | Balance Adjustment |          | Camera Backing Base  |          | Servo Zoom/<br>Focus Motor | Installation Remark   |
|------------------------------------|-------|--------------------------------------|---------------------------------------|--------------------|----------|--|----------|----------------------------|---|
|                                    |       |                                      |                                       | Horizontal         | Vertical | Horizontal   | Vertical |                            |   |
| Sony                               | α6700 | FE 14mm F1.8 GM                      | Standard quick release plate provided | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                      |
|                                    |       | FE 20mm F1.8 G                       |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                      |
|                                    |       | Sonnar T* E 24mm F1.8 ZA             |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                      |
|                                    |       | FE 24 mm F1.4 GM                     |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                      |
|                                    |       | FE 24mm F2.8 G                       |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                      |
|                                    |       | FE 28mm F2                           |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                      |
|                                    |       | Sigma 30mm f/1.4 DC DN               |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                      |
|                                    |       | FE 35mm F1.8                         |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                      |
|                                    |       | Sonnar T* FE 35mm F2.8 ZA            |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                      |
|                                    |       | FE 40mm F2.5 G                       |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                      |
|                                    |       | Sigma 45mm f/2.8 DG DN               |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                      |
|                                    |       | FE 50mm F1.8                         |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                      |
|                                    |       | FE 50mm F2.5 G                       |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                      |
|                                    |       | FE 50mm F2.8                         |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                      |
|                                    |       | Sonnar® T* FE 55mm F1.8 ZA           |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                      |
|                                    |       | FE 85mm f/1.8                        |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                      |
|                                    |       | E 10-18mm F4 OSS                     |                                       | √                  | -        | -  | -        | -                          | Can be balanced at any focal length, no need to remove eyepiece cap |
|                                    |       | FE PZ 16-35mm F4 G                   |                                       | √                  | -        | -  | -        | -                          | Can be balanced at any focal length, no need to remove eyepiece cap |
|                                    |       | FE 28-60mm F4-5.6                    |                                       | √                  | -        | -  | -        | -                          | Can be balanced at any focal length, no need to remove eyepiece cap |
|                                    |       | Sigma 28-70mm f/2.8 DG DN            |                                       | √                  | -        | -  | -        | -                          | Can be balanced at any focal length, no need to remove eyepiece cap |
|                                    |       | FE 28-70mm F3.5-5.6 OSS              |                                       | √                  | -        | -  | -        | -                          | Can be balanced at any focal length, no need to remove eyepiece cap |
|                                    |       | Vario-Tessar T* E 16-70mm F4 ZA OSS  |                                       | √                  | -        | -  | -        | -                          | Can be balanced at any focal length, no need to remove eyepiece cap |
|                                    |       | Vario-Tessar T* FE 24-70mm F4 ZA OSS |                                       | √                  | -        | -  | -        | -                          | Can be balanced at any focal length, no need to remove eyepiece cap |
|                                    |       | Tamron 28-75mm F2.8 Di III RXD       |                                       | √                  | -        | -  | -        | -                          | Can be balanced at 28-35mm, no need to remove eyepiece cap          |
| Tamron 28-75mm F/2.8 Di III VXD G2 | √     | -                                    | -                                     | -                  | -        | Can be balanced at 28-35mm, no need to remove eyepiece cap       |          |                            |   |
| E PZ 18-105mm F4 G OSS             | √     | -                                    | -                                     | -                  | -        | Can be balanced at any focal length, need to remove eyepiece cap |          |                            |   |



| Camera Brand           | Model | Lens Model                 | Mounting Status                       | Balance Adjustment |          | Camera Backing Base   |          | Servo Zoom/<br>Focus Motor | Installation Remark   |
|------------------------|-------|----------------------------|---------------------------------------|--------------------|----------|---|----------|----------------------------|---|
|                        |       |                            |                                       | Horizontal         | Vertical | Horizontal  | Vertical |                            |   |
| Sony                   | α6600 | FE 14mm F1.8 GM            | Standard quick release plate provided | √                  | -        | -   | -        | -                          | No need to remove eyepiece cap                                      |
|                        |       | FE 20mm F1.8 G             |                                       | √                  | -        | -   | -        | -                          | No need to remove eyepiece cap                                      |
|                        |       | Sonnar T* E 24mm F1.8 ZA   |                                       | √                  | -        | -   | -        | -                          | No need to remove eyepiece cap                                      |
|                        |       | FE 24 mm F1.4 GM           |                                       | √                  | -        | -   | -        | -                          | No need to remove eyepiece cap                                      |
|                        |       | FE 24mm F2.8 G             |                                       | √                  | -        | -   | -        | -                          | No need to remove eyepiece cap                                      |
|                        |       | FE 28mm F2                 |                                       | √                  | -        | -   | -        | -                          | No need to remove eyepiece cap                                      |
|                        |       | Sigma 30mm f/1.4 DC DN     |                                       | √                  | -        | -   | -        | -                          | No need to remove eyepiece cap                                      |
|                        |       | FE 35mm F1.8               |                                       | √                  | -        | -   | -        | -                          | No need to remove eyepiece cap                                      |
|                        |       | Sonnar T* FE 35mm F2.8 ZA  |                                       | √                  | -        | -   | -        | -                          | No need to remove eyepiece cap                                      |
|                        |       | FE 40mm F2.5 G             |                                       | √                  | -        | -   | -        | -                          | No need to remove eyepiece cap                                      |
|                        |       | Sigma 45mm f/2.8 DG DN     |                                       | √                  | -        | -   | -        | -                          | No need to remove eyepiece cap                                      |
|                        |       | FE 50mm F1.8               |                                       | √                  | -        | -   | -        | -                          | No need to remove eyepiece cap                                      |
|                        |       | FE 50mm F2.5 G             |                                       | √                  | -        | -   | -        | -                          | No need to remove eyepiece cap                                      |
|                        |       | FE 50mm F2.8               |                                       | √                  | -        | -   | -        | -                          | No need to remove eyepiece cap                                      |
|                        |       | Sonnar® T* FE 55mm F1.8 ZA |                                       | √                  | -        | -   | -        | -                          | No need to remove eyepiece cap                                      |
|                        |       | FE 85mm f/1.8              |                                       | √                  | -        | -   | -        | -                          | No need to remove eyepiece cap                                      |
|                        |       | E 10-18mm F4 OSS           |                                       | √                  | -        | -   | -        | -                          | Can be balanced at any focal length, no need to remove eyepiece cap |
| E PZ 18-105mm F4 G OSS | √     | -                          | -                                     | -                  | -        | Can be balanced at any focal length, no need to remove eyepiece cap |          |                            |   |



| Camera Brand               | Model | Lens Model                            | Mounting Status                       | Balance Adjustment |          | Camera Backing Base            |          | Servo Zoom/<br>Focus Motor | Installation Remark   |
|----------------------------|-------|---------------------------------------|---------------------------------------|--------------------|----------|--------------------------------|----------|----------------------------|---|
|                            |       |                                       |                                       | Horizontal         | Vertical | Horizontal                     | Vertical |                            |   |
| Sony                       | α6600 | FE PZ 16-35mm F4 G                    | Standard quick release plate provided | √                  | -        | -                              | -        | -                          | Can be balanced at any focal length, no need to remove eyepiece cap |
|                            |       | FE 28-60mm F4-5.6                     |                                       | √                  | -        | -                              | -        | -                          | Can be balanced at any focal length, no need to remove eyepiece cap |
|                            |       | Sigma 28-70mm f/2.8 DG DN             |                                       | √                  | -        | -                              | -        | -                          | Can be balanced at any focal length, no need to remove eyepiece cap |
|                            |       | FE 28-70mm F3.5-5.6 OSS               |                                       | √                  | -        | -                              | -        | -                          | Can be balanced at any focal length, no need to remove eyepiece cap |
|                            |       | Vario-Tessar T* E 16-70mm F4 ZA OSS   |                                       | √                  | -        | -                              | -        | -                          | Can be balanced at any focal length, no need to remove eyepiece cap |
|                            |       | Vario-Tessar T* FE 24-70mm F4 ZA OSS  |                                       | √                  | -        | -                              | -        | -                          | Can be balanced at any focal length, no need to remove eyepiece cap |
|                            |       | Tamron 28-75mm F2.8 Di III RXD        |                                       | √                  | -        | -                              | -        | -                          | Can be balanced at 28-35mm, no need to remove eyepiece cap          |
|                            |       | Tamron 28-75mm F/2.8 Di III VXD G2    |                                       | √                  | -        | -                              | -        | -                          | Can be balanced at 28-35mm, No need to remove eyepiece cap          |
|                            | α6500 | Standard quick release plate provided | FE 14mm F1.8 GM                       | √                  | -        | -                              | -        | -                          | No need to remove eyepiece cap                                      |
|                            |       |                                       | FE 20mm F1.8 G                        | √                  | -        | -                              | -        | -                          | No need to remove eyepiece cap                                      |
|                            |       |                                       | Sonnar T* E 24mm F1.8 ZA              | √                  | -        | -                              | -        | -                          | No need to remove eyepiece cap                                      |
|                            |       |                                       | FE 24 mm F1.4 GM                      | √                  | -        | -                              | -        | -                          | No need to remove eyepiece cap                                      |
|                            |       |                                       | FE 24mm F2.8 G                        | √                  | -        | -                              | -        | -                          | No need to remove eyepiece cap                                      |
|                            |       |                                       | FE 28mm F2                            | √                  | -        | -                              | -        | -                          | No need to remove eyepiece cap                                      |
|                            |       |                                       | Sigma 30mm f/1.4 DC DN                | √                  | -        | -                              | -        | -                          | No need to remove eyepiece cap                                      |
|                            |       |                                       | FE 35mm F1.8                          | √                  | -        | -                              | -        | -                          | No need to remove eyepiece cap                                      |
|                            |       |                                       | Sonnar T* FE 35mm F2.8 ZA             | √                  | -        | -                              | -        | -                          | No need to remove eyepiece cap                                      |
|                            |       |                                       | FE 40mm F2.5 G                        | √                  | -        | -                              | -        | -                          | No need to remove eyepiece cap                                      |
|                            |       |                                       | Sigma 45mm f/2.8 DG DN                | √                  | -        | -                              | -        | -                          | No need to remove eyepiece cap                                      |
|                            |       |                                       | FE 50mm F1.8                          | √                  | -        | -                              | -        | -                          | No need to remove eyepiece cap                                      |
| FE 50mm F2.5 G             | √     | -                                     | -                                     | -                  | -        | No need to remove eyepiece cap |          |                            |   |
| FE 50mm F2.8               | √     | -                                     | -                                     | -                  | -        | No need to remove eyepiece cap |          |                            |   |
| Sonnar® T* FE 55mm F1.8 ZA | √     | -                                     | -                                     | -                  | -        | No need to remove eyepiece cap |          |                            |   |
| FE 85mm f/1.8              | √     | -                                     | -                                     | -                  | -        | No need to remove eyepiece cap |          |                            |   |



| Camera Brand               | Model | Lens Model                           | Mounting Status                       | Balance Adjustment |          | Camera Backing Base            |          | Servo Zoom/<br>Focus Motor     | Installation Remark   |
|----------------------------|-------|--------------------------------------|---------------------------------------|--------------------|----------|--------------------------------|----------|--------------------------------|---|
|                            |       |                                      |                                       | Horizontal         | Vertical | Horizontal                     | Vertical |                                |   |
| Sony                       | α6500 | E 10-18mm F4 OSS                     | Standard quick release plate provided | √                  | -        | -                              | -        | -                              | Can be balanced at any focal length, no need to remove eyepiece cap |
|                            |       | E PZ 18-105mm F4 G OSS               |                                       | √                  | -        | -                              | -        | -                              | Can be balanced at any focal length, no need to remove eyepiece cap |
|                            |       | FE PZ 16-35mm F4 G                   |                                       | √                  | -        | -                              | -        | -                              | Can be balanced at any focal length, no need to remove eyepiece cap |
|                            |       | FE 28-60mm F4-5.6                    |                                       | √                  | -        | -                              | -        | -                              | Can be balanced at any focal length, no need to remove eyepiece cap |
|                            |       | Sigma 28-70mm f/2.8 DG DN            |                                       | √                  | -        | -                              | -        | -                              | Can be balanced at any focal length, no need to remove eyepiece cap |
|                            |       | FE 28-70mm F3.5-5.6 OSS              |                                       | √                  | -        | -                              | -        | -                              | Can be balanced at any focal length, no need to remove eyepiece cap |
|                            |       | Vario-Tessar T* E 16-70mm F4 ZA OSS  |                                       | √                  | -        | -                              | -        | -                              | Can be balanced at any focal length, no need to remove eyepiece cap |
|                            |       | Vario-Tessar T* FE 24-70mm F4 ZA OSS |                                       | √                  | -        | -                              | -        | -                              | Can be balanced at any focal length, no need to remove eyepiece cap |
|                            |       | Tamron 28-75mm F2.8 Di III RXD       |                                       | √                  | -        | -                              | -        | -                              | Can be balanced at 28-35mm, no need to remove eyepiece cap          |
|                            |       | Tamron 28-75mm F/2.8 Di III VXD G2   |                                       | √                  | -        | -                              | -        | -                              | Can be balanced at 28-35mm, no need to remove eyepiece cap          |
|                            | α6400 | FE 14mm F1.8 GM                      | Standard quick release plate provided | √                  | -        | -                              | -        | -                              | No need to remove eyepiece cap                                      |
|                            |       | FE 20mm F1.8 G                       |                                       | √                  | -        | -                              | -        | -                              | No need to remove eyepiece cap                                      |
|                            |       | Sonnar T* E 24mm F1.8 ZA             |                                       | √                  | -        | -                              | -        | -                              | No need to remove eyepiece cap                                      |
|                            |       | FE 24 mm F1.4 GM                     |                                       | √                  | -        | -                              | -        | -                              | No need to remove eyepiece cap                                      |
|                            |       | FE 24mm F2.8 G                       |                                       | √                  | -        | -                              | -        | -                              | No need to remove eyepiece cap                                      |
|                            |       | FE 28mm F2                           |                                       | √                  | -        | -                              | -        | -                              | No need to remove eyepiece cap                                      |
|                            |       | Sigma 30mm f/1.4 DC DN               |                                       | √                  | -        | -                              | -        | -                              | No need to remove eyepiece cap                                      |
|                            |       | FE 35mm F1.8                         |                                       | √                  | -        | -                              | -        | -                              | No need to remove eyepiece cap                                      |
|                            |       | Sonnar T* FE 35mm F2.8 ZA            |                                       | √                  | -        | -                              | -        | -                              | No need to remove eyepiece cap                                      |
|                            |       | FE 40mm F2.5 G                       |                                       | √                  | -        | -                              | -        | -                              | No need to remove eyepiece cap                                      |
| Sigma 45mm f/2.8 DG DN     |       | √                                    |                                       | -                  | -        | -                              | -        | No need to remove eyepiece cap |   |
| FE 50mm F1.8               |       | √                                    |                                       | -                  | -        | -                              | -        | No need to remove eyepiece cap |   |
| FE 50mm F2.5 G             |       | √                                    |                                       | -                  | -        | -                              | -        | No need to remove eyepiece cap |   |
| FE 50mm F2.8               |       | √                                    |                                       | -                  | -        | -                              | -        | No need to remove eyepiece cap |   |
| Sonnar® T* FE 55mm F1.8 ZA | √     | -                                    | -                                     | -                  | -        | No need to remove eyepiece cap |          |                                |   |

| Camera Brand           | Model | Lens Model                           | Mounting Status                       | Balance Adjustment |          | Camera Backing Base            |          | Servo Zoom/<br>Focus Motor     | Installation Remark   |
|------------------------|-------|--------------------------------------|---------------------------------------|--------------------|----------|--------------------------------|----------|--------------------------------|---|
|                        |       |                                      |                                       | Horizontal         | Vertical | Horizontal                     | Vertical |                                |   |
| Sony                   | α6400 | FE 85mm f/1.8                        | Standard quick release plate provided | √                  | -        | -                              | -        | -                              | No need to remove eyepiece cap                                      |
|                        |       | E 10-18mm F4 OSS                     |                                       | √                  | -        | -                              | -        | -                              | Can be balanced at any focal length, no need to remove eyepiece cap |
|                        |       | E PZ 18-105mm F4 G OSS               |                                       | √                  | -        | -                              | -        | -                              | Can be balanced at any focal length, no need to remove eyepiece cap |
|                        |       | FE PZ 16-35mm F4 G                   |                                       | √                  | -        | -                              | -        | -                              | Can be balanced at any focal length, no need to remove eyepiece cap |
|                        |       | FE 28-60mm F4-5.6                    |                                       | √                  | -        | -                              | -        | -                              | Can be balanced at any focal length, no need to remove eyepiece cap |
|                        |       | Sigma 28-70mm f/2.8 DG DN            |                                       | √                  | -        | -                              | -        | -                              | Can be balanced at any focal length, no need to remove eyepiece cap |
|                        |       | FE 28-70mm F3.5-5.6 OSS              |                                       | √                  | -        | -                              | -        | -                              | Can be balanced at any focal length, no need to remove eyepiece cap |
|                        |       | Vario-Tessar T* E 16-70mm F4 ZA OSS  |                                       | √                  | -        | -                              | -        | -                              | Can be balanced at any focal length, no need to remove eyepiece cap |
|                        |       | Vario-Tessar T* FE 24-70mm F4 ZA OSS |                                       | √                  | -        | -                              | -        | -                              | Can be balanced at any focal length, no need to remove eyepiece cap |
|                        |       | Tamron 28-75mm F2.8 Di III RXD       |                                       | √                  | -        | -                              | -        | -                              | Can be balanced at 28-35mm, no need to remove eyepiece cap          |
|                        |       | Tamron 28-75mm F/2.8 Di III VXD G2   |                                       | √                  | -        | -                              | -        | -                              | Can be balanced at 28-35mm, no need to remove eyepiece cap          |
|                        | α6300 | FE 14mm F1.8 GM                      | Standard quick release plate provided | √                  | -        | -                              | -        | -                              | No need to remove eyepiece cap                                      |
|                        |       | FE 20mm F1.8 G                       |                                       | √                  | -        | -                              | -        | -                              | No need to remove eyepiece cap                                      |
|                        |       | Sonnar T* E 24mm F1.8 ZA             |                                       | √                  | -        | -                              | -        | -                              | No need to remove eyepiece cap                                      |
|                        |       | FE 24 mm F1.4 GM                     |                                       | √                  | -        | -                              | -        | -                              | No need to remove eyepiece cap                                      |
|                        |       | FE 24mm F2.8 G                       |                                       | √                  | -        | -                              | -        | -                              | No need to remove eyepiece cap                                      |
|                        |       | FE 28mm F2                           |                                       | √                  | -        | -                              | -        | -                              | No need to remove eyepiece cap                                      |
|                        |       | Sigma 30mm f/1.4 DC DN               |                                       | √                  | -        | -                              | -        | -                              | No need to remove eyepiece cap                                      |
|                        |       | FE 35mm F1.8                         |                                       | √                  | -        | -                              | -        | -                              | No need to remove eyepiece cap                                      |
|                        |       | Sonnar T* FE 35mm F2.8 ZA            |                                       | √                  | -        | -                              | -        | -                              | No need to remove eyepiece cap                                      |
| FE 40mm F2.5 G         |       | √                                    |                                       | -                  | -        | -                              | -        | No need to remove eyepiece cap |   |
| Sigma 45mm f/2.8 DG DN |       | √                                    |                                       | -                  | -        | -                              | -        | No need to remove eyepiece cap |   |
| FE 50mm F1.8           |       | √                                    |                                       | -                  | -        | -                              | -        | No need to remove eyepiece cap |   |
| FE 50mm F2.5 G         |       | √                                    |                                       | -                  | -        | -                              | -        | No need to remove eyepiece cap |   |
| FE 50mm F2.8           | √     | -                                    | -                                     | -                  | -        | No need to remove eyepiece cap |          |                                |   |



| Camera Brand           | Model | Lens Model                            | Mounting Status                       | Balance Adjustment |          | Camera Backing Base |          | Servo Zoom/<br>Focus Motor     | Installation Remark   |
|------------------------|-------|---------------------------------------|---------------------------------------|--------------------|----------|---------------------|----------|--------------------------------|---|
|                        |       |                                       |                                       | Horizontal         | Vertical | Horizontal          | Vertical |                                |   |
| Sony                   | α6300 | Sonnar® T* FE 55mm F1.8 ZA            | Standard quick release plate provided | √                  | -        | -                   | -        | -                              | No need to remove eyepiece cap                                      |
|                        |       | FE 85mm f/1.8                         |                                       | √                  | -        | -                   | -        | -                              | No need to remove eyepiece cap                                      |
|                        |       | E 10-18mm F4 OSS                      |                                       | √                  | -        | -                   | -        | -                              | Can be balanced at any focal length, no need to remove eyepiece cap |
|                        |       | E PZ 18-105mm F4 G OSS                |                                       | √                  | -        | -                   | -        | -                              | Can be balanced at any focal length, no need to remove eyepiece cap |
|                        |       | FE PZ 16-35mm F4 G                    |                                       | √                  | -        | -                   | -        | -                              | Can be balanced at any focal length, no need to remove eyepiece cap |
|                        |       | FE 28-60mm F4-5.6                     |                                       | √                  | -        | -                   | -        | -                              | Can be balanced at any focal length, no need to remove eyepiece cap |
|                        |       | Sigma 28-70mm f/2.8 DG DN             |                                       | √                  | -        | -                   | -        | -                              | Can be balanced at any focal length, no need to remove eyepiece cap |
|                        |       | FE 28-70mm F3.5-5.6 OSS               |                                       | √                  | -        | -                   | -        | -                              | Can be balanced at any focal length, no need to remove eyepiece cap |
|                        |       | Vario-Tessar T* E 16-70mm F4 ZA OSS   |                                       | √                  | -        | -                   | -        | -                              | Can be balanced at any focal length, no need to remove eyepiece cap |
|                        |       | Vario-Tessar T* FE 24-70mm F4 ZA OSS  |                                       | √                  | -        | -                   | -        | -                              | Can be balanced at any focal length, no need to remove eyepiece cap |
|                        |       | Tamron 28-75mm F2.8 Di III RXD        |                                       | √                  | -        | -                   | -        | -                              | Can be balanced at 28-35mm, No need to remove eyepiece cap          |
|                        |       | Tamron 28-75mm F/2.8 Di III VXD G2    |                                       | √                  | -        | -                   | -        | -                              | Can be balanced at 28-35mm, No need to remove eyepiece cap          |
|                        | α6100 | Standard quick release plate provided | FE 14mm F1.8 GM                       | √                  | -        | -                   | -        | -                              | No need to remove eyepiece cap                                      |
|                        |       |                                       | FE 20mm F1.8 G                        | √                  | -        | -                   | -        | -                              | No need to remove eyepiece cap                                      |
|                        |       |                                       | Sonnar T* E 24mm F1.8 ZA              | √                  | -        | -                   | -        | -                              | No need to remove eyepiece cap                                      |
|                        |       |                                       | FE 24 mm F1.4 GM                      | √                  | -        | -                   | -        | -                              | No need to remove eyepiece cap                                      |
|                        |       |                                       | FE 24mm F2.8 G                        | √                  | -        | -                   | -        | -                              | No need to remove eyepiece cap                                      |
|                        |       |                                       | FE 28mm F2                            | √                  | -        | -                   | -        | -                              | No need to remove eyepiece cap                                      |
|                        |       |                                       | Sigma 30mm f/1.4 DC DN                | √                  | -        | -                   | -        | -                              | No need to remove eyepiece cap                                      |
|                        |       |                                       | FE 35mm F1.8                          | √                  | -        | -                   | -        | -                              | No need to remove eyepiece cap                                      |
|                        |       |                                       | Sonnar T* FE 35mm F2.8 ZA             | √                  | -        | -                   | -        | -                              | No need to remove eyepiece cap                                      |
| FE 40mm F2.5 G         |       |                                       | √                                     | -                  | -        | -                   | -        | No need to remove eyepiece cap |   |
| Sigma 45mm f/2.8 DG DN |       |                                       | √                                     | -                  | -        | -                   | -        | No need to remove eyepiece cap |   |
| FE 50mm F1.8           |       |                                       | √                                     | -                  | -        | -                   | -        | No need to remove eyepiece cap |   |
| FE 50mm F2.5 G         |       |                                       | √                                     | -                  | -        | -                   | -        | No need to remove eyepiece cap |   |



| Camera Brand              | Model  | Lens Model                            | Mounting Status                       | Balance Adjustment |          | Camera Backing Base |          | Servo Zoom/<br>Focus Motor     | Installation Remark   |
|---------------------------|--------|---------------------------------------|---------------------------------------|--------------------|----------|---------------------|----------|--------------------------------|---|
|                           |        |                                       |                                       | Horizontal         | Vertical | Horizontal          | Vertical |                                |   |
| Sony                      | α6100  | FE 50mm F2.8                          | Standard quick release plate provided | √                  | -        | -                   | -        | -                              | No need to remove eyepiece cap                                      |
|                           |        | Sonnar® T* FE 55mm F1.8 ZA            |                                       | √                  | -        | -                   | -        | -                              | No need to remove eyepiece cap                                      |
|                           |        | FE 85mm f/1.8                         |                                       | √                  | -        | -                   | -        | -                              | No need to remove eyepiece cap                                      |
|                           |        | E 10-18mm F4 OSS                      |                                       | √                  | -        | -                   | -        | -                              | Can be balanced at any focal length, no need to remove eyepiece cap |
|                           |        | E PZ 18-105mm F4 G OSS                |                                       | √                  | -        | -                   | -        | -                              | Can be balanced at any focal length, no need to remove eyepiece cap |
|                           |        | FE PZ 16-35mm F4 G                    |                                       | √                  | -        | -                   | -        | -                              | Can be balanced at any focal length, no need to remove eyepiece cap |
|                           |        | FE 28-60mm F4-5.6                     |                                       | √                  | -        | -                   | -        | -                              | Can be balanced at any focal length, no need to remove eyepiece cap |
|                           |        | Sigma 28-70mm f/2.8 DG DN             |                                       | √                  | -        | -                   | -        | -                              | Can be balanced at any focal length, no need to remove eyepiece cap |
|                           |        | FE 28-70mm F3.5-5.6 OSS               |                                       | √                  | -        | -                   | -        | -                              | Can be balanced at any focal length, no need to remove eyepiece cap |
|                           |        | Vario-Tessar T* E 16-70mm F4 ZA OSS   |                                       | √                  | -        | -                   | -        | -                              | Can be balanced at any focal length, no need to remove eyepiece cap |
|                           |        | Vario-Tessar T* FE 24-70mm F4 ZA OSS  |                                       | √                  | -        | -                   | -        | -                              | Can be balanced at any focal length, no need to remove eyepiece cap |
|                           |        | Tamron 28-75mm F2.8 Di III RXD        |                                       | √                  | -        | -                   | -        | -                              | Can be balanced at 28-35mm, No need to remove eyepiece cap          |
|                           |        | Tamron 28-75mm F/2.8 Di III VXD G2    |                                       | √                  | -        | -                   | -        | -                              | Can be balanced at 28-35mm, No need to remove eyepiece cap          |
|                           | ZV-E10 | Standard quick release plate provided | FE 14mm F1.8 GM                       | √                  | -        | -                   | -        | -                              | No need to remove eyepiece cap                                      |
|                           |        |                                       | FE 20mm F1.8 G                        | √                  | -        | -                   | -        | -                              | No need to remove eyepiece cap                                      |
|                           |        |                                       | Sonnar T* E 24mm F1.8 ZA              | √                  | -        | -                   | -        | -                              | No need to remove eyepiece cap                                      |
|                           |        |                                       | FE 24 mm F1.4 GM                      | √                  | -        | -                   | -        | -                              | No need to remove eyepiece cap                                      |
|                           |        |                                       | FE 24mm F2.8 G                        | √                  | -        | -                   | -        | -                              | No need to remove eyepiece cap                                      |
|                           |        |                                       | FE 28mm F2                            | √                  | -        | -                   | -        | -                              | No need to remove eyepiece cap                                      |
|                           |        |                                       | Sigma 30mm f/1.4 DC DN                | √                  | -        | -                   | -        | -                              | No need to remove eyepiece cap                                      |
| FE 35mm F1.8              |        |                                       | √                                     | -                  | -        | -                   | -        | No need to remove eyepiece cap |   |
| Sonnar T* FE 35mm F2.8 ZA |        |                                       | √                                     | -                  | -        | -                   | -        | No need to remove eyepiece cap |   |
| FE 40mm F2.5 G            |        |                                       | √                                     | -                  | -        | -                   | -        | No need to remove eyepiece cap |   |
| Sigma 45mm f/2.8 DG DN    |        |                                       | √                                     | -                  | -        | -                   | -        | No need to remove eyepiece cap |   |





| Camera Brand | Model                              | Lens Model                           | Mounting Status                       | Balance Adjustment                    |          | Camera Backing Base |  | Servo Zoom/<br>Focus Motor | Installation Remark   |                                 |
|--------------|------------------------------------|--------------------------------------|---------------------------------------|---------------------------------------|----------|---------------------|--|----------------------------|---|---------------------------------|
|              |                                    |                                      |                                       | Horizontal                            | Vertical | Horizontal          | Vertical   |                            |   |                                 |
| Sony         | ZV-E10                             | FE 50mm F1.8                         | Standard quick release plate provided | √                                     | -        | -                   | -  | -                          | No need to remove eyepiece cap                                      |                                 |
|              |                                    | FE 50mm F2.5 G                       |                                       | √                                     | -        | -                   | -  | -                          | No need to remove eyepiece cap                                      |                                 |
|              |                                    | FE 50mm F2.8                         |                                       | √                                     | -        | -                   | -  | -                          | No need to remove eyepiece cap                                      |                                 |
|              |                                    | Sonnar® T* FE 55mm F1.8 ZA           |                                       | √                                     | -        | -                   | -  | -                          | No need to remove eyepiece cap                                      |                                 |
|              |                                    | FE 85mm f/1.8                        |                                       | √                                     | -        | -                   | -  | -                          | No need to remove eyepiece cap                                      |                                 |
|              |                                    | E 10-18mm F4 OSS                     |                                       | √                                     | -        | -                   | -  | -                          | Can be balanced at any focal length, no need to remove eyepiece cap |                                 |
|              |                                    | E PZ 18-105mm F4 G OSS               |                                       | √                                     | -        | -                   | -  | -                          | Can be balanced at any focal length, no need to remove eyepiece cap |                                 |
|              |                                    | E PZ 18-105mm F4 G OSS               |                                       | √                                     | -        | -                   | -  | -                          | Can be balanced at any focal length, no need to remove eyepiece cap |                                 |
|              |                                    | FE PZ 16-35mm F4 G                   |                                       | √                                     | -        | -                   | -  | -                          | Can be balanced at any focal length, no need to remove eyepiece cap |                                 |
|              |                                    | FE 28-60mm F4-5.6                    |                                       | √                                     | -        | -                   | -  | -                          | Can be balanced at any focal length, no need to remove eyepiece cap |                                 |
|              |                                    | Sigma 28-70mm f/2.8 DG DN            |                                       | √                                     | -        | -                   | -  | -                          | Can be balanced at any focal length, no need to remove eyepiece cap |                                 |
|              |                                    | FE 28-70mm F3.5-5.6 OSS              |                                       | √                                     | -        | -                   | -  | -                          | Can be balanced at any focal length, no need to remove eyepiece cap |                                 |
|              |                                    | Vario-Tessar T* E 16-70mm F4 ZA OSS  |                                       | √                                     | -        | -                   | -  | -                          | Can be balanced at any focal length, no need to remove eyepiece cap |                                 |
|              |                                    | Vario-Tessar T* FE 24-70mm F4 ZA OSS |                                       | √                                     | -        | -                   | -  | -                          | Can be balanced at any focal length, no need to remove eyepiece cap |                                 |
|              | Tamron 28-75mm F2.8 Di III RXD     | √                                    | -                                     | -                                     | -        | -                   | Can be balanced at 28-35mm, no need to remove eyepiece cap |                            |   |                                 |
|              | Tamron 28-75mm F/2.8 Di III VXD G2 | √                                    | -                                     | -                                     | -        | -                   | Can be balanced at 28-35mm, no need to remove eyepiece cap |                            |   |                                 |
|              |                                    |                                      |                                       |                                       |          |                     |  |                            |   |                                 |
|              |                                    | DSC-RX100M5A                         | Comes with the lens                   | Standard quick release plate provided | √        | -                   | -  | -                          | -   | Should be powered on to balance |
|              |                                    | DSC-RX100M5                          | Comes with the lens                   |                                       | √        | -                   | -  | -                          | -   | Should be powered on to balance |
|              |                                    | DSC-RX100M6                          | Comes with the lens                   |                                       | √        | -                   | -  | -                          | -   | Should be powered on to balance |
|              | DSC-RX100M7                        | Comes with the lens                  | √                                     |                                       | -        | -                   | -  | -                          | Should be powered on to balance                                     |                                 |
|              | DSC-WX350                          | Comes with the lens                  | √                                     |                                       | -        | -                   | -  | -                          | Should be powered on to balance                                     |                                 |
|              | DSC-HX90                           | Comes with the lens                  | √                                     |                                       | -        | -                   | -  | -                          | Should be powered on to balance                                     |                                 |
|              |                                    |                                      |                                       |                                       |          |                     |  |                            |   |                                 |
|              | ZV-1, ZV-1 II                      | Comes with the lens                  | Standard quick release plate provided | √                                     | -        | -                   | -  | -                          | Should be powered on to balance                                     |                                 |



| Camera Brand | Model  | Lens Model                    | Mounting Status                       | Balance Adjustment |          | Camera Backing Base |          | Servo Zoom/<br>Focus Motor | Installation Remark        |
|--------------|--------|-------------------------------|---------------------------------------|--------------------|----------|---------------------|----------|----------------------------|----------------------------|
|              |        |                               |                                       | Horizontal         | Vertical | Horizontal          | Vertical |                            |                            |
| Canon        | EOS R  | RF 15-30mm f/4.5-6.3 IS STM   | Standard quick release plate provided | √                  | -        | -                   | -        | -                          | Do not remove eyepiece cap |
|              |        | RF 16mm F2.8 STM              |                                       | √                  | -        | -                   | -        | -                          | Do not remove eyepiece cap |
|              |        | RF 24-105mm F4-7.1 IS STM     |                                       | √                  | -        | -                   | -        | -                          | Do not remove eyepiece cap |
|              |        | RF 24mm f/1.8 Macro IS STM    |                                       | √                  | -        | -                   | -        | -                          | Do not remove eyepiece cap |
|              |        | RF 35mm F1.8 MACRO IS STM     |                                       | √                  | -        | -                   | -        | -                          | Do not remove eyepiece cap |
|              |        | RF 50mm F1.8 STM              |                                       | √                  | -        | -                   | -        | -                          | Do not remove eyepiece cap |
|              |        | RF-S 18-45mm f/4.5-6.3 IS STM |                                       | √                  | -        | -                   | -        | -                          | Do not remove eyepiece cap |
|              |        | RF 24-50mm F4.5-6.3 IS STM    |                                       | √                  | -        | -                   | -        | -                          | Do not remove eyepiece cap |
|              | EOS R5 | RF 15-30mm f/4.5-6.3 IS STM   | Standard quick release plate provided | √                  | -        | -                   | -        | -                          | Do not remove eyepiece cap |
|              |        | RF 16mm F2.8 STM              |                                       | √                  | -        | -                   | -        | -                          | Do not remove eyepiece cap |
|              |        | RF 24-105mm F4-7.1 IS STM     |                                       | √                  | -        | -                   | -        | -                          | Do not remove eyepiece cap |
|              |        | RF 24mm f/1.8 Macro IS STM    |                                       | √                  | -        | -                   | -        | -                          | Do not remove eyepiece cap |
|              |        | RF 35mm F1.8 MACRO IS STM     |                                       | √                  | -        | -                   | -        | -                          | Do not remove eyepiece cap |
|              |        | RF 50mm F1.8 STM              |                                       | √                  | -        | -                   | -        | -                          | Do not remove eyepiece cap |
|              |        | RF-S 18-45mm f/4.5-6.3 IS STM |                                       | √                  | -        | -                   | -        | -                          | Do not remove eyepiece cap |
|              |        | RF 24-50mm F4.5-6.3 IS STM    |                                       | √                  | -        | -                   | -        | -                          | Do not remove eyepiece cap |
|              | EOS R6 | RF 15-30mm f/4.5-6.3 IS STM   | Standard quick release plate provided | √                  | -        | -                   | -        | -                          | Do not remove eyepiece cap |
|              |        | RF 16mm F2.8 STM              |                                       | √                  | -        | -                   | -        | -                          | Do not remove eyepiece cap |
|              |        | RF 24-105mm F4-7.1 IS STM     |                                       | √                  | -        | -                   | -        | -                          | Do not remove eyepiece cap |
|              |        | RF 24mm f/1.8 Macro IS STM    |                                       | √                  | -        | -                   | -        | -                          | Do not remove eyepiece cap |
|              |        | RF 35mm F1.8 MACRO IS STM     |                                       | √                  | -        | -                   | -        | -                          | Do not remove eyepiece cap |
|              |        | RF 50mm F1.8 STM              |                                       | √                  | -        | -                   | -        | -                          | Do not remove eyepiece cap |
|              |        | RF-S 18-45mm f/4.5-6.3 IS STM |                                       | √                  | -        | -                   | -        | -                          | Do not remove eyepiece cap |
|              |        | RF 24-50mm F4.5-6.3 IS STM    |                                       | √                  | -        | -                   | -        | -                          | Do not remove eyepiece cap |



| Camera Brand | Model          | Lens Model                    | Mounting Status                       | Balance Adjustment |          | Camera Backing Base |          | Servo Zoom/<br>Focus Motor | Installation Remark        |
|--------------|----------------|-------------------------------|---------------------------------------|--------------------|----------|---------------------|----------|----------------------------|----------------------------|
|              |                |                               |                                       | Horizontal         | Vertical | Horizontal          | Vertical |                            |                            |
| Canon        | EOS R6 Mark II | RF 15-30mm f/4.5-6.3 IS STM   | Standard quick release plate provided | √                  | -        | -                   | -        | -                          | Do not remove eyepiece cap |
|              |                | RF 16mm F2.8 STM              |                                       | √                  | -        | -                   | -        | -                          | Do not remove eyepiece cap |
|              |                | RF 24-105mm F4-7.1 IS STM     |                                       | √                  | -        | -                   | -        | -                          | Do not remove eyepiece cap |
|              |                | RF 24mm f/1.8 Macro IS STM    |                                       | √                  | -        | -                   | -        | -                          | Do not remove eyepiece cap |
|              |                | RF 35mm F1.8 MACRO IS STM     |                                       | √                  | -        | -                   | -        | -                          | Do not remove eyepiece cap |
|              |                | RF 50mm F1.8 STM              |                                       | √                  | -        | -                   | -        | -                          | Do not remove eyepiece cap |
|              |                | RF-S 18-45mm f/4.5-6.3 IS STM |                                       | √                  | -        | -                   | -        | -                          | Do not remove eyepiece cap |
|              |                | RF 24-50mm F4.5-6.3 IS STM    |                                       | √                  | -        | -                   | -        | -                          | Do not remove eyepiece cap |
|              | EOS R7         | RF 15-30mm f/4.5-6.3 IS STM   | Standard quick release plate provided | √                  | -        | -                   | -        | -                          | Do not remove eyepiece cap |
|              |                | RF 16mm F2.8 STM              |                                       | √                  | -        | -                   | -        | -                          | Do not remove eyepiece cap |
|              |                | RF 24-105mm F4-7.1 IS STM     |                                       | √                  | -        | -                   | -        | -                          | Do not remove eyepiece cap |
|              |                | RF 24mm f/1.8 Macro IS STM    |                                       | √                  | -        | -                   | -        | -                          | Do not remove eyepiece cap |
|              |                | RF 35mm F1.8 MACRO IS STM     |                                       | √                  | -        | -                   | -        | -                          | Do not remove eyepiece cap |
|              |                | RF 50mm F1.8 STM              |                                       | √                  | -        | -                   | -        | -                          | Do not remove eyepiece cap |
|              |                | RF-S 18-45mm f/4.5-6.3 IS STM |                                       | √                  | -        | -                   | -        | -                          | Do not remove eyepiece cap |
|              |                | RF 24-50mm F4.5-6.3 IS STM    |                                       | √                  | -        | -                   | -        | -                          | Do not remove eyepiece cap |



| Camera Brand | Model   | Lens Model                    | Mounting Status                       | Balance Adjustment |          | Camera Backing Base |          | Servo Zoom/<br>Focus Motor | Installation Remark        |
|--------------|---------|-------------------------------|---------------------------------------|--------------------|----------|---------------------|----------|----------------------------|----------------------------|
|              |         |                               |                                       | Horizontal         | Vertical | Horizontal          | Vertical |                            |                            |
| Canon        | EOS R8  | RF 15-30mm f/4.5-6.3 IS STM   | Standard quick release plate provided | √                  | -        | -                   | -        | -                          | Do not remove eyepiece cap |
|              |         | RF 16mm F2.8 STM              |                                       | √                  | -        | -                   | -        | -                          | Do not remove eyepiece cap |
|              |         | RF 24-105mm F4-7.1 IS STM     |                                       | √                  | -        | -                   | -        | -                          | Do not remove eyepiece cap |
|              |         | RF 24mm f/1.8 Macro IS STM    |                                       | √                  | -        | -                   | -        | -                          | Do not remove eyepiece cap |
|              |         | RF 35mm F1.8 MACRO IS STM     |                                       | √                  | -        | -                   | -        | -                          | Do not remove eyepiece cap |
|              |         | RF 50mm F1.8 STM              |                                       | √                  | -        | -                   | -        | -                          | Do not remove eyepiece cap |
|              |         | RF-S 18-45mm f/4.5-6.3 IS STM |                                       | √                  | -        | -                   | -        | -                          | Do not remove eyepiece cap |
|              |         | RF 24-50mm F4.5-6.3 IS STM    |                                       | √                  | -        | -                   | -        | -                          | Do not remove eyepiece cap |
|              | EOS R10 | RF 15-30mm f/4.5-6.3 IS STM   | Standard quick release plate provided | √                  | -        | -                   | -        | -                          | Do not remove eyepiece cap |
|              |         | RF 16mm F2.8 STM              |                                       | √                  | -        | -                   | -        | -                          | Do not remove eyepiece cap |
|              |         | RF 24-105mm F4-7.1 IS STM     |                                       | √                  | -        | -                   | -        | -                          | Do not remove eyepiece cap |
|              |         | RF 24mm f/1.8 Macro IS STM    |                                       | √                  | -        | -                   | -        | -                          | Do not remove eyepiece cap |
|              |         | RF 35mm F1.8 MACRO IS STM     |                                       | √                  | -        | -                   | -        | -                          | Do not remove eyepiece cap |
|              |         | RF 50mm F1.8 STM              |                                       | √                  | -        | -                   | -        | -                          | Do not remove eyepiece cap |
|              |         | RF-S 18-45mm f/4.5-6.3 IS STM |                                       | √                  | -        | -                   | -        | -                          | Do not remove eyepiece cap |
|              |         | RF 24-50mm F4.5-6.3 IS STM    |                                       | √                  | -        | -                   | -        | -                          | Do not remove eyepiece cap |
|              | EOS R50 | RF 15-30mm f/4.5-6.3 IS STM   | Standard quick release plate provided | √                  | -        | -                   | -        | -                          | Do not remove eyepiece cap |
|              |         | RF 16mm F2.8 STM              |                                       | √                  | -        | -                   | -        | -                          | Do not remove eyepiece cap |
|              |         | RF 24-105mm F4-7.1 IS STM     |                                       | √                  | -        | -                   | -        | -                          | Do not remove eyepiece cap |
|              |         | RF 24mm f/1.8 Macro IS STM    |                                       | √                  | -        | -                   | -        | -                          | Do not remove eyepiece cap |
|              |         | RF 35mm F1.8 MACRO IS STM     |                                       | √                  | -        | -                   | -        | -                          | Do not remove eyepiece cap |
|              |         | RF 50mm F1.8 STM              |                                       | √                  | -        | -                   | -        | -                          | Do not remove eyepiece cap |
|              |         | RF-S 18-45mm f/4.5-6.3 IS STM |                                       | √                  | -        | -                   | -        | -                          | Do not remove eyepiece cap |
|              |         | RF 24-50mm F4.5-6.3 IS STM    |                                       | √                  | -        | -                   | -        | -                          | Do not remove eyepiece cap |



| Camera Brand                   | Model       | Lens Model                     | Mounting Status                       | Balance Adjustment |          | Camera Backing Base |          | Servo Zoom/<br>Focus Motor                             | Installation Remark   |
|--------------------------------|-------------|--------------------------------|---------------------------------------|--------------------|----------|---------------------|----------|--|---|
|                                |             |                                |                                       | Horizontal         | Vertical | Horizontal          | Vertical |  |   |
| Canon                          | EOS RP      | RF 15-30mm f/4.5-6.3 IS STM    | Standard quick release plate provided | √                  | -        | -                   | -        | -  | Do not remove eyepiece cap                                      |
|                                |             | RF 16mm F2.8 STM               |                                       | √                  | -        | -                   | -        | -  | Do not remove eyepiece cap                                      |
|                                |             | RF 24-105mm F4-7.1 IS STM      |                                       | √                  | -        | -                   | -        | -  | Do not remove eyepiece cap                                      |
|                                |             | RF 24mm f/1.8 Macro IS STM     |                                       | √                  | -        | -                   | -        | -  | Do not remove eyepiece cap                                      |
|                                |             | RF 35mm F1.8 MACRO IS STM      |                                       | √                  | -        | -                   | -        | -  | Do not remove eyepiece cap                                      |
|                                |             | RF 50mm F1.8 STM               |                                       | √                  | -        | -                   | -        | -  | Do not remove eyepiece cap                                      |
|                                |             | RF-S 18-45mm f/4.5-6.3 IS STM  |                                       | √                  | -        | -                   | -        | -  | Do not remove eyepiece cap                                      |
|                                |             | RF 24-50mm F4.5-6.3 IS STM     |                                       | √                  | -        | -                   | -        | -  | Do not remove eyepiece cap                                      |
|                                | EOS M50     | EF-M 22mm f/2 STM              | Standard quick release plate provided | √                  | -        | -                   | -        | -  | Do not remove eyepiece cap                                      |
|                                |             | EF-M 28mm f/3.5 IS STM         |                                       | √                  | -        | -                   | -        | -  | Do not remove eyepiece cap                                      |
|                                |             | EF-M 32mm f/1.4 STM            |                                       | √                  | -        | -                   | -        | -  | Do not remove eyepiece cap                                      |
|                                |             | EF-M 11-22mm f/4-5.6 IS STM    |                                       | √                  | -        | -                   | -        | -  | Can be balanced at any focal length, do not remove eyepiece cap |
|                                |             | EF-M 15-45mm f/3.5-6.3 IS STM  |                                       | √                  | -        | -                   | -        | -  | Can be balanced at any focal length, do not remove eyepiece cap |
|                                |             | EF-M 18-55mm f/3.5-5.6 IS STM  |                                       | √                  | -        | -                   | -        | -  | Can be balanced at any focal length, do not remove eyepiece cap |
|                                |             | EF-M 18-150mm f/3.5-6.3 IS STM |                                       | √                  | -        | -                   | -        | -  | Can be balanced at 18-50mm, do not remove eyepiece cap          |
|                                | M50 Mark II | EF-M 22mm f/2 STM              | Standard quick release plate provided | √                  | -        | -                   | -        | -  | Do not remove eyepiece cap                                      |
|                                |             | EF-M 28mm f/3.5 IS STM         |                                       | √                  | -        | -                   | -        | -  | Do not remove eyepiece cap                                      |
|                                |             | EF-M 32mm f/1.4 STM            |                                       | √                  | -        | -                   | -        | -  | Do not remove eyepiece cap                                      |
|                                |             | EF-M 11-22mm f/4-5.6 IS STM    |                                       | √                  | -        | -                   | -        | -  | Can be balanced at any focal length, do not remove eyepiece cap |
|                                |             | EF-M 15-45mm f/3.5-6.3 IS STM  |                                       | √                  | -        | -                   | -        | -  | Can be balanced at any focal length, do not remove eyepiece cap |
|                                |             | EF-M 18-55mm f/3.5-5.6 IS STM  |                                       | √                  | -        | -                   | -        | -  | Can be balanced at any focal length, do not remove eyepiece cap |
| EF-M 18-150mm f/3.5-6.3 IS STM |             | √                              |                                       | -                  | -        | -                   | -        | Can be balanced at 18-50mm, do not remove eyepiece cap |   |



| Camera Brand                  | Model          | Lens Model                     | Mounting Status                       | Balance Adjustment |          | Camera Backing Base |          | Servo Zoom/<br>Focus Motor  | Installation Remark   |
|-------------------------------|----------------|--------------------------------|---------------------------------------|--------------------|----------|---------------------|----------|---|---|
|                               |                |                                |                                       | Horizontal         | Vertical | Horizontal          | Vertical |   |   |
| Canon                         | EOS M6         | EF-M 22mm f/2 STM              | Standard quick release plate provided | √                  | -        | -                   | -        | -   | -   |
|                               |                | EF-M 28mm f/3.5 IS STM         |                                       | √                  | -        | -                   | -        | -   | -   |
|                               |                | EF-M 32mm f/1.4 STM            |                                       | √                  | -        | -                   | -        | -   | -   |
|                               |                | EF-M 11-22mm f/4-5.6 IS STM    |                                       | √                  | -        | -                   | -        | -   | Can be balanced at any focal length                                 |
|                               |                | EF-M 15-45mm f/3.5-6.3 IS STM  |                                       | √                  | -        | -                   | -        | -   | Can be balanced at any focal length                                 |
|                               |                | EF-M 18-55mm f/3.5-5.6 IS STM  |                                       | √                  | -        | -                   | -        | -   | Can be balanced at any focal length                                 |
|                               |                | EF-M 18-150mm f/3.5-6.3 IS STM |                                       | √                  | -        | -                   | -        | -   | Can be balanced at any focal length                                 |
|                               | EOS M6 Mark II | EF-M 22mm f/2 STM              | Standard quick release plate provided | √                  | -        | -                   | -        | -   | -   |
|                               |                | EF-M 28mm f/3.5 IS STM         |                                       | √                  | -        | -                   | -        | -   | -   |
|                               |                | EF-M 32mm f/1.4 STM            |                                       | √                  | -        | -                   | -        | -   | -   |
|                               |                | EF-M 11-22mm f/4-5.6 IS STM    |                                       | √                  | -        | -                   | -        | -   | Can be balanced at any focal length                                 |
|                               |                | EF-M 15-45mm f/3.5-6.3 IS STM  |                                       | √                  | -        | -                   | -        | -   | Can be balanced at any focal length                                 |
|                               |                | EF-M 18-55mm f/3.5-5.6 IS STM  |                                       | √                  | -        | -                   | -        | -   | Can be balanced at any focal length                                 |
|                               |                | EF-M 18-150mm f/3.5-6.3 IS STM |                                       | √                  | -        | -                   | -        | -   | Can be balanced at any focal length                                 |
|                               | EOS 200D       | EF 24mm f/2.8 IS USM           | Standard quick release plate provided | √                  | -        | -                   | -        | -   | No need to remove eyepiece cap                                      |
|                               |                | EF-S 24mm f/2.8 STM            |                                       | √                  | -        | -                   | -        | -   | No need to remove eyepiece cap                                      |
|                               |                | EF 35mm f/2 IS USM             |                                       | √                  | -        | -                   | -        | -   | No need to remove eyepiece cap                                      |
|                               |                | EF-S 35mm f/2.8 IS STM MC      |                                       | √                  | -        | -                   | -        | -   | No need to remove eyepiece cap                                      |
|                               |                | EF 50mm f/1.4 USM              |                                       | √                  | -        | -                   | -        | -   | No need to remove eyepiece cap                                      |
|                               |                | EF 50mm f/1.8 STM              |                                       | √                  | -        | -                   | -        | -   | No need to remove eyepiece cap                                      |
|                               |                | EF-S 10-18mm f/4.5-5.6 IS STM  |                                       | √                  | -        | -                   | -        | -   | Can be balanced at any focal length, no need to remove eyepiece cap |
| EF-S 18-55mm f/3.5-5.6 IS STM |                | √                              |                                       | -                  | -        | -                   | -        | Can be balanced at any focal length, no need to remove eyepiece cap |   |
| EF-S 18-55mm f/4-5.6 IS STM   |                | √                              |                                       | -                  | -        | -                   | -        | Can be balanced at any focal length, no need to remove eyepiece cap |   |



| Camera Brand | Model                       | Lens Model                        | Mounting Status                          | Balance Adjustment |          | Camera Backing Base |   | Servo Zoom/<br>Focus Motor | Installation Remark   |
|--------------|-----------------------------|-----------------------------------|--|--------------------|----------|---------------------|---|----------------------------|---|
|              |                             |                                   |  | Horizontal         | Vertical | Horizontal          | Vertical  |                            |   |
| Canon        | EOS 200D<br>Mark II         | EF 24mm f/2.8 IS USM              | Standard quick release<br>plate provided | √                  | -        | -                   | -   | -                          | No need to remove eyepiece cap                                      |
|              |                             | EF-S 24mm f/2.8 STM               |  | √                  | -        | -                   | -   | -                          | No need to remove eyepiece cap                                      |
|              |                             | EF 35mm f/2 IS USM                |  | √                  | -        | -                   | -   | -                          | No need to remove eyepiece cap                                      |
|              |                             | EF-S 35mm f/2.8 IS STM MC         |  | √                  | -        | -                   | -   | -                          | No need to remove eyepiece cap                                      |
|              |                             | EF 50mm f/1.4 USM                 |  | √                  | -        | -                   | -   | -                          | No need to remove eyepiece cap                                      |
|              |                             | EF 50mm f/1.8 STM                 |  | √                  | -        | -                   | -   | -                          | No need to remove eyepiece cap                                      |
|              |                             | EF-S 10-18mm f/4.5-5.6 IS STM     |  | √                  | -        | -                   | -   | -                          | Can be balanced at any focal length, no need to remove eyepiece cap |
|              |                             | EF-S 18-55mm f/3.5-5.6 IS STM     |  | √                  | -        | -                   | -   | -                          | Can be balanced at any focal length, no need to remove eyepiece cap |
|              | EF-S 18-55mm f/4-5.6 IS STM | √                                 | -  | -                  | -        | -                   | Can be balanced at any focal length, no need to remove eyepiece cap |                            |   |
|              | PowerShot<br>G1X Mark II    | Comes with the lens               | Standard quick release<br>plate provided | √                  | -        | -                   | -   | -                          | Should be powered on to balance                                     |
|              | PowerShot<br>G7X Mark III   | Comes with the lens               | Standard quick release<br>plate provided | √                  | -        | -                   | -   | -                          | Should be powered on to balance                                     |
|              | PowerShot<br>SX720 HS       | Comes with the lens               | Standard quick release<br>plate provided | √                  | -        | -                   | -   | -                          | Should be powered on to balance                                     |
| Nikon        | Z30                         | NIKKOR Z 28mm f/2.8 (SE)          | Standard quick release<br>plate provided | √                  | -        | -                   | -   | -                          | -   |
|              |                             | NIKKOR Z 35mm f/1.8S              |  | √                  | -        | -                   | -   | -                          | -   |
|              |                             | NIKKOR Z 40mm f/2                 |  | √                  | -        | -                   | -   | -                          | -   |
|              |                             | NIKKOR Z 50mm f/1.8S              |  | √                  | -        | -                   | -   | -                          | -   |
|              |                             | NIKKOR Z MC 50mm f/2.8            |  | √                  | -        | -                   | -   | -                          | -   |
|              |                             | NIKKOR Z DX 16-50mm f/3.5-6.3 VR  |  | √                  | -        | -                   | -   | -                          | Can be balanced at any focal length, no need to remove eyepiece cap |
|              |                             | NIKKOR Z 24-50mm f/4-6.3          |  | √                  | -        | -                   | -   | -                          | Can be balanced at any focal length, no need to remove eyepiece cap |
|              |                             | NIKKOR Z DX 18-140mm f/3.5-6.3 VR |  | √                  | -        | -                   | -   | -                          | Can be balanced at 18-50mm, No need to remove eyepiece cap          |



| Camera Brand | Model | Lens Model                       | Mounting Status                       | Balance Adjustment |          | Camera Backing Base |          | Servo Zoom/<br>Focus Motor | Installation Remark   |
|--------------|-------|----------------------------------|---------------------------------------|--------------------|----------|---------------------|----------|----------------------------|---|
|              |       |                                  |                                       | Horizontal         | Vertical | Horizontal          | Vertical |                            |   |
| Nikon        | Z50   | NIKKOR Z 28mm f/2.8 (SE)         | Standard quick release plate provided | √                  | -        | -                   | -        | -                          | -   |
|              |       | NIKKOR Z 35mm f/1.8S             |                                       | √                  | -        | -                   | -        | -                          | -   |
|              |       | NIKKOR Z 40mm f/2                |                                       | √                  | -        | -                   | -        | -                          | -   |
|              |       | NIKKOR Z 50mm f/1.8S             |                                       | √                  | -        | -                   | -        | -                          | -   |
|              |       | NIKKOR Z MC 50mm f/2.8           |                                       | √                  | -        | -                   | -        | -                          | -   |
|              |       | NIKKOR Z DX 16-50mm f/3.5-6.3 VR |                                       | √                  | -        | -                   | -        | -                          | Can be balanced at any focal length, no need to remove eyepiece cap |
|              |       | NIKKOR Z 24-50mm f/4-6.3         |                                       | √                  | -        | -                   | -        | -                          | Can be balanced at any focal length, no need to remove eyepiece cap |
|              | Z5    | NIKKOR Z 28mm f/2.8 (SE)         | Standard quick release plate provided | √                  | -        | -                   | -        | -                          | -   |
|              |       | NIKKOR Z 35mm f/1.8S             |                                       | √                  | -        | -                   | -        | -                          | -   |
|              |       | NIKKOR Z 40mm f/2                |                                       | √                  | -        | -                   | -        | -                          | -   |
|              |       | NIKKOR Z 50mm f/1.8S             |                                       | √                  | -        | -                   | -        | -                          | -   |
|              |       | NIKKOR Z MC 50mm f/2.8           |                                       | √                  | -        | -                   | -        | -                          | -   |
|              |       | NIKKOR Z DX 16-50mm f/3.5-6.3 VR |                                       | √                  | -        | -                   | -        | -                          | Can be balanced at any focal length, no need to remove eyepiece cap |
|              |       | NIKKOR Z 24-50mm f/4-6.3         |                                       | √                  | -        | -                   | -        | -                          | Can be balanced at any focal length, no need to remove eyepiece cap |
|              | Z6    | NIKKOR Z 28mm f/2.8 (SE)         | Standard quick release plate provided | √                  | -        | -                   | -        | -                          | -   |
|              |       | NIKKOR Z 35mm f/1.8S             |                                       | √                  | -        | -                   | -        | -                          | -   |
|              |       | NIKKOR Z 40mm f/2                |                                       | √                  | -        | -                   | -        | -                          | -   |
|              |       | NIKKOR Z 50mm f/1.8S             |                                       | √                  | -        | -                   | -        | -                          | -   |
|              |       | NIKKOR Z MC 50mm f/2.8           |                                       | √                  | -        | -                   | -        | -                          | -   |
|              |       | NIKKOR Z DX 16-50mm f/3.5-6.3 VR |                                       | √                  | -        | -                   | -        | -                          | Can be balanced at any focal length, no need to remove eyepiece cap |
|              |       | NIKKOR Z 24-50mm f/4-6.3         |                                       | √                  | -        | -                   | -        | -                          | Can be balanced at any focal length, no need to remove eyepiece cap |





| Camera Brand | Model | Lens Model                       | Mounting Status                       | Balance Adjustment |          | Camera Backing Base |          | Servo Zoom/<br>Focus Motor | Installation Remark   |
|--------------|-------|----------------------------------|---------------------------------------|--------------------|----------|---------------------|----------|----------------------------|---|
|              |       |                                  |                                       | Horizontal         | Vertical | Horizontal          | Vertical |                            |   |
| Nikon        | Z6 II | NIKKOR Z 28mm f/2.8 (SE)         | Standard quick release plate provided | √                  | -        | -                   | -        | -                          | -   |
|              |       | NIKKOR Z 35mm f/1.8S             |                                       | √                  | -        | -                   | -        | -                          | -   |
|              |       | NIKKOR Z 40mm f/2                |                                       | √                  | -        | -                   | -        | -                          | -   |
|              |       | NIKKOR Z 50mm f/1.8S             |                                       | √                  | -        | -                   | -        | -                          | -   |
|              |       | NIKKOR Z MC 50mm f/2.8           |                                       | √                  | -        | -                   | -        | -                          | -   |
|              |       | NIKKOR Z DX 16-50mm f/3.5-6.3 VR |                                       | √                  | -        | -                   | -        | -                          | Can be balanced at any focal length, no need to remove eyepiece cap |
|              |       | NIKKOR Z 24-50mm f/4-6.3         |                                       | √                  | -        | -                   | -        | -                          | Can be balanced at any focal length, no need to remove eyepiece cap |
|              | Z7    | NIKKOR Z 28mm f/2.8 (SE)         | Standard quick release plate provided | √                  | -        | -                   | -        | -                          | -   |
|              |       | NIKKOR Z 35mm f/1.8S             |                                       | √                  | -        | -                   | -        | -                          | -   |
|              |       | NIKKOR Z 40mm f/2                |                                       | √                  | -        | -                   | -        | -                          | -   |
|              |       | NIKKOR Z 50mm f/1.8S             |                                       | √                  | -        | -                   | -        | -                          | -   |
|              |       | NIKKOR Z MC 50mm f/2.8           |                                       | √                  | -        | -                   | -        | -                          | -   |
|              |       | NIKKOR Z DX 16-50mm f/3.5-6.3 VR |                                       | √                  | -        | -                   | -        | -                          | Can be balanced at any focal length, no need to remove eyepiece cap |
|              |       | NIKKOR Z 24-50mm f/4-6.3         |                                       | √                  | -        | -                   | -        | -                          | Can be balanced at any focal length, no need to remove eyepiece cap |
|              | Z7 II | NIKKOR Z 28mm f/2.8 (SE)         | Standard quick release plate provided | √                  | -        | -                   | -        | -                          | -   |
|              |       | NIKKOR Z 35mm f/1.8S             |                                       | √                  | -        | -                   | -        | -                          | -   |
|              |       | NIKKOR Z 40mm f/2                |                                       | √                  | -        | -                   | -        | -                          | -   |
|              |       | NIKKOR Z 50mm f/1.8S             |                                       | √                  | -        | -                   | -        | -                          | -   |
|              |       | NIKKOR Z MC 50mm f/2.8           |                                       | √                  | -        | -                   | -        | -                          | -   |
|              |       | NIKKOR Z DX 16-50mm f/3.5-6.3 VR |                                       | √                  | -        | -                   | -        | -                          | Can be balanced at any focal length, no need to remove eyepiece cap |
|              |       | NIKKOR Z 24-50mm f/4-6.3         |                                       | √                  | -        | -                   | -        | -                          | Can be balanced at any focal length, no need to remove eyepiece cap |



| Camera Brand | Model | Lens Model                        | Mounting Status                       | Balance Adjustment |          | Camera Backing Base |          | Servo Zoom/<br>Focus Motor | Installation Remark   |
|--------------|-------|-----------------------------------|---------------------------------------|--------------------|----------|---------------------|----------|----------------------------|---|
|              |       |                                   |                                       | Horizontal         | Vertical | Horizontal          | Vertical |                            |   |
| Nikon        | Zfc   | NIKKOR Z 35mm f/1.8S              | Standard quick release plate provided | √                  | -        | -                   | -        | -                          | -   |
|              |       | NIKKOR Z 28mm f/2.8 (SE)          |                                       | √                  | -        | -                   | -        | -                          | -   |
|              |       | NIKKOR Z 40mm f/2                 |                                       | √                  | -        | -                   | -        | -                          | -   |
|              |       | NIKKOR Z 50mm f/1.8S              |                                       | √                  | -        | -                   | -        | -                          | -   |
|              |       | NIKKOR Z MC 50mm f/2.8            |                                       | √                  | -        | -                   | -        | -                          | -   |
|              |       | NIKKOR Z DX 16-50mm f/3.5-6.3 VR  |                                       | √                  | -        | -                   | -        | -                          | Can be balanced at any focal length, no need to remove eyepiece cap |
|              |       | NIKKOR Z 24-50mm f/4-6.3          |                                       | √                  | -        | -                   | -        | -                          | Can be balanced at any focal length, no need to remove eyepiece cap |
|              |       | NIKKOR Z DX 18-140mm f/3.5-6.3 VR |                                       | √                  | -        | -                   | -        | -                          | Can be balanced at 18-50mm, No need to remove eyepiece cap          |
|              | Zf    | NIKKOR Z 28mm f/2.8 (SE)          |                                       | √                  | -        | -                   | -        | -                          | -   |
|              |       | NIKKOR Z 35mm f/1.8S              |                                       | √                  | -        | -                   | -        | -                          | -   |
|              |       | NIKKOR Z 40mm f/2                 |                                       | √                  | -        | -                   | -        | -                          | -   |
|              |       | NIKKOR Z 50mm f/1.8S              |                                       | √                  | -        | -                   | -        | -                          | -   |
|              |       | NIKKOR Z MC 50mm f/2.8            |                                       | √                  | -        | -                   | -        | -                          | -   |
|              |       | NIKKOR Z DX 16-50mm f/3.5-6.3 VR  |                                       | √                  | -        | -                   | -        | -                          | Can be balanced at any focal length, no need to remove eyepiece cap |
|              |       | NIKKOR Z 24-50mm f/4-6.3          |                                       | √                  | -        | -                   | -        | -                          | Can be balanced at any focal length, no need to remove eyepiece cap |



| Camera Brand             | Model | Lens Model               | Mounting Status                       | Balance Adjustment |          | Camera Backing Base  |          | Servo Zoom/<br>Focus Motor | Installation Remark  |
|--------------------------|-------|--------------------------|---------------------------------------|--------------------|----------|--|----------|----------------------------|--|
|                          |       |                          |                                       | Horizontal         | Vertical | Horizontal   | Vertical |                            |  |
| FUJIFILM                 | X-T20 | XF14mmF2.8 R             | Standard quick release plate provided | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF16mmF1.4 R WR          |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF16mmF2.8 R WR          |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF18mmF1.4 R LM WR       |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF18mmF2 R               |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF23mmF1.4 R             |                                       | √                  | -        | -  | -        | -                          | Need to remove eyepiece cap                                      |
|                          |       | XF23mmF1.4 R LM WR       |                                       | √                  | -        | -  | -        | -                          | Need to remove eyepiece cap                                      |
|                          |       | XF23mmF2 R WR            |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF27mmF2.8               |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF30mmF2.8 R LM WR Macro |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF33mmF1.4 R LM WR       |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XC35mmF2                 |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF 35mm f/1.4 R          |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF 35mm f/2 R WR         |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF50mmF2 R WR            |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF56mmF1.2 R WR          |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF56mmF1.2 R APD         |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF60mmF2.4 R Macro       |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF10-24mmF4 R OIS WR     |                                       | √                  | -        | -  | -        | -                          | Can be balanced at any focal length, need to remove eyepiece cap |
|                          |       | XC 15-45mm f/3.5-5.6 OIS |                                       | √                  | -        | -  | -        | -                          | Can be balanced at any focal length, need to remove eyepiece cap |
| XC16-50mmF3.5-5.6 OIS II | √     | -                        | -                                     | -                  | -        | Can be balanced at any focal length, need to remove eyepiece cap |          |                            |  |
| XF 18-55mm f/2.8-4 R OIS | √     | -                        | -                                     | -                  | -        | Can be balanced at any focal length, need to remove eyepiece cap |          |                            |  |
| XF16-80mmF4 R OIS WR     | √     | -                        | -                                     | -                  | -        | Can be balanced at any focal length, need to remove eyepiece cap |          |                            |  |



| Camera Brand             | Model | Lens Model               | Mounting Status                       | Balance Adjustment |          | Camera Backing Base  |          | Servo Zoom/<br>Focus Motor | Installation Remark  |
|--------------------------|-------|--------------------------|---------------------------------------|--------------------|----------|--|----------|----------------------------|--|
|                          |       |                          |                                       | Horizontal         | Vertical | Horizontal   | Vertical |                            |  |
| FUJIFILM                 | X-A7  | XF14mmF2.8 R             | Standard quick release plate provided | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF16mmF1.4 R WR          |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF16mmF2.8 R WR          |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF18mmF1.4 R LM WR       |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF18mmF2 R               |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF23mmF1.4 R             |                                       | √                  | -        | -  | -        | -                          | Need to remove eyepiece cap                                      |
|                          |       | XF23mmF1.4 R LM WR       |                                       | √                  | -        | -  | -        | -                          | Need to remove eyepiece cap                                      |
|                          |       | XF23mmF2 R WR            |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF27mmF2.8               |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF30mmF2.8 R LM WR Macro |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF33mmF1.4 R LM WR       |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XC35mmF2                 |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF 35mm f/1.4 R          |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF 35mm f/2 R WR         |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF50mmF2 R WR            |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF56mmF1.2 R WR          |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF56mmF1.2 R APD         |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF60mmF2.4 R Macro       |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF10-24mmF4 R OIS WR     |                                       | √                  | -        | -  | -        | -                          | Can be balanced at any focal length, need to remove eyepiece cap |
|                          |       | XC 15-45mm f/3.5-5.6 OIS |                                       | √                  | -        | -  | -        | -                          | Can be balanced at any focal length, need to remove eyepiece cap |
|                          |       | XC16-50mmF3.5-5.6 OIS II |                                       | √                  | -        | -  | -        | -                          | Can be balanced at any focal length, need to remove eyepiece cap |
| XF 18-55mm f/2.8-4 R OIS | √     | -                        | -                                     | -                  | -        | Can be balanced at any focal length, need to remove eyepiece cap |          |                            |  |
| XF16-80mmF4 R OIS WR     | √     | -                        | -                                     | -                  | -        | Can be balanced at any focal length, need to remove eyepiece cap |          |                            |  |



| Camera Brand             | Model | Lens Model               | Mounting Status                       | Balance Adjustment |          | Camera Backing Base  |          | Servo Zoom/<br>Focus Motor | Installation Remark  |
|--------------------------|-------|--------------------------|---------------------------------------|--------------------|----------|--|----------|----------------------------|--|
|                          |       |                          |                                       | Horizontal         | Vertical | Horizontal   | Vertical |                            |  |
| FUJIFILM                 | X-T2  | XF14mmF2.8 R             | Standard quick release plate provided | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF16mmF1.4 R WR          |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF16mmF2.8 R WR          |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF18mmF1.4 R LM WR       |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF18mmF2 R               |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF23mmF1.4 R             |                                       | √                  | -        | -  | -        | -                          | Need to remove eyepiece cap                                      |
|                          |       | XF23mmF1.4 R LM WR       |                                       | √                  | -        | -  | -        | -                          | Need to remove eyepiece cap                                      |
|                          |       | XF23mmF2 R WR            |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF27mmF2.8               |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF30mmF2.8 R LM WR Macro |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF33mmF1.4 R LM WR       |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XC35mmF2                 |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF 35mm f/1.4 R          |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF 35mm f/2 R WR         |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF50mmF2 R WR            |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF56mmF1.2 R WR          |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF56mmF1.2 R APD         |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF60mmF2.4 R Macro       |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF10-24mmF4 R OIS WR     |                                       | √                  | -        | -  | -        | -                          | Can be balanced at any focal length, need to remove eyepiece cap |
|                          |       | XC 15-45mm f/3.5-5.6 OIS |                                       | √                  | -        | -  | -        | -                          | Can be balanced at any focal length, need to remove eyepiece cap |
| XC16-50mmF3.5-5.6 OIS II | √     | -                        | -                                     | -                  | -        | Can be balanced at any focal length, need to remove eyepiece cap |          |                            |  |
| XF 18-55mm f/2.8-4 R OIS | √     | -                        | -                                     | -                  | -        | Can be balanced at any focal length, need to remove eyepiece cap |          |                            |  |
| XF16-80mmF4 R OIS WR     | √     | -                        | -                                     | -                  | -        | Can be balanced at any focal length, need to remove eyepiece cap |          |                            |  |



| Camera Brand             | Model | Lens Model               | Mounting Status                       | Balance Adjustment |          | Camera Backing Base  |          | Servo Zoom/<br>Focus Motor | Installation Remark  |
|--------------------------|-------|--------------------------|---------------------------------------|--------------------|----------|--|----------|----------------------------|--|
|                          |       |                          |                                       | Horizontal         | Vertical | Horizontal   | Vertical |                            |  |
| FUJIFILM                 | X-T3  | XF14mmF2.8 R             | Standard quick release plate provided | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF16mmF1.4 R WR          |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF16mmF2.8 R WR          |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF18mmF1.4 R LM WR       |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF18mmF2 R               |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF23mmF1.4 R             |                                       | √                  | -        | -  | -        | -                          | Need to remove eyepiece cap                                      |
|                          |       | XF23mmF1.4 R LM WR       |                                       | √                  | -        | -  | -        | -                          | Need to remove eyepiece cap                                      |
|                          |       | XF23mmF2 R WR            |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF27mmF2.8               |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF30mmF2.8 R LM WR Macro |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF33mmF1.4 R LM WR       |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XC35mmF2                 |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF 35mm f/1.4 R          |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF 35mm f/2 R WR         |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF50mmF2 R WR            |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF56mmF1.2 R WR          |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF56mmF1.2 RAPD          |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF60mmF2.4 R Macro       |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF10-24mmF4 R OIS WR     |                                       | √                  | -        | -  | -        | -                          | Can be balanced at any focal length, need to remove eyepiece cap |
|                          |       | XC 15-45mm f/3.5-5.6 OIS |                                       | √                  | -        | -  | -        | -                          | Can be balanced at any focal length, need to remove eyepiece cap |
| XC16-50mmF3.5-5.6 OIS II | √     | -                        | -                                     | -                  | -        | Can be balanced at any focal length, need to remove eyepiece cap |          |                            |  |
| XF 18-55mm f/2.8-4 R OIS | √     | -                        | -                                     | -                  | -        | Can be balanced at any focal length, need to remove eyepiece cap |          |                            |  |
| XF16-80mmF4 R OIS WR     | √     | -                        | -                                     | -                  | -        | Can be balanced at any focal length, need to remove eyepiece cap |          |                            |  |



| Camera Brand             | Model | Lens Model               | Mounting Status                       | Balance Adjustment |          | Camera Backing Base  |          | Servo Zoom/<br>Focus Motor | Installation Remark  |
|--------------------------|-------|--------------------------|---------------------------------------|--------------------|----------|--|----------|----------------------------|--|
|                          |       |                          |                                       | Horizontal         | Vertical | Horizontal   | Vertical |                            |  |
| FUJIFILM                 | X-T4  | XF14mmF2.8 R             | Standard quick release plate provided | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF16mmF1.4 R WR          |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF16mmF2.8 R WR          |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF18mmF1.4 R LM WR       |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF18mmF2 R               |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF23mmF1.4 R             |                                       | √                  | -        | -  | -        | -                          | Need to remove eyepiece cap                                      |
|                          |       | XF23mmF1.4 R LM WR       |                                       | √                  | -        | -  | -        | -                          | Need to remove eyepiece cap                                      |
|                          |       | XF23mmF2 R WR            |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF27mmF2.8               |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF30mmF2.8 R LM WR Macro |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF33mmF1.4 R LM WR       |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XC35mmF2                 |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF 35mm f/1.4 R          |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF 35mm f/2 R WR         |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF50mmF2 R WR            |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF56mmF1.2 R WR          |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF56mmF1.2 R APD         |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF60mmF2.4 R Macro       |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF10-24mmF4 R OIS WR     |                                       | √                  | -        | -  | -        | -                          | Can be balanced at any focal length, need to remove eyepiece cap |
|                          |       | XC 15-45mm f/3.5-5.6 OIS |                                       | √                  | -        | -  | -        | -                          | Can be balanced at any focal length, need to remove eyepiece cap |
|                          |       | XC16-50mmF3.5-5.6 OIS II |                                       | √                  | -        | -  | -        | -                          | Can be balanced at any focal length, need to remove eyepiece cap |
| XF 18-55mm f/2.8-4 R OIS | √     | -                        | -                                     | -                  | -        | Can be balanced at any focal length, need to remove eyepiece cap |          |                            |  |
| XF16-80mmF4 R OIS WR     | √     | -                        | -                                     | -                  | -        | Can be balanced at any focal length, need to remove eyepiece cap |          |                            |  |



| Camera Brand             | Model | Lens Model               | Mounting Status                       | Balance Adjustment |          | Camera Backing Base  |          | Servo Zoom/<br>Focus Motor | Installation Remark  |
|--------------------------|-------|--------------------------|---------------------------------------|--------------------|----------|--|----------|----------------------------|--|
|                          |       |                          |                                       | Horizontal         | Vertical | Horizontal   | Vertical |                            |  |
| FUJIFILM                 | X-T5  | XF14mmF2.8 R             | Standard quick release plate provided | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF16mmF1.4 R WR          |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF16mmF2.8 R WR          |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF18mmF1.4 R LM WR       |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF18mmF2 R               |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF23mmF1.4 R             |                                       | √                  | -        | -  | -        | -                          | Need to remove eyepiece cap                                      |
|                          |       | XF23mmF1.4 R LM WR       |                                       | √                  | -        | -  | -        | -                          | Need to remove eyepiece cap                                      |
|                          |       | XF23mmF2 R WR            |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF27mmF2.8               |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF30mmF2.8 R LM WR Macro |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF33mmF1.4 R LM WR       |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XC35mmF2                 |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF 35mm f/1.4 R          |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF 35mm f/2 R WR         |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF50mmF2 R WR            |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF56mmF1.2 R WR          |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF56mmF1.2 R APD         |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF60mmF2.4 R Macro       |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF10-24mmF4 R OIS WR     |                                       | √                  | -        | -  | -        | -                          | Can be balanced at any focal length, need to remove eyepiece cap |
|                          |       | XC 15-45mm f/3.5-5.6 OIS |                                       | √                  | -        | -  | -        | -                          | Can be balanced at any focal length, need to remove eyepiece cap |
|                          |       | XC16-50mmF3.5-5.6 OIS II |                                       | √                  | -        | -  | -        | -                          | Can be balanced at any focal length, need to remove eyepiece cap |
| XF 18-55mm f/2.8-4 R OIS | √     | -                        | -                                     | -                  | -        | Can be balanced at any focal length, need to remove eyepiece cap |          |                            |  |
| XF16-80mmF4 R OIS WR     | √     | -                        | -                                     | -                  | -        | Can be balanced at any focal length, need to remove eyepiece cap |          |                            |  |





| Camera Brand             | Model | Lens Model               | Mounting Status                       | Balance Adjustment |          | Camera Backing Base  |          | Servo Zoom/<br>Focus Motor | Installation Remark  |
|--------------------------|-------|--------------------------|---------------------------------------|--------------------|----------|--|----------|----------------------------|--|
|                          |       |                          |                                       | Horizontal         | Vertical | Horizontal   | Vertical |                            |  |
| FUJIFILM                 | X-H2s | XF14mmF2.8 R             | Standard quick release plate provided | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF16mmF1.4 R WR          |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF16mmF2.8 R WR          |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF18mmF1.4 R LM WR       |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF18mmF2 R               |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF23mmF1.4 R             |                                       | √                  | -        | -  | -        | -                          | Need to remove eyepiece cap                                      |
|                          |       | XF23mmF1.4 R LM WR       |                                       | √                  | -        | -  | -        | -                          | Need to remove eyepiece cap                                      |
|                          |       | XF23mmF2 R WR            |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF27mmF2.8               |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF30mmF2.8 R LM WR Macro |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF33mmF1.4 R LM WR       |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XC35mmF2                 |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF 35mm f/1.4 R          |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF 35mm f/2 R WR         |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF50mmF2 R WR            |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF56mmF1.2 R WR          |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF56mmF1.2 R APD         |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF60mmF2.4 R Macro       |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF10-24mmF4 R OIS WR     |                                       | √                  | -        | -  | -        | -                          | Can be balanced at any focal length, need to remove eyepiece cap |
|                          |       | XC 15-45mm f/3.5-5.6 OIS |                                       | √                  | -        | -  | -        | -                          | Can be balanced at any focal length, need to remove eyepiece cap |
| XC16-50mmF3.5-5.6 OIS II | √     | -                        | -                                     | -                  | -        | Can be balanced at any focal length, need to remove eyepiece cap |          |                            |  |
| XF 18-55mm f/2.8-4 R OIS | √     | -                        | -                                     | -                  | -        | Can be balanced at any focal length, need to remove eyepiece cap |          |                            |  |
| XF16-80mmF4 R OIS WR     | √     | -                        | -                                     | -                  | -        | Can be balanced at any focal length, need to remove eyepiece cap |          |                            |  |



| Camera Brand             | Model | Lens Model               | Mounting Status                       | Balance Adjustment |          | Camera Backing Base  |          | Servo Zoom/<br>Focus Motor | Installation Remark  |
|--------------------------|-------|--------------------------|---------------------------------------|--------------------|----------|--|----------|----------------------------|--|
|                          |       |                          |                                       | Horizontal         | Vertical | Horizontal   | Vertical |                            |  |
| FUJIFILM                 | X-S10 | XF14mmF2.8 R             | Standard quick release plate provided | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF16mmF1.4 R WR          |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF16mmF2.8 R WR          |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF18mmF1.4 R LM WR       |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF18mmF2 R               |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF23mmF1.4 R             |                                       | √                  | -        | -  | -        | -                          | Need to remove eyepiece cap                                      |
|                          |       | XF23mmF1.4 R LM WR       |                                       | √                  | -        | -  | -        | -                          | Need to remove eyepiece cap                                      |
|                          |       | XF23mmF2 R WR            |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF27mmF2.8               |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF30mmF2.8 R LM WR Macro |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF33mmF1.4 R LM WR       |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XC35mmF2                 |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF 35mm f/1.4 R          |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF 35mm f/2 R WR         |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF50mmF2 R WR            |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF56mmF1.2 R WR          |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF56mmF1.2 R APD         |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF60mmF2.4 R Macro       |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF10-24mmF4 R OIS WR     |                                       | √                  | -        | -  | -        | -                          | Can be balanced at any focal length, need to remove eyepiece cap |
|                          |       | XC 15-45mm f/3.5-5.6 OIS |                                       | √                  | -        | -  | -        | -                          | Can be balanced at any focal length, need to remove eyepiece cap |
|                          |       | XC16-50mmF3.5-5.6 OIS II |                                       | √                  | -        | -  | -        | -                          | Can be balanced at any focal length, need to remove eyepiece cap |
| XF 18-55mm f/2.8-4 R OIS | √     | -                        | -                                     | -                  | -        | Can be balanced at any focal length, need to remove eyepiece cap |          |                            |  |
| XF16-80mmF4 R OIS WR     | √     | -                        | -                                     | -                  | -        | Can be balanced at any focal length, need to remove eyepiece cap |          |                            |  |



| Camera Brand             | Model | Lens Model               | Mounting Status                       | Balance Adjustment |          | Camera Backing Base  |          | Servo Zoom/<br>Focus Motor | Installation Remark  |
|--------------------------|-------|--------------------------|---------------------------------------|--------------------|----------|--|----------|----------------------------|--|
|                          |       |                          |                                       | Horizontal         | Vertical | Horizontal   | Vertical |                            |  |
| FUJIFILM                 | X-S20 | XF14mmF2.8 R             | Standard quick release plate provided | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF16mmF1.4 R WR          |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF16mmF2.8 R WR          |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF18mmF1.4 R LM WR       |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF18mmF2 R               |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF23mmF1.4 R             |                                       | √                  | -        | -  | -        | -                          | Need to remove eyepiece cap                                      |
|                          |       | XF23mmF1.4 R LM WR       |                                       | √                  | -        | -  | -        | -                          | Need to remove eyepiece cap                                      |
|                          |       | XF23mmF2 R WR            |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF27mmF2.8               |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF30mmF2.8 R LM WR Macro |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF33mmF1.4 R LM WR       |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XC35mmF2                 |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF 35mm f/1.4 R          |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF 35mm f/2 R WR         |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF50mmF2 R WR            |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF56mmF1.2 R WR          |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF56mmF1.2 R APD         |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF60mmF2.4 R Macro       |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF10-24mmF4 R OIS WR     |                                       | √                  | -        | -  | -        | -                          | Can be balanced at any focal length, need to remove eyepiece cap |
|                          |       | XC 15-45mm f/3.5-5.6 OIS |                                       | √                  | -        | -  | -        | -                          | Can be balanced at any focal length, need to remove eyepiece cap |
|                          |       | XC16-50mmF3.5-5.6 OIS II |                                       | √                  | -        | -  | -        | -                          | Can be balanced at any focal length, need to remove eyepiece cap |
| XF 18-55mm f/2.8-4 R OIS | √     | -                        | -                                     | -                  | -        | Can be balanced at any focal length, need to remove eyepiece cap |          |                            |  |
| XF16-80mmF4 R OIS WR     | √     | -                        | -                                     | -                  | -        | Can be balanced at any focal length, need to remove eyepiece cap |          |                            |  |



| Camera Brand             | Model | Lens Model               | Mounting Status                       | Balance Adjustment |          | Camera Backing Base  |          | Servo Zoom/<br>Focus Motor | Installation Remark  |
|--------------------------|-------|--------------------------|---------------------------------------|--------------------|----------|--|----------|----------------------------|--|
|                          |       |                          |                                       | Horizontal         | Vertical | Horizontal   | Vertical |                            |  |
| FUJIFILM                 | X-T30 | XF14mmF2.8 R             | Standard quick release plate provided | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF16mmF1.4 R WR          |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF16mmF2.8 R WR          |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF18mmF1.4 R LM WR       |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF18mmF2 R               |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF23mmF1.4 R             |                                       | √                  | -        | -  | -        | -                          | Need to remove eyepiece cap                                      |
|                          |       | XF23mmF1.4 R LM WR       |                                       | √                  | -        | -  | -        | -                          | Need to remove eyepiece cap                                      |
|                          |       | XF23mmF2 R WR            |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF27mmF2.8               |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF30mmF2.8 R LM WR Macro |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF33mmF1.4 R LM WR       |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XC35mmF2                 |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF 35mm f/1.4 R          |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF 35mm f/2 R WR         |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF50mmF2 R WR            |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF56mmF1.2 R WR          |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF56mmF1.2 R APD         |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF60mmF2.4 R Macro       |                                       | √                  | -        | -  | -        | -                          | No need to remove eyepiece cap                                   |
|                          |       | XF10-24mmF4 R OIS WR     |                                       | √                  | -        | -  | -        | -                          | Can be balanced at any focal length, need to remove eyepiece cap |
|                          |       | XC 15-45mm f/3.5-5.6 OIS |                                       | √                  | -        | -  | -        | -                          | Can be balanced at any focal length, need to remove eyepiece cap |
|                          |       | XC16-50mmF3.5-5.6 OIS II |                                       | √                  | -        | -  | -        | -                          | Can be balanced at any focal length, need to remove eyepiece cap |
| XF 18-55mm f/2.8-4 R OIS | √     | -                        | -                                     | -                  | -        | Can be balanced at any focal length, need to remove eyepiece cap |          |                            |  |
| XF16-80mmF4 R OIS WR     | √     | -                        | -                                     | -                  | -        | Can be balanced at any focal length, need to remove eyepiece cap |          |                            |  |



| Camera Brand | Model   | Lens Model   | Mounting Status                       | Balance Adjustment            |                                       | Camera Backing Base |          | Servo Zoom/<br>Focus Motor | Installation Remark   |
|--------------|---|--|---------------------------------------|-------------------------------|---------------------------------------|---------------------|----------|----------------------------|---|
|              |   |  |                                       | Horizontal                    | Vertical                              | Horizontal          | Vertical |                            |   |
| Panasonic    | DC-G100   | LEICA DG SUMMILUX 15mm f/1.7 ASPH                    | Standard quick release plate provided | √                             | -                                     | -                   | -        | -                          | No need to remove eyepiece cap                                      |
|              |   | Lumix G 25mm f/1.4                                   |                                       | √                             | -                                     | -                   | -        | -                          | No need to remove eyepiece cap                                      |
|              |   | Lumix G 25mm f/1.7                                   |                                       | √                             | -                                     | -                   | -        | -                          | No need to remove eyepiece cap                                      |
|              |   | LUMIX G MACRO 30mm f/2.8 ASPH MEGA OIS               |                                       | √                             | -                                     | -                   | -        | -                          | No need to remove eyepiece cap                                      |
|              |   | LEICA DG Vario-Elmarit 8-18mm f/2.8-4.0 ASPH         |                                       | √                             | -                                     | -                   | -        | -                          | Can be balanced at any focal length, no need to remove eyepiece cap |
|              |   | 12-32 0.2m/0.66ft                                    |                                       | √                             | -                                     | -                   | -        | -                          | Can be balanced at any focal length, no need to remove eyepiece cap |
|              |   | Lumix G X Vario 12-35mm f/2.8 II ASPH POWER OIS      |                                       | √                             | -                                     | -                   | -        | -                          | Can be balanced at any focal length, no need to remove eyepiece cap |
|              | DMC-GH4   | LEICA DG MACRO 45mm f/2.8 OIS                        | Standard quick release plate provided | √                             | -                                     | -                   | -        | -                          | No need to remove eyepiece cap                                      |
|              |   | LEICA DG SUMMILUX 15mm f/1.7 ASPH                    |                                       | √                             | -                                     | -                   | -        | -                          | No need to remove eyepiece cap                                      |
|              |   | LEICA DG Vario-Elmarit 12-60 f/2.8-4 Power OIS       |                                       | √                             | -                                     | -                   | -        | -                          | Can be balanced at any focal length, no need to remove eyepiece cap |
|              |   | LEICA DG Vario-Elmarit 8-18mm f/2.8-4.0 ASPH         |                                       | √                             | -                                     | -                   | -        | -                          | Can be balanced at any focal length, no need to remove eyepiece cap |
|              |   | LUMIX G X Vario 12-35mm f/2.8 II ASPH POWER OIS      |                                       | √                             | -                                     | -                   | -        | -                          | Can be balanced at any focal length, no need to remove eyepiece cap |
|              |   | Panasonic Leica DG Summilux 12mm f/1.4 ASPH          |                                       | √                             | -                                     | -                   | -        | -                          | No need to remove eyepiece cap                                      |
|              |   | Panasonic Leica DG Summilux 25mm f/1.4 II ASPH       |                                       | √                             | -                                     | -                   | -        | -                          | No need to remove eyepiece cap                                      |
|              |   | Panasonic LUMIX G 14mm / F2.5 ASPH                   |                                       | √                             | -                                     | -                   | -        | -                          | No need to remove eyepiece cap                                      |
|              |   | Panasonic LUMIX G 20mm / F1.7 II ASPH                |                                       | √                             | -                                     | -                   | -        | -                          | No need to remove eyepiece cap                                      |
|              |   | Panasonic Lumix G 25mm f/1.7 ASPH                    |                                       | √                             | -                                     | -                   | -        | -                          | No need to remove eyepiece cap                                      |
|              |   | Panasonic Lumix G 42.5mm f/1.7 ASPH. POWER O.I.S.    |                                       | √                             | -                                     | -                   | -        | -                          | No need to remove eyepiece cap                                      |
|              |   | Panasonic Lumix G Macro 30mm f/2.8 ASPH. MEGA O.I.S. |                                       | √                             | -                                     | -                   | -        | -                          | No need to remove eyepiece cap                                      |
|              |   | DMC-GH5  |                                       | LEICA DG MACRO 45mm f/2.8 OIS | Standard quick release plate provided | √                   | -        | -                          | -   |
|              | LEICA DG SUMMILUX 15mm f/1.7 ASPH               |  | √                                     | -                             |                                       | -                   | -        | -                          | No need to remove eyepiece cap                                      |
|              | LEICA DG Vario-Elmarit 12-60 f/2.8-4 Power OIS  |  | √                                     | -                             |                                       | -                   | -        | -                          | Can be balanced at any focal length, no need to remove eyepiece cap |
|              | LEICA DG Vario-Elmarit 8-18mm f/2.8-4.0 ASPH    |  | √                                     | -                             |                                       | -                   | -        | -                          | Can be balanced at any focal length, no need to remove eyepiece cap |
|              | LUMIX G X Vario 12-35mm f/2.8 II ASPH POWER OIS |  | √                                     | -                             |                                       | -                   | -        | -                          | Can be balanced at any focal length, no need to remove eyepiece cap |



| Camera Brand                                    | Model    | Lens Model   | Mounting Status                       | Balance Adjustment |          | Camera Backing Base |          | Servo Zoom/<br>Focus Motor  | Installation Remark   |
|---|----------|--|---------------------------------------|--------------------|----------|---------------------|----------|---|---|
|   |          |  |                                       | Horizontal         | Vertical | Horizontal          | Vertical |   |   |
| Panasonic                                       | DMC-GH5  | Panasonic Leica DG Summilux 12mm f/1.4 ASPH          | Standard quick release plate provided | √                  | -        | -                   | -        | -   | No need to remove eyepiece cap                                      |
|   |          | Panasonic Leica DG Summilux 25mm f/1.4 II ASPH       |                                       | √                  | -        | -                   | -        | -   | No need to remove eyepiece cap                                      |
|   |          | Panasonic LUMIX G 14mm / F2.5 ASPH                   |                                       | √                  | -        | -                   | -        | -   | No need to remove eyepiece cap                                      |
|   |          | Panasonic LUMIX G 20mm / F1.7 II ASPH                |                                       | √                  | -        | -                   | -        | -   | No need to remove eyepiece cap                                      |
|   |          | Panasonic Lumix G 25mm f/1.7 ASPH                    |                                       | √                  | -        | -                   | -        | -   | No need to remove eyepiece cap                                      |
|   |          | Panasonic Lumix G 42.5mm f/1.7 ASPH. POWER O.I.S.    |                                       | √                  | -        | -                   | -        | -   | No need to remove eyepiece cap                                      |
|   | DMC-GH5S | LEICA DG MACRO 45mm f/2.8 OIS                        | Standard quick release plate provided | √                  | -        | -                   | -        | -   | No need to remove eyepiece cap                                      |
|   |          | LEICA DG SUMMILUX 15mm f/1.7 ASPH                    |                                       | √                  | -        | -                   | -        | -   | No need to remove eyepiece cap                                      |
|   |          | LEICA DG Vario-Elmarit 12-60 f/2.8-4 Power OIS       |                                       | √                  | -        | -                   | -        | -   | Can be balanced at any focal length, no need to remove eyepiece cap |
|   |          | LEICA DG Vario-Elmarit 8-18mm f/2.8-4.0 ASPH         |                                       | √                  | -        | -                   | -        | -   | Can be balanced at any focal length, no need to remove eyepiece cap |
|   |          | LUMIX G X Vario 12-35mm f/2.8 II ASPH POWER OIS      |                                       | √                  | -        | -                   | -        | -   | Can be balanced at any focal length, no need to remove eyepiece cap |
|   |          | Panasonic Leica DG Summilux 12mm f/1.4 ASPH          |                                       | √                  | -        | -                   | -        | -   | No need to remove eyepiece cap                                      |
|   |          | Panasonic Leica DG Summilux 25mm f/1.4 II ASPH       |                                       | √                  | -        | -                   | -        | -   | No need to remove eyepiece cap                                      |
|   |          | Panasonic LUMIX G 14mm / F2.5 ASPH                   |                                       | √                  | -        | -                   | -        | -   | No need to remove eyepiece cap                                      |
|   |          | Panasonic LUMIX G 20mm / F1.7 II ASPH                |                                       | √                  | -        | -                   | -        | -   | No need to remove eyepiece cap                                      |
|   |          | Panasonic Lumix G 25mm f/1.7 ASPH                    |                                       | √                  | -        | -                   | -        | -   | No need to remove eyepiece cap                                      |
|   |          | Panasonic Lumix G 42.5mm f/1.7 ASPH. POWER O.I.S.    |                                       | √                  | -        | -                   | -        | -   | No need to remove eyepiece cap                                      |
|   |          | Panasonic Lumix G Macro 30mm f/2.8 ASPH. MEGA O.I.S. |                                       | √                  | -        | -                   | -        | -   | No need to remove eyepiece cap                                      |
|   | DMC-GH6  | LEICA DG MACRO 45mm f/2.8 OIS                        | Standard quick release plate provided | √                  | -        | -                   | -        | -   | No need to remove eyepiece cap                                      |
|   |          | LEICA DG SUMMILUX 15mm f/1.7 ASPH                    |                                       | √                  | -        | -                   | -        | -   | No need to remove eyepiece cap                                      |
|   |          | LEICA DG Vario-Elmarit 12-60 f/2.8-4 Power OIS       |                                       | √                  | -        | -                   | -        | -   | Can be balanced at any focal length, no need to remove eyepiece cap |
| LEICA DG Vario-Elmarit 8-18mm f/2.8-4.0 ASPH    |          | √  |                                       | -                  | -        | -                   | -        | Can be balanced at any focal length, no need to remove eyepiece cap |   |
| LUMIX G X Vario 12-35mm f/2.8 II ASPH POWER OIS |          | √  |                                       | -                  | -        | -                   | -        | Can be balanced at any focal length, no need to remove eyepiece cap |   |
| Panasonic Leica DG Summilux 12mm f/1.4 ASPH     |          | √  |                                       | -                  | -        | -                   | -        | No need to remove eyepiece cap                                      |   |



| Camera Brand              | Model   | Lens Model   | Mounting Status                       | Balance Adjustment |          | Camera Backing Base |          | Servo Zoom/<br>Focus Motor     | Installation Remark   |
|---------------------------|---------|--|---------------------------------------|--------------------|----------|---------------------|----------|--------------------------------|---|
|                           |         |  |                                       | Horizontal         | Vertical | Horizontal          | Vertical |                                |   |
| Panasonic                 | DMC-GH6 | Panasonic Leica DG Summilux 25mm f/1.4 II ASPH       | Standard quick release plate provided | √                  | -        | -                   | -        | -                              | No need to remove eyepiece cap                                      |
|                           |         | Panasonic LUMIX G 14mm / F2.5 ASPH                   |                                       | √                  | -        | -                   | -        | -                              | No need to remove eyepiece cap                                      |
|                           |         | Panasonic LUMIX G 20mm / F1.7 II ASPH                |                                       | √                  | -        | -                   | -        | -                              | No need to remove eyepiece cap                                      |
|                           |         | Panasonic Lumix G 25mm f/1.7 ASPH                    |                                       | √                  | -        | -                   | -        | -                              | No need to remove eyepiece cap                                      |
|                           |         | Panasonic Lumix G 42.5mm f/1.7 ASPH. POWER O.I.S.    |                                       | √                  | -        | -                   | -        | -                              | No need to remove eyepiece cap                                      |
|                           |         | Panasonic Lumix G Macro 30mm f/2.8 ASPH. MEGA O.I.S. |                                       | √                  | -        | -                   | -        | -                              | No need to remove eyepiece cap                                      |
|                           | DMC-G9  | LEICA DG MACRO 45mm f/2.8 OIS                        | Standard quick release plate provided | √                  | -        | -                   | -        | -                              | No need to remove eyepiece cap                                      |
|                           |         | LEICA DG SUMMILUX 15mm f/1.7 ASPH                    |                                       | √                  | -        | -                   | -        | -                              | No need to remove eyepiece cap                                      |
|                           |         | LEICA DG Vario-Elmarit 12-60 f/2.8-4 Power OIS       |                                       | √                  | -        | -                   | -        | -                              | Can be balanced at any focal length, no need to remove eyepiece cap |
|                           |         | LEICA DG Vario-Elmarit 8-18mm f/2.8-4.0 ASPH         |                                       | √                  | -        | -                   | -        | -                              | Can be balanced at any focal length, no need to remove eyepiece cap |
|                           |         | LUMIX G X Vario 12-35mm f/2.8 II ASPH POWER OIS      |                                       | √                  | -        | -                   | -        | -                              | Can be balanced at any focal length, no need to remove eyepiece cap |
|                           |         | Panasonic Leica DG Summilux 12mm f/1.4 ASPH          |                                       | √                  | -        | -                   | -        | -                              | No need to remove eyepiece cap                                      |
|                           |         | Panasonic Leica DG Summilux 25mm f/1.4 II ASPH       |                                       | √                  | -        | -                   | -        | -                              | No need to remove eyepiece cap                                      |
|                           |         | Panasonic LUMIX G 14mm / F2.5 ASPH                   |                                       | √                  | -        | -                   | -        | -                              | No need to remove eyepiece cap                                      |
|                           |         | Panasonic LUMIX G 20mm / F1.7 II ASPH                |                                       | √                  | -        | -                   | -        | -                              | No need to remove eyepiece cap                                      |
|                           |         | Panasonic Lumix G 25mm f/1.7 ASPH                    |                                       | √                  | -        | -                   | -        | -                              | No need to remove eyepiece cap                                      |
|                           |         | Panasonic Lumix G 42.5mm f/1.7 ASPH. POWER O.I.S.    |                                       | √                  | -        | -                   | -        | -                              | No need to remove eyepiece cap                                      |
|                           |         | Panasonic Lumix G Macro 30mm f/2.8 ASPH. MEGA O.I.S. |                                       | √                  | -        | -                   | -        | -                              | No need to remove eyepiece cap                                      |
|                           | DMC-S5  | LUMIX S 18mm F1.8                                    | Standard quick release plate provided | √                  | -        | -                   | -        | -                              | No need to remove eyepiece cap                                      |
|                           |         | LUMIX S 24mm F1.8                                    |                                       | √                  | -        | -                   | -        | -                              | No need to remove eyepiece cap                                      |
|                           |         | LUMIX S 35mm F1.8                                    |                                       | √                  | -        | -                   | -        | -                              | No need to remove eyepiece cap                                      |
| LUMIX S 50mm F1.8         |         | √  |                                       | -                  | -        | -                   | -        | No need to remove eyepiece cap |   |
| LUMIX S 85mm F1.8         |         | √  |                                       | -                  | -        | -                   | -        | No need to remove eyepiece cap |   |
| LUMIX S 20-60 mm F3.5-5.6 |         | √  |                                       | -                  | -        | -                   | -        | No need to remove eyepiece cap |   |



| Camera Brand | Model       | Lens Model          | Mounting Status                       | Balance Adjustment |          | Camera Backing Base |          | Servo Zoom/<br>Focus Motor | Installation Remark             |
|--------------|-------------|---------------------|---------------------------------------|--------------------|----------|---------------------|----------|----------------------------|---------------------------------|
|              |             |                     |                                       | Horizontal         | Vertical | Horizontal          | Vertical |                            |                                 |
| Panasonic    | DMC-LX100M2 | Comes with the lens | Standard quick release plate provided | √                  | -        | -                   | -        | -                          | Should be powered on to balance |
|              | DMC-LX10    | Comes with the lens | Standard quick release plate provided | √                  | -        | -                   | -        | -                          | Should be powered on to balance |
|              | DMC-ZS110   | Comes with the lens | Standard quick release plate provided | √                  | -        | -                   | -        | -                          | Should be powered on to balance |
|              |             |                     |                                       |                    |          |                     |          |                            |                                 |
| SIGMA        | fp          | 45mm F2.8           | Standard quick release plate provided | √                  | -        | -                   | -        | -                          | -                               |