

WEEBILL 3E Camera Compatibility List



Update on December 24 , 2024 (Firmware version V1.53)

V1.60

Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Canon	EOS 5DS	EF 16-35mm f/4L IS USM	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		EF 16-35mm f/2.8L III USM	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		EF 17-40mm f/4L USM	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		EF 24-70mm f/2.8L II USM	Camera and lens	√	√	√	√	Can be balanced at 24-50mm, no need to remove eyepiece cap
		EF 24-70mm f/4L IS USM	Camera and lens	√	√	√	√	Can be balanced at 24-50mm, no need to remove eyepiece cap
		EF 24-105mm f/4L IS II USM	Camera and lens	√	√	√	√	Can be balanced at 24-50mm, no need to remove eyepiece cap
		EF 24-105mm f/3.5-5.6 IS STM	Camera and lens	√	√	√	√	Can be balanced at 24-50mm, no need to remove eyepiece cap
		EF 24mm f/1.4L II USM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		EF 35mm f/1.4L II USM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		EF 50mm f/1.4 USM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		EF 85mm f/1.4L IS USM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		EF 85mm f/1.8 USM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Sigma 24-70mm f/2.8 DG HSM Art	Camera and lens	√	-	√	-	Can be balanced at any focal length, no need to remove eyepiece cap
		Sigma 35mm f/1.4 DG HSM Art	Camera and lens	√	-	√	-	no need to remove eyepiece cap
	Sigma 50mm f/1.4 DG HSM Art	Camera and lens	√	-	√	-	no need to remove eyepiece cap	
	EOS 5DS R	EF 16-35mm f/4L IS USM	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		EF 16-35mm f/2.8L III USM	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		EF 17-40mm f/4L USM	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		EF 24-70mm f/2.8L II USM	Camera and lens	√	√	√	√	Can be balanced at 24-50mm, no need to remove eyepiece cap
EF 24-70mm f/4L IS USM		Camera and lens	√	√	√	√	Can be balanced at 24-50mm, no need to remove eyepiece cap	
EF 24-105mm f/4L IS II USM		Camera and lens	√	√	√	√	Can be balanced at 24-50mm, no need to remove eyepiece cap	
EF 24-105mm f/3.5-5.6 IS STM		Camera and lens	√	√	√	√	Can be balanced at 24-50mm, no need to remove eyepiece cap	

Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Canon	EOS 5DS R	EF 24mm f/1.4L II USM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		EF 35mm f/1.4L II USM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		EF 50mm f/1.4 USM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		EF 85mm f/1.4L IS USM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		EF 85mm f/1.8 USM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Sigma 24-70mm f/2.8 DG HSM Art	Camera and lens	√	-	√	-	Can be balanced at any focal length, no need to remove eyepiece cap
		Sigma 35mm f/1.4 DG HSM Art	Camera and lens	√	-	√	-	no need to remove eyepiece cap
		Sigma 50mm f/1.4 DG HSM Art	Camera and lens	√	-	√	-	no need to remove eyepiece cap
	EOS 5D Mark III	EF 16-35mm f/4L IS USM	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		EF 16-35mm f/2.8L III USM	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		EF 17-40mm f/4L USM	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		EF 24-70mm f/2.8L II USM	Camera and lens	√	√	√	√	Can be balanced at 24-50mm, no need to remove eyepiece cap
		EF 24-70mm f/4L IS USM	Camera and lens	√	√	√	√	Can be balanced at 24-50mm, no need to remove eyepiece cap
		EF 24-105mm f/4L IS II USM	Camera and lens	√	√	√	√	Can be balanced at 24-50mm, no need to remove eyepiece cap
		EF 24-105mm f/3.5-5.6 IS STM	Camera and lens	√	√	√	√	Can be balanced at 24-50mm, no need to remove eyepiece cap
		EF 24mm f/1.4L II USM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		EF 35mm f/1.4L II USM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		EF 50mm f/1.4 USM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		EF 85mm f/1.4L IS USM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		EF 85mm f/1.8 USM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
Sigma 24-70mm f/2.8 DG HSM Art	Camera and lens	√	-	√	-	Can be balanced at any focal length, no need to remove eyepiece cap		
Sigma 35mm f/1.4 DG HSM Art	Camera and lens	√	-	√	-	no need to remove eyepiece cap		
Sigma 50mm f/1.4 DG HSM Art	Camera and lens	√	-	√	-	no need to remove eyepiece cap		

Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Canon	EOS 5D Mark IV	EF 16-35mm f/4L IS USM	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		EF 16-35mm f/2.8L III USM	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		EF 17-40mm f/4L USM	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		EF 24-70mm f/2.8L II USM	Camera and lens	√	√	√	√	Can be balanced at 24-50mm, no need to remove eyepiece cap
		EF 24-70mm f/4L IS USM	Camera and lens	√	√	√	√	Can be balanced at 24-50mm, no need to remove eyepiece cap
		EF 24-105mm f/4L IS II USM	Camera and lens	√	√	√	√	Can be balanced at 24-50mm, no need to remove eyepiece cap
		EF 24-105mm f/3.5-5.6 IS STM	Camera and lens	√	√	√	√	Can be balanced at 24-50mm, no need to remove eyepiece cap
		EF 24mm f/1.4L II USM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		EF 35mm f/1.4L II USM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		EF 50mm f/1.4 USM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		EF 85mm f/1.4L IS USM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		EF 85mm f/1.8 USM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Sigma 24-70mm f/2.8 DG HSM Art	Camera and lens	√	-	√	-	Can be balanced at any focal length, no need to remove eyepiece cap
		Sigma 35mm f/1.4 DG HSM Art	Camera and lens	√	-	√	-	no need to remove eyepiece cap
		Sigma 50mm f/1.4 DG HSM Art	Camera and lens	√	-	√	-	no need to remove eyepiece cap
	EOS 6D Mark II	EF 16-35mm f/4L IS USM	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		EF 16-35mm f/2.8L III USM	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		EF 17-40mm f/4L USM	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		EF 24-70mm f/2.8L II USM	Camera and lens	√	√	√	√	Can be balanced at 24-50mm, no need to remove eyepiece cap
		EF 24-70mm f/4L IS USM	Camera and lens	√	√	√	√	Can be balanced at 24-50mm, no need to remove eyepiece cap
		EF 24-105mm f/4L IS II USM	Camera and lens	√	√	√	√	Can be balanced at 24-50mm, no need to remove eyepiece cap
EF 24-105mm f/3.5-5.6 IS STM		Camera and lens	√	√	√	√	Can be balanced at 24-50mm, no need to remove eyepiece cap	

Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Canon	EOS 6D Mark II	EF 24mm f/1.4L II USM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		EF 35mm f/1.4L II USM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		EF 50mm f/1.4 USM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		EF 85mm f/1.4L IS USM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		EF 85mm f/1.8 USM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Sigma 24-70mm f/2.8 DG HSM Art	Camera and lens	√	-	√	-	Can be balanced at any focal length, no need to remove eyepiece cap
		Sigma 35mm f/1.4 DG HSM Art	Camera and lens	√	-	√	-	no need to remove eyepiece cap
		Sigma 50mm f/1.4 DG HSM Art	Camera and lens	√	-	√	-	no need to remove eyepiece cap
	EOS 6D	EF 16-35mm f/4L IS USM	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		EF 16-35mm f/2.8L III USM	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		EF 17-40mm f/4L USM	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		EF 24-70mm f/2.8L II USM	Camera and lens	√	√	√	√	Can be balanced at 24-50mm, no need to remove eyepiece cap
		EF 24-70mm f/4L IS USM	Camera and lens	√	√	√	√	Can be balanced at 24-50mm, no need to remove eyepiece cap
		EF 24-105mm f/4L IS II USM	Camera and lens	√	√	√	√	Can be balanced at 24-50mm, no need to remove eyepiece cap
		EF 24-105mm f/3.5-5.6 IS STM	Camera and lens	√	√	√	√	Can be balanced at 24-50mm, no need to remove eyepiece cap
		EF 24mm f/1.4L II USM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		EF 35mm f/1.4L II USM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		EF 50mm f/1.4 USM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		EF 85mm f/1.4L IS USM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		EF 85mm f/1.8 USM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
Sigma 24-70mm f/2.8 DG HSM Art	Camera and lens	√	-	√	-	Can be balanced at any focal length, no need to remove eyepiece cap		
Sigma 35mm f/1.4 DG HSM Art	Camera and lens	√	-	√	-	no need to remove eyepiece cap		
Sigma 50mm f/1.4 DG HSM Art	Camera and lens	√	-	√	-	no need to remove eyepiece cap		



Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Canon	EOS 80D	EF 16-35mm f/4L IS USM	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		EF 16-35mm f/2.8L III USM	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		EF 17-40mm f/4L USM	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		EF 24-70mm f/2.8L II USM	Camera and lens	√	√	√	√	Can be balanced at 24-50mm, no need to remove eyepiece cap
		EF 24-70mm f/4L IS USM	Camera and lens	√	√	√	√	Can be balanced at 24-50mm, no need to remove eyepiece cap
		EF 24-105mm f/4L IS II USM	Camera and lens	√	√	√	√	Can be balanced at 24-50mm, no need to remove eyepiece cap
		EF 24-105mm f/3.5-5.6 IS STM	Camera and lens	√	√	√	√	Can be balanced at 24-50mm, no need to remove eyepiece cap
		EF 24mm f/1.4L II USM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		EF 35mm f/1.4L II USM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		EF 50mm f/1.4 USM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		EF 85mm f/1.4L IS USM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		EF 85mm f/1.8 USM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Sigma 24-70mm f/2.8 DG HSM Art	Camera and lens	√	-	√	-	Can be balanced at any focal length, no need to remove eyepiece cap
		Sigma 35mm f/1.4 DG HSM Art	Camera and lens	√	-	√	-	no need to remove eyepiece cap
		Sigma 50mm f/1.4 DG HSM Art	Camera and lens	√	-	√	-	no need to remove eyepiece cap



Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Canon	EOS 90D	EF 16-35mm f/4L IS USM	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		EF 16-35mm f/2.8L III USM	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		EF 17-40mm f/4L USM	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		EF 24-70mm f/2.8L II USM	Camera and lens	√	√	√	√	Can be balanced at 24-50mm, no need to remove eyepiece cap
		EF 24-70mm f/4L IS USM	Camera and lens	√	√	√	√	Can be balanced at 24-50mm, no need to remove eyepiece cap
		EF 24-105mm f/4L IS II USM	Camera and lens	√	√	√	√	Can be balanced at 24-50mm, no need to remove eyepiece cap
		EF 24-105mm f/3.5-5.6 IS STM	Camera and lens	√	√	√	√	Can be balanced at 24-50mm, no need to remove eyepiece cap
		EF 24mm f/1.4L II USM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		EF 35mm f/1.4L II USM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		EF 50mm f/1.4 USM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		EF 85mm f/1.4L IS USM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		EF 85mm f/1.8 USM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Sigma 24-70mm f/2.8 DG HSM Art	Camera and lens	√	-	√	-	Can be balanced at any focal length, no need to remove eyepiece cap
		Sigma 35mm f/1.4 DG HSM Art	Camera and lens	√	-	√	-	no need to remove eyepiece cap
		Sigma 50mm f/1.4 DG HSM Art	Camera and lens	√	-	√	-	no need to remove eyepiece cap



Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Canon	EOS 800D	EF 16-35mm f/4L IS USM	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		EF 16-35mm f/2.8L III USM	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		EF 17-40mm f/4L USM	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		EF 24-70mm f/2.8L II USM	Camera and lens	√	√	√	√	Can be balanced at 24-50mm, no need to remove eyepiece cap
		EF 24-70mm f/4L IS USM	Camera and lens	√	√	√	√	Can be balanced at 24-50mm, no need to remove eyepiece cap
		EF 24-105mm f/4L IS II USM	Camera and lens	√	√	√	√	Can be balanced at 24-50mm, no need to remove eyepiece cap
		EF 24-105mm f/3.5-5.6 IS STM	Camera and lens	√	√	√	√	Can be balanced at 24-50mm, no need to remove eyepiece cap
		EF 24mm f/1.4L II USM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		EF 35mm f/1.4L II USM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		EF 50mm f/1.4 USM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		EF 85mm f/1.4L IS USM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		EF 85mm f/1.8 USM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Sigma 24-70mm f/2.8 DG HSM Art	Camera and lens	√	-	√	-	Can be balanced at any focal length, no need to remove eyepiece cap
		Sigma 35mm f/1.4 DG HSM Art	Camera and lens	√	-	√	-	no need to remove eyepiece cap
		Sigma 50mm f/1.4 DG HSM Art	Camera and lens	√	-	√	-	no need to remove eyepiece cap



Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Canon	EOS 850D	EF 16-35mm f/4L IS USM	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		EF 16-35mm f/2.8L III USM	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		EF 17-40mm f/4L USM	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		EF 24-70mm f/2.8L II USM	Camera and lens	√	√	√	√	Can be balanced at 24-50mm, no need to remove eyepiece cap
		EF 24-70mm f/4L IS USM	Camera and lens	√	√	√	√	Can be balanced at 24-50mm, no need to remove eyepiece cap
		EF 24-105mm f/4L IS II USM	Camera and lens	√	√	√	√	Can be balanced at 24-50mm, no need to remove eyepiece cap
		EF 24-105mm f/3.5-5.6 IS STM	Camera and lens	√	√	√	√	Can be balanced at 24-50mm, no need to remove eyepiece cap
		EF 24mm f/1.4L II USM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		EF 35mm f/1.4L II USM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		EF 50mm f/1.4 USM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		EF 85mm f/1.4L IS USM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		EF 85mm f/1.8 USM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Sigma 24-70mm f/2.8 DG HSM Art	Camera and lens	√	-	√	-	Can be balanced at any focal length, no need to remove eyepiece cap
		Sigma 35mm f/1.4 DG HSM Art	Camera and lens	√	-	√	-	no need to remove eyepiece cap
		Sigma 50mm f/1.4 DG HSM Art	Camera and lens	√	-	√	-	no need to remove eyepiece cap



Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Canon	EOS 200D II	EF 16-35mm f/4L IS USM	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		EF 16-35mm f/2.8L III USM	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		EF 17-40mm f/4L USM	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		EF 24-70mm f/2.8L II USM	Camera and lens	√	√	√	√	Can be balanced at 24-50mm, no need to remove eyepiece cap
		EF 24-70mm f/4L IS USM	Camera and lens	√	√	√	√	Can be balanced at 24-50mm, no need to remove eyepiece cap
		EF 24-105mm f/4L IS II USM	Camera and lens	√	√	√	√	Can be balanced at 24-50mm, no need to remove eyepiece cap
		EF 24-105mm f/3.5-5.6 IS STM	Camera and lens	√	√	√	√	Can be balanced at 24-50mm, no need to remove eyepiece cap
		EF 24mm f/1.4L II USM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		EF 35mm f/1.4L II USM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		EF 50mm f/1.4 USM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		EF 85mm f/1.4L IS USM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		EF 85mm f/1.8 USM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Sigma 24-70mm f/2.8 DG HSM Art	Camera and lens	√	-	√	-	Can be balanced at any focal length, no need to remove eyepiece cap
		Sigma 35mm f/1.4 DG HSM Art	Camera and lens	√	-	√	-	no need to remove eyepiece cap
		Sigma 50mm f/1.4 DG HSM Art	Camera and lens	√	-	√	-	no need to remove eyepiece cap

Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Canon	EOS R50 (use mount adapter EF-RF for non-RF lenses)	EF 16-35mm f/4L IS USM	Camera and lens	√	√	√	√	Can be balanced at any focal length, do not remove eyepiece cap
		EF 16-35mm f/2.8L III USM	Camera and lens	-	-	-	-	
		EF 17-40mm f/4L USM	Camera and lens	√	√	√	√	Can be balanced at any focal length, do not remove eyepiece cap
		EF 24-70mm f/2.8L II USM	Camera and lens	-	-	-	-	
		EF 24-70mm f/4L IS USM	Camera and lens	√	√	√	√	Can be balanced at 24mm, do not remove eyepiece cap
		EF 24-105mm f/4L IS II USM	Camera and lens	√	√	√	√	Can be balanced at 24mm, do not remove eyepiece cap
		EF 24-105mm f/3.5-5.6 IS STM	Camera and lens	√	√	√	√	Can be balanced at 24mm, do not remove eyepiece cap
		EF 24mm f/1.4L II USM	Camera and lens	√	√	√	√	do not remove eyepiece cap
		EF 35mm f/1.4L II USM	Camera and lens	√	√	√	√	do not remove eyepiece cap
		EF 50mm f/1.2L USM	Camera and lens	√	√	√	√	do not remove eyepiece cap
		EF 50mm f/1.4 USM	Camera and lens	√	√	√	√	do not remove eyepiece cap
		EF 85mm f/1.4L IS USM	Camera and lens	√	√	√	√	do not remove eyepiece cap
		EF 85mm f/1.8 USM	Camera and lens	√	√	√	√	do not remove eyepiece cap
		Sigma 24-70mm f/2.8 DG HSM Art	Camera and lens	-	-	-	-	
		Sigma 35mm f/1.4 DG HSM Art	Camera and lens	√	-	√	-	do not remove eyepiece cap
		Sigma 50mm f/1.4 DG HSM Art	Camera and lens	√	-	√	-	do not remove eyepiece cap
		RF 24-70mm f/2.8 L IS USM	Camera and lens	√	√	√	√	Can be balanced at 24mm, do not remove eyepiece cap
		RF 15-35mm f/2.8 L IS USM	Camera and lens	√	√	√	√	Can be balanced at any focal length
		RF50mm F1.2 L USM	Camera and lens	√	-	√	-	do not remove eyepiece cap

Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Canon	EOS R (use mount adapter EF-RF for non-RF lenses)	EF 16-35mm f/4L IS USM	Camera and lens	√	√	√	√	Can be balanced at any focal length, do not remove eyepiece cap
		EF 16-35mm f/2.8L III USM	Camera and lens	-	-	-	-	
		EF 17-40mm f/4L USM	Camera and lens	√	√	√	√	Can be balanced at any focal length, do not remove eyepiece cap
		EF 24-70mm f/2.8L II USM	Camera and lens	-	-	-	-	
		EF 24-70mm f/4L IS USM	Camera and lens	√	√	√	√	Can be balanced at 24mm, do not remove eyepiece cap
		EF 24-105mm f/4L IS II USM	Camera and lens	√	√	√	√	Can be balanced at 24mm, do not remove eyepiece cap
		EF 24-105mm f/3.5-5.6 IS STM	Camera and lens	√	√	√	√	Can be balanced at 24mm, do not remove eyepiece cap
		EF 24mm f/1.4L II USM	Camera and lens	√	√	√	√	do not remove eyepiece cap
		EF 35mm f/1.4L II USM	Camera and lens	√	√	√	√	do not remove eyepiece cap
		EF 50mm f/1.2L USM	Camera and lens	√	√	√	√	do not remove eyepiece cap
		EF 50mm f/1.4 USM	Camera and lens	√	√	√	√	do not remove eyepiece cap
		EF 85mm f/1.4L IS USM	Camera and lens	√	√	√	√	do not remove eyepiece cap
		EF 85mm f/1.8 USM	Camera and lens	√	√	√	√	do not remove eyepiece cap
		Sigma 24-70mm f/2.8 DG HSM Art	Camera and lens	-	-	-	-	
		Sigma 35mm f/1.4 DG HSM Art	Camera and lens	√	-	√	-	do not remove eyepiece cap
		Sigma 50mm f/1.4 DG HSM Art	Camera and lens	√	-	√	-	do not remove eyepiece cap
		RF 24-70mm f/2.8 L IS USM	Camera and lens	√	√	√	√	Can be balanced at 24mm, do not remove eyepiece cap
		RF 15-35mm f/2.8 L IS USM	Camera and lens	√	√	√	√	Can be balanced at any focal length
		RF50mm F1.2 L USM	Camera and lens	√	-	√	-	do not remove eyepiece cap

Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Canon	EOS R5, EOS R5 II (use mount adapter EF-RF for non-RF lenses)	EF 16-35mm f/4L IS USM	Camera and lens	√	√	√	√	Can be balanced at any focal length, do not remove eyepiece cap
		EF 16-35mm f/2.8L III USM	Camera and lens	-	-	-	-	
		EF 17-40mm f/4L USM	Camera and lens	√	√	√	√	Can be balanced at any focal length, do not remove eyepiece cap
		EF 24-70mm f/2.8L II USM	Camera and lens	-	-	-	-	
		EF 24-70mm f/4L IS USM	Camera and lens	√	√	√	√	Can be balanced at 24mm, do not remove eyepiece cap
		EF 24-105mm f/4L IS II USM	Camera and lens	√	√	√	√	Can be balanced at 24mm, do not remove eyepiece cap
		EF 24-105mm f/3.5-5.6 IS STM	Camera and lens	√	√	√	√	Can be balanced at 24mm, do not remove eyepiece cap
		EF 24mm f/1.4L II USM	Camera and lens	√	√	√	√	do not remove eyepiece cap
		EF 35mm f/1.4L II USM	Camera and lens	√	√	√	√	do not remove eyepiece cap
		EF 50mm f/1.2L USM	Camera and lens	√	√	√	√	do not remove eyepiece cap
		EF 50mm f/1.4 USM	Camera and lens	√	√	√	√	do not remove eyepiece cap
		EF 85mm f/1.4L IS USM	Camera and lens	√	√	√	√	do not remove eyepiece cap
		EF 85mm f/1.8 USM	Camera and lens	√	√	√	√	do not remove eyepiece cap
		Sigma 24-70mm f/2.8 DG HSM Art	Camera and lens	-	-	-	-	
		Sigma 35mm f/1.4 DG HSM Art	Camera and lens	√	-	√	-	do not remove eyepiece cap
		Sigma 50mm f/1.4 DG HSM Art	Camera and lens	√	-	√	-	do not remove eyepiece cap
		RF 24-70mm f/2.8 L IS USM	Camera and lens	√	√	√	√	Can be balanced at 24mm, do not remove eyepiece cap
		RF 15-35mm f/2.8 L IS USM	Camera and lens	√	√	√	√	Can be balanced at any focal length
		RF50mm F1.2 L USM	Camera and lens	√	-	√	-	do not remove eyepiece cap
		RF 15-30mm f/4.5-6.3 IS STM	Camera and lens	√	√	-	-	Can be balanced at any focal length
		RF 16mm F2.8 STM	Camera and lens	√	√	-	-	
		RF 24-105mm F4-7.1 IS STM	Camera and lens	√	√	-	-	Can be balanced at any focal length
		RF 24mm f/1.8 Macro IS STM	Camera and lens	√	√	-	-	
		RF 35mm F1.8 MACRO IS STM	Camera and lens	√	√	-	-	
		RF-S 18-45mm f/4.5-6.3 IS STM	Camera and lens	√	√	-	-	Can be balanced at any focal length
RF 50mm F1.8 STM	Camera and lens	√	√	-	-			

Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Canon	EOS R6 (use mount adapter EF-RF for non-RF lenses)	EF 16-35mm f/4L IS USM	Camera and lens	√	√	√	√	Can be balanced at any focal length, do not remove eyepiece cap
		EF 16-35mm f/2.8L III USM	Camera and lens	-	-	-	-	
		EF 17-40mm f/4L USM	Camera and lens	√	√	√	√	Can be balanced at any focal length, do not remove eyepiece cap
		EF 24-70mm f/2.8L II USM	Camera and lens	-	-	-	-	
		EF 24-70mm f/4L IS USM	Camera and lens	√	√	√	√	Can be balanced at 24mm, do not remove eyepiece cap
		EF 24-105mm f/4L IS II USM	Camera and lens	√	√	√	√	Can be balanced at 24mm, do not remove eyepiece cap
		EF 24-105mm f/3.5-5.6 IS STM	Camera and lens	√	√	√	√	Can be balanced at 24mm, do not remove eyepiece cap
		EF 24mm f/1.4L II USM	Camera and lens	√	√	√	√	do not remove eyepiece cap
		EF 35mm f/1.4L II USM	Camera and lens	√	√	√	√	do not remove eyepiece cap
		EF 50mm f/1.2L USM	Camera and lens	√	√	√	√	do not remove eyepiece cap
		EF 50mm f/1.4 USM	Camera and lens	√	√	√	√	do not remove eyepiece cap
		EF 85mm f/1.4L IS USM	Camera and lens	√	√	√	√	do not remove eyepiece cap
		EF 85mm f/1.8 USM	Camera and lens	√	√	√	√	do not remove eyepiece cap
		Sigma 24-70mm f/2.8 DG HSM Art	Camera and lens	-	-	-	-	
		Sigma 35mm f/1.4 DG HSM Art	Camera and lens	√	-	√	-	do not remove eyepiece cap
		Sigma 50mm f/1.4 DG HSM Art	Camera and lens	√	-	√	-	do not remove eyepiece cap
		RF 24-70mm f/2.8 L IS USM	Camera and lens	√	√	√	√	Can be balanced at 24mm, do not remove eyepiece cap
		RF 15-35mm f/2.8 L IS USM	Camera and lens	√	√	√	√	Can be balanced at any focal length
		RF50mm F1.2 L USM	Camera and lens	√	-	√	-	do not remove eyepiece cap
		RF 15-30mm f/4.5-6.3 IS STM	Camera and lens	√	√	-	-	Can be balanced at any focal length
		RF 16mm F2.8 STM	Camera and lens	√	√	-	-	
		RF 24-105mm F4-7.1 IS STM	Camera and lens	√	√	-	-	Can be balanced at any focal length
		RF 24mm f/1.8 Macro IS STM	Camera and lens	√	√	-	-	
		RF 35mm F1.8 MACRO IS STM	Camera and lens	√	√	-	-	
RF-S 18-45mm f/4.5-6.3 IS STM	Camera and lens	√	√	-	-	Can be balanced at any focal length		
RF 50mm F1.8 STM	Camera and lens	√	√	-	-			

Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Canon	EOS R6 Mark II (use mount adapter EF-RF for non-RF lenses)	EF 16-35mm f/4L IS USM	Camera and lens	√	√	√	√	Can be balanced at any focal length, do not remove eyepiece cap
		EF 16-35mm f/2.8L III USM	Camera and lens	-	-	-	-	
		EF 17-40mm f/4L USM	Camera and lens	√	√	√	√	Can be balanced at any focal length, do not remove eyepiece cap
		EF 24-70mm f/2.8L II USM	Camera and lens	-	-	-	-	
		EF 24-70mm f/4L IS USM	Camera and lens	√	√	√	√	Can be balanced at 24mm, do not remove eyepiece cap
		EF 24-105mm f/4L IS II USM	Camera and lens	√	√	√	√	Can be balanced at 24mm, do not remove eyepiece cap
		EF 24-105mm f/3.5-5.6 IS STM	Camera and lens	√	√	√	√	Can be balanced at 24mm, do not remove eyepiece cap
		EF 24mm f/1.4L II USM	Camera and lens	√	√	√	√	do not remove eyepiece cap
		EF 35mm f/1.4L II USM	Camera and lens	√	√	√	√	do not remove eyepiece cap
		EF 50mm f/1.2L USM	Camera and lens	√	√	√	√	do not remove eyepiece cap
		EF 50mm f/1.4 USM	Camera and lens	√	√	√	√	do not remove eyepiece cap
		EF 85mm f/1.4L IS USM	Camera and lens	√	√	√	√	do not remove eyepiece cap
		EF 85mm f/1.8 USM	Camera and lens	√	√	√	√	do not remove eyepiece cap
		Sigma 24-70mm f/2.8 DG HSM Art	Camera and lens	-	-	-	-	
		Sigma 35mm f/1.4 DG HSM Art	Camera and lens	√	-	√	-	do not remove eyepiece cap
		Sigma 50mm f/1.4 DG HSM Art	Camera and lens	√	-	√	-	do not remove eyepiece cap
		RF 24-70mm f/2.8 L IS USM	Camera and lens	√	√	√	√	Can be balanced at 24mm, do not remove eyepiece cap
		RF 15-35mm f/2.8 L IS USM	Camera and lens	√	√	√	√	Can be balanced at any focal length
		RF50mm F1.2 L USM	Camera and lens	√	-	√	-	do not remove eyepiece cap
		RF 15-30mm f/4.5-6.3 IS STM	Camera and lens	√	√	-	-	Can be balanced at any focal length
		RF 16mm F2.8 STM	Camera and lens	√	√	-	-	
		RF 24-105mm F4-7.1 IS STM	Camera and lens	√	√	-	-	Can be balanced at any focal length
		RF 24mm f/1.8 Macro IS STM	Camera and lens	√	√	-	-	
		RF 35mm F1.8 MACRO IS STM	Camera and lens	√	√	-	-	
RF-S 18-45mm f/4.5-6.3 IS STM	Camera and lens	√	√	-	-	Can be balanced at any focal length		
RF 50mm F1.8 STM	Camera and lens	√	√	-	-			

Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Canon	EOS RP (use mount adapter EF-RF for non-RF lenses)	EF 16-35mm f/4L IS USM	Camera and lens	√	√	√	√	Can be balanced at any focal length, do not remove eyepiece cap
		EF 16-35mm f/2.8L III USM	Camera and lens	-	-	-	-	
		EF 17-40mm f/4L USM	Camera and lens	√	-	√	-	Can be balanced at any focal length, do not remove eyepiece cap
		EF 24-70mm f/2.8L II USM	Camera and lens	-	-	-	-	
		EF 24-70mm f/4L IS USM	Camera and lens	-	-	-	-	
		EF 24-105mm f/4L IS II USM	Camera and lens	-	-	-	-	
		EF 24-105mm f/3.5-5.6 IS STM	Camera and lens	-	-	-	-	
		EF 24mm f/1.4L II USM	Camera and lens	√	√	√	√	do not remove eyepiece cap
		EF 35mm f/1.4L II USM	Camera and lens	√	√	√	√	do not remove eyepiece cap
		EF 50mm f/1.2L USM	Camera and lens	√	√	√	√	do not remove eyepiece cap
		EF 50mm f/1.4 USM	Camera and lens	√	√	√	√	do not remove eyepiece cap
		EF 85mm f/1.4L IS USM	Camera and lens	√	√	√	√	do not remove eyepiece cap
		EF 85mm f/1.8 USM	Camera and lens	√	√	√	√	do not remove eyepiece cap
		Sigma 24-70mm f/2.8 DG HSM Art	Camera and lens	-	-	-	-	
		Sigma 35mm f/1.4 DG HSM Art	Camera and lens	√	√	√	√	do not remove eyepiece cap
		Sigma 50mm f/1.4 DG HSM Art	Camera and lens	√	√	√	√	do not remove eyepiece cap
		RF 24-70mm f/2.8 L IS USM	Camera and lens	√	√	√	√	Can be balanced at 24mm, do not remove eyepiece cap
		RF 15-35mm f/2.8 L IS USM	Camera and lens	√	√	√	√	Can be balanced at any focal length
		RF50mm F1.2 L USM	Camera and lens	√	-	√	-	do not remove eyepiece cap
		RF 15-30mm f/4.5-6.3 IS STM	Camera and lens	√	√	-	-	Can be balanced at any focal length
		RF 16mm F2.8 STM	Camera and lens	√	√	-	-	
		RF 24-105mm F4-7.1 IS STM	Camera and lens	√	√	-	-	Can be balanced at any focal length
		RF 24mm f/1.8 Macro IS STM	Camera and lens	√	√	-	-	
		RF 35mm F1.8 MACRO IS STM	Camera and lens	√	√	-	-	
		RF-S 18-45mm f/4.5-6.3 IS STM	Camera and lens	√	√	-	-	Can be balanced at any focal length
RF 50mm F1.8 STM	Camera and lens	√	√	-	-			

Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Canon	EOS R7 (use mount adapter EF-RF for non-RF lenses)	EF 16-35mm f/4L IS USM	Camera and lens	√	√	√	√	Can be balanced at any focal length, do not remove eyepiece cap
		EF 16-35mm f/2.8L III USM	Camera and lens	-	-	-	-	
		EF 17-40mm f/4L USM	Camera and lens	√	-	√	-	Can be balanced at any focal length, do not remove eyepiece cap
		EF 24-70mm f/2.8L II USM	Camera and lens	-	-	-	-	
		EF 24-70mm f/4L IS USM	Camera and lens	-	-	-	-	
		EF 24-105mm f/4L IS II USM	Camera and lens	-	-	-	-	
		EF 24-105mm f/3.5-5.6 IS STM	Camera and lens	-	-	-	-	
		EF 24mm f/1.4L II USM	Camera and lens	√	√	√	√	do not remove eyepiece cap
		EF 35mm f/1.4L II USM	Camera and lens	√	√	√	√	do not remove eyepiece cap
		EF 50mm f/1.2L USM	Camera and lens	√	√	√	√	do not remove eyepiece cap
		EF 50mm f/1.4 USM	Camera and lens	√	√	√	√	do not remove eyepiece cap
		EF 85mm f/1.4L IS USM	Camera and lens	√	√	√	√	do not remove eyepiece cap
		EF 85mm f/1.8 USM	Camera and lens	√	√	√	√	do not remove eyepiece cap
		Sigma 24-70mm f/2.8 DG HSM Art	Camera and lens	-	-	-	-	
		Sigma 35mm f/1.4 DG HSM Art	Camera and lens	√	√	√	√	do not remove eyepiece cap
		Sigma 50mm f/1.4 DG HSM Art	Camera and lens	√	√	√	√	do not remove eyepiece cap
		RF 24-70mm f/2.8 L IS USM	Camera and lens	√	√	√	√	Can be balanced at 24mm, do not remove eyepiece cap
		RF 15-35mm f/2.8 L IS USM	Camera and lens	√	√	√	√	Can be balanced at any focal length
		RF50mm F1.2 L USM	Camera and lens	√	-	√	-	do not remove eyepiece cap
		RF 15-30mm f/4.5-6.3 IS STM	Camera and lens	√	√	-	-	Can be balanced at any focal length
		RF 16mm F2.8 STM	Camera and lens	√	√	-	-	
		RF 24-105mm F4-7.1 IS STM	Camera and lens	√	√	-	-	Can be balanced at any focal length
		RF 24mm f/1.8 Macro IS STM	Camera and lens	√	√	-	-	
		RF 35mm F1.8 MACRO IS STM	Camera and lens	√	√	-	-	
		RF-S 18-45mm f/4.5-6.3 IS STM	Camera and lens	√	√	-	-	Can be balanced at any focal length
RF 50mm F1.8 STM	Camera and lens	√	√	-	-			

Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Canon	EOS R8 (use mount adapter EF-RF for non-RF lenses)	EF 16-35mm f/4L IS USM	Camera and lens	√	√	√	√	Can be balanced at any focal length, do not remove eyepiece cap
		EF 16-35mm f/2.8L III USM	Camera and lens	-	-	-	-	
		EF 17-40mm f/4L USM	Camera and lens	√	-	√	-	Can be balanced at any focal length, do not remove eyepiece cap
		EF 24-70mm f/2.8L II USM	Camera and lens	-	-	-	-	
		EF 24-70mm f/4L IS USM	Camera and lens	-	-	-	-	
		EF 24-105mm f/4L IS II USM	Camera and lens	-	-	-	-	
		EF 24-105mm f/3.5-5.6 IS STM	Camera and lens	-	-	-	-	
		EF 24mm f/1.4L II USM	Camera and lens	√	√	√	√	do not remove eyepiece cap
		EF 35mm f/1.4L II USM	Camera and lens	√	√	√	√	do not remove eyepiece cap
		EF 50mm f/1.2L USM	Camera and lens	√	√	√	√	do not remove eyepiece cap
		EF 50mm f/1.4 USM	Camera and lens	√	√	√	√	do not remove eyepiece cap
		EF 85mm f/1.4L IS USM	Camera and lens	√	√	√	√	do not remove eyepiece cap
		EF 85mm f/1.8 USM	Camera and lens	√	√	√	√	do not remove eyepiece cap
		Sigma 24-70mm f/2.8 DG HSM Art	Camera and lens	-	-	-	-	
		Sigma 35mm f/1.4 DG HSM Art	Camera and lens	√	√	√	√	do not remove eyepiece cap
		Sigma 50mm f/1.4 DG HSM Art	Camera and lens	√	√	√	√	do not remove eyepiece cap
		RF 24-70mm f/2.8 L IS USM	Camera and lens	√	√	√	√	Can be balanced at 24mm, do not remove eyepiece cap
		RF 15-35mm f/2.8 L IS USM	Camera and lens	√	√	√	√	Can be balanced at any focal length
		RF50mm F1.2 L USM	Camera and lens	√	-	√	-	do not remove eyepiece cap
		RF 15-30mm f/4.5-6.3 IS STM	Camera and lens	√	√	-	-	Can be balanced at any focal length
		RF 16mm F2.8 STM	Camera and lens	√	√	-	-	
		RF 24-105mm F4-7.1 IS STM	Camera and lens	√	√	-	-	Can be balanced at any focal length
		RF 24mm f/1.8 Macro IS STM	Camera and lens	√	√	-	-	
		RF 35mm F1.8 MACRO IS STM	Camera and lens	√	√	-	-	
		RF-S 18-45mm f/4.5-6.3 IS STM	Camera and lens	√	√	-	-	Can be balanced at any focal length
RF 50mm F1.8 STM	Camera and lens	√	√	-	-			

Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Canon	EOS R10 (use mount adapter EF-RF for non-RF lenses)	EF 16-35mm f/4L IS USM	Camera and lens	√	√	√	√	Can be balanced at any focal length, do not remove eyepiece cap
		EF 16-35mm f/2.8L III USM	Camera and lens	-	-	-	-	
		EF 17-40mm f/4L USM	Camera and lens	√	-	√	-	Can be balanced at any focal length, do not remove eyepiece cap
		EF 24-70mm f/2.8L II USM	Camera and lens	-	-	-	-	
		EF 24-70mm f/4L IS USM	Camera and lens	-	-	-	-	
		EF 24-105mm f/4L IS II USM	Camera and lens	-	-	-	-	
		EF 24-105mm f/3.5-5.6 IS STM	Camera and lens	-	-	-	-	
		EF 24mm f/1.4L II USM	Camera and lens	√	√	√	√	do not remove eyepiece cap
		EF 35mm f/1.4L II USM	Camera and lens	√	√	√	√	do not remove eyepiece cap
		EF 50mm f/1.2L USM	Camera and lens	√	√	√	√	do not remove eyepiece cap
		EF 50mm f/1.4 USM	Camera and lens	√	√	√	√	do not remove eyepiece cap
		EF 85mm f/1.4L IS USM	Camera and lens	√	√	√	√	do not remove eyepiece cap
		EF 85mm f/1.8 USM	Camera and lens	√	√	√	√	do not remove eyepiece cap
		Sigma 24-70mm f/2.8 DG HSM Art	Camera and lens	-	-	-	-	
		Sigma 35mm f/1.4 DG HSM Art	Camera and lens	√	√	√	√	do not remove eyepiece cap
		Sigma 50mm f/1.4 DG HSM Art	Camera and lens	√	√	√	√	do not remove eyepiece cap
		RF 24-70mm f/2.8 L IS USM	Camera and lens	√	√	√	√	Can be balanced at 24mm, do not remove eyepiece cap
		RF 15-35mm f/2.8 L IS USM	Camera and lens	√	√	√	√	Can be balanced at any focal length
		RF50mm F1.2 L USM	Camera and lens	√	-	√	-	do not remove eyepiece cap
		RF 14-35mm F4 L IS USM	Camera and lens	√	√	-	-	Can be balanced at any focal length
		RF 15-30mm f/4.5-6.3 IS STM	Camera and lens	√	√	-	-	Can be balanced at any focal length
		RF 16mm F2.8 STM	Camera and lens	√	√	-	-	
		RF 24-105mm F4-7.1 IS STM	Camera and lens	√	√	-	-	Can be balanced at any focal length
		RF 24mm f/1.8 Macro IS STM	Camera and lens	√	√	-	-	
		RF 35mm F1.8 MACRO IS STM	Camera and lens	√	√	-	-	
		RF-S 18-45mm f/4.5-6.3 IS STM	Camera and lens	√	√	-	-	Can be balanced at any focal length
RF 50mm F1.8 STM	Camera and lens	√	√	-	-			

Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Canon	EOS M50	EF-M 32mm f/1.4 STM	Camera and lens	√	√	√	√	
		EF-M 11-22mm f/4-5.6 IS STM	Camera and lens	√	√	√	√	
		EF-M 15-45mm f/3.5-6.3 IS STM	Camera and lens	√	√	√	√	
		EF-M 18-55mm f/3.5-5.6 IS STM	Camera and lens	√	√	√	√	
		EF-M 18-150mm f/3.5-6.3 IS STM	Camera and lens	√	√	√	√	
		EF-M 55-200mm f/4.5-6.3 IS STM	Camera and lens	√	√	√	√	
		EF-M 22mm f/2 STM	Camera and lens	√	√	√	√	
		EF-M 28mm f/3.5 IS STM	Camera and lens	√	√	√	√	
	EOS M6 Mark II	EF-M 32mm f/1.4 STM	Camera and lens	√	√	√	√	
		EF-M 11-22mm f/4-5.6 IS STM	Camera and lens	√	√	√	√	
		EF-M 15-45mm f/3.5-6.3 IS STM	Camera and lens	√	√	√	√	
		EF-M 18-55mm f/3.5-5.6 IS STM	Camera and lens	√	√	√	√	
		EF-M 18-150mm f/3.5-6.3 IS STM	Camera and lens	√	√	√	√	
		EF-M 55-200mm f/4.5-6.3 IS STM	Camera and lens	√	√	√	√	
EF-M 22mm f/2 STM		Camera and lens	√	√	√	√		
EF-M 28mm f/3.5 IS STM		Camera and lens	√	√	√	√		

Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Nikon	D850	AF-S NIKKOR 14-24mm f/2.8G ED	Camera and lens	-	-	-	-	
		AF-S NIKKOR 16-35mm f/4G ED VR	Camera and lens	√	-	√	-	Can be balanced at any focal length, no need to remove eyepiece cap
		AF-S NIKKOR 24-70mm f/2.8E ED VR	Camera and lens	-	-	-	-	
		AF-S NIKKOR 24-70mm f/2.8G ED	Camera and lens	-	-	-	-	
		AF-S NIKKOR 24-120mm f/4G ED VR	Camera and lens	√	-	√	-	Can be balanced at any focal length, no need to remove eyepiece cap
		AF-S NIKKOR 24mm f/1.4G ED	Camera and lens	√	-	√	-	no need to remove eyepiece cap
		AF-S NIKKOR 24mm f/1.8G ED	Camera and lens	√	-	√	-	no need to remove eyepiece cap
		AF-S NIKKOR 35mm f/1.4G	Camera and lens	√	-	√	-	no need to remove eyepiece cap
		AF-S NIKKOR 50mm f/1.4G	Camera and lens	√	-	√	-	no need to remove eyepiece cap
		AF-S NIKKOR 85mm f/1.4G	Camera and lens	√	-	√	-	no need to remove eyepiece cap
		AF-S NIKKOR 85mm f/1.8G	Camera and lens	√	-	√	-	no need to remove eyepiece cap
		Sigma 24-70mm f/2.8L DG	Camera and lens	√	-	√	-	Can be balanced at 24mm, no need to remove eyepiece cap
		Sigma 35mm F1.4 DG	Camera and lens	√	-	√	-	no need to remove eyepiece cap
		Sigma 50mm F1.4 DG	Camera and lens	√	-	√	-	no need to remove eyepiece cap



Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Nikon	D780	AF-S NIKKOR 14-24mm f/2.8G ED	Camera and lens	-	-	-	-	
		AF-S NIKKOR 16-35mm f/4G ED VR	Camera and lens	√	-	√	-	Can be balanced at any focal length, no need to remove eyepiece cap
		AF-S NIKKOR 24-70mm f/2.8E ED VR	Camera and lens	-	-	-	-	
		AF-S NIKKOR 24-70mm f/2.8G ED	Camera and lens	-	-	-	-	
		AF-S NIKKOR 24-120mm f/4G ED VR	Camera and lens	√	-	√	-	Can be balanced at any focal length, no need to remove eyepiece cap
		AF-S NIKKOR 24mm f/1.4G ED	Camera and lens	√	-	√	-	no need to remove eyepiece cap
		AF-S NIKKOR 24mm f/1.8G ED	Camera and lens	√	-	√	-	no need to remove eyepiece cap
		AF-S NIKKOR 35mm f/1.4G	Camera and lens	√	-	√	-	no need to remove eyepiece cap
		AF-S NIKKOR 50mm f/1.4G	Camera and lens	√	-	√	-	no need to remove eyepiece cap
		AF-S NIKKOR 85mm f/1.4G	Camera and lens	√	-	√	-	no need to remove eyepiece cap
		AF-S NIKKOR 85mm f/1.8G	Camera and lens	√	-	√	-	no need to remove eyepiece cap
		Sigma 24-70mm f/2.8L DG	Camera and lens	√	-	√	-	Can be balanced at 24mm, no need to remove eyepiece cap
		Sigma 35mm F1.4 DG	Camera and lens	√	-	√	-	no need to remove eyepiece cap
		Sigma 50mm F1.4 DG	Camera and lens	√	-	√	-	no need to remove eyepiece cap

Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Nikon	Z fc	NIKKOR Z 24-70mm f/2.8S	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		NIKKOR Z 24-70mm f/4S	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		NIKKOR Z 35mm f/1.8S	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		NIKKOR Z 50mm f/1.8S	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		AF-S NIKKOR 14-24mm f/2.8G ED	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		AF-S NIKKOR 16-35mm f/4G ED VR	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		AF-S NIKKOR 24-70mm f/2.8E ED VR	Camera and lens	-	-	-	-	
		AF-S NIKKOR 24-70mm f/2.8G ED	Camera and lens	-	-	-	-	
		AF-S NIKKOR 24-120mm f/4G ED VR	Camera and lens	-	-	-	-	
		AF-S NIKKOR 24mm f/1.4G ED	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap
		AF-S NIKKOR 24mm f/1.8G ED	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap
		AF-S NIKKOR 35mm f/1.4G	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap
		AF-S NIKKOR 50mm f/1.4G	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap
		Sigma 24-70mm f/2.8L DG	Camera and lens	√	√	√	√	Can be balanced at 24mm, need to remove eyepiece cap
		Sigma 35mm F1.4 DG	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap
		Sigma 50mm F1.4 DG	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap
		AF-S NIKKOR 20mm f/1.8G ED	Camera and lens	√	√	-	-	
		NIKKOR Z 20mm f/1.8 S	Camera and lens	√	√	-	-	
		NIKKOR Z 24mm f/1.8 S	Camera and lens	√	√	-	-	
		NIKKOR Z 28mm f/2.8	Camera and lens	√	√	-	-	
		NIKKOR Z 35mm f/1.8 S	Camera and lens	√	√	-	-	
		NIKKOR Z 40mm f/2	Camera and lens	√	√	-	-	
		NIKKOR Z 50mm f/1.8 S	Camera and lens	√	√	-	-	
		NIKKOR Z 85mm f/1.8 S	Camera and lens	√	√	-	-	
		NIKKOR Z DX 16-50mm f/3.5-6.3 VR	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		NIKKOR Z 14-30mm f/4 S	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		AF-S NIKKOR 18-35mm f/3.5-4.5G ED	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		NIKKOR Z 17-28mm f/2.8	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		NIKKOR Z 24-50mm f/4-6.3	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap

Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Nikon	Z50	NIKKOR Z 24-70mm f/2.8S	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		NIKKOR Z 24-70mm f/4S	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		NIKKOR Z 35mm f/1.8S	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		NIKKOR Z 50mm f/1.8S	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		AF-S NIKKOR 14-24mm f/2.8G ED	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		AF-S NIKKOR 16-35mm f/4G ED VR	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		AF-S NIKKOR 24-70mm f/2.8E ED VR	Camera and lens	-	-	-	-	
		AF-S NIKKOR 24-70mm f/2.8G ED	Camera and lens	-	-	-	-	
		AF-S NIKKOR 24-120mm f/4G ED VR	Camera and lens	-	-	-	-	
		AF-S NIKKOR 24mm f/1.4G ED	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap
		AF-S NIKKOR 24mm f/1.8G ED	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap
		AF-S NIKKOR 35mm f/1.4G	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap
		AF-S NIKKOR 50mm f/1.4G	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap
		Sigma 24-70mm f/2.8L DG	Camera and lens	√	√	√	√	Can be balanced at 24mm, need to remove eyepiece cap
		Sigma 35mm F1.4 DG	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap
		Sigma 50mm F1.4 DG	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap
		AF-S NIKKOR 20mm f/1.8G ED	Camera and lens	√	√	-	-	
		NIKKOR Z 20mm f/1.8 S	Camera and lens	√	√	-	-	
		NIKKOR Z 24mm f/1.8 S	Camera and lens	√	√	-	-	
		NIKKOR Z 28mm f/2.8	Camera and lens	√	√	-	-	
		NIKKOR Z 35mm f/1.8 S	Camera and lens	√	√	-	-	
		NIKKOR Z 40mm f/2	Camera and lens	√	√	-	-	
		NIKKOR Z 50mm f/1.8 S	Camera and lens	√	√	-	-	
		NIKKOR Z 85mm f/1.8 S	Camera and lens	√	√	-	-	
		NIKKOR Z DX 16-50mm f/3.5-6.3 VR	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		NIKKOR Z 14-30mm f/4 S	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		AF-S NIKKOR 18-35mm f/3.5-4.5G ED	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		NIKKOR Z 17-28mm f/2.8	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		NIKKOR Z 24-50mm f/4-6.3	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap

Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Nikon	Z5	NIKKOR Z 24-70mm f/2.8S	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		NIKKOR Z 24-70mm f/4S	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		NIKKOR Z 35mm f/1.8S	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		NIKKOR Z 50mm f/1.8S	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		AF-S NIKKOR 14-24mm f/2.8G ED	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		AF-S NIKKOR 16-35mm f/4G ED VR	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		AF-S NIKKOR 24-70mm f/2.8E ED VR	Camera and lens	-	-	-	-	
		AF-S NIKKOR 24-70mm f/2.8G ED	Camera and lens	-	-	-	-	
		AF-S NIKKOR 24-120mm f/4G ED VR	Camera and lens	-	-	-	-	
		AF-S NIKKOR 24mm f/1.4G ED	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap
		AF-S NIKKOR 24mm f/1.8G ED	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap
		AF-S NIKKOR 35mm f/1.4G	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap
		AF-S NIKKOR 50mm f/1.4G	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap
		Sigma 24-70mm f/2.8L DG	Camera and lens	√	√	√	√	Can be balanced at 24mm, need to remove eyepiece cap
		Sigma 35mm F1.4 DG	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap
		Sigma 50mm F1.4 DG	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap
		AF-S NIKKOR 20mm f/1.8G ED	Camera and lens	√	√	-	-	
		NIKKOR Z 20mm f/1.8 S	Camera and lens	√	√	-	-	
		NIKKOR Z 24mm f/1.8 S	Camera and lens	√	√	-	-	
		NIKKOR Z 28mm f/2.8	Camera and lens	√	√	-	-	
		NIKKOR Z 35mm f/1.8 S	Camera and lens	√	√	-	-	
		NIKKOR Z 40mm f/2	Camera and lens	√	√	-	-	
		NIKKOR Z 50mm f/1.8 S	Camera and lens	√	√	-	-	
		NIKKOR Z 85mm f/1.8 S	Camera and lens	√	√	-	-	
		NIKKOR Z DX 16-50mm f/3.5-6.3 VR	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		NIKKOR Z 14-30mm f/4 S	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		AF-S NIKKOR 18-35mm f/3.5-4.5G ED	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		NIKKOR Z 17-28mm f/2.8	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		NIKKOR Z 24-50mm f/4-6.3	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap

Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Nikon	Z6	NIKKOR Z 24-70mm f/2.8S	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		NIKKOR Z 24-70mm f/4S	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		NIKKOR Z 35mm f/1.8S	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		NIKKOR Z 50mm f/1.8S	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		AF-S NIKKOR 14-24mm f/2.8G ED	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		AF-S NIKKOR 16-35mm f/4G ED VR	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		AF-S NIKKOR 24-70mm f/2.8E ED VR	Camera and lens	-	-	-	-	
		AF-S NIKKOR 24-70mm f/2.8G ED	Camera and lens	-	-	-	-	
		AF-S NIKKOR 24-120mm f/4G ED VR	Camera and lens	-	-	-	-	
		AF-S NIKKOR 24mm f/1.4G ED	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap
		AF-S NIKKOR 24mm f/1.8G ED	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap
		AF-S NIKKOR 35mm f/1.4G	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap
		AF-S NIKKOR 50mm f/1.4G	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap
		Sigma 24-70mm f/2.8L DG	Camera and lens	√	√	√	√	Can be balanced at 24mm, need to remove eyepiece cap
		Sigma 35mm F1.4 DG	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap
		Sigma 50mm F1.4 DG	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap
		AF-S NIKKOR 20mm f/1.8G ED	Camera and lens	√	√	-	-	
		NIKKOR Z 20mm f/1.8 S	Camera and lens	√	√	-	-	
		NIKKOR Z 24mm f/1.8 S	Camera and lens	√	√	-	-	
		NIKKOR Z 28mm f/2.8	Camera and lens	√	√	-	-	
		NIKKOR Z 35mm f/1.8 S	Camera and lens	√	√	-	-	
		NIKKOR Z 40mm f/2	Camera and lens	√	√	-	-	
		NIKKOR Z 50mm f/1.8 S	Camera and lens	√	√	-	-	
		NIKKOR Z 85mm f/1.8 S	Camera and lens	√	√	-	-	
		NIKKOR Z DX 16-50mm f/3.5-6.3 VR	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		NIKKOR Z 14-30mm f/4 S	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		AF-S NIKKOR 18-35mm f/3.5-4.5G ED	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		NIKKOR Z 17-28mm f/2.8	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		NIKKOR Z 24-50mm f/4-6.3	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap

Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Nikon	Z6 II, Z6 III	NIKKOR Z 24-70mm f/2.8S	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		NIKKOR Z 24-70mm f/4S	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		NIKKOR Z 35mm f/1.8S	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		NIKKOR Z 50mm f/1.8S	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		AF-S NIKKOR 14-24mm f/2.8G ED	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		AF-S NIKKOR 16-35mm f/4G ED VR	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		AF-S NIKKOR 24-70mm f/2.8E ED VR	Camera and lens	-	-	-	-	
		AF-S NIKKOR 24-70mm f/2.8G ED	Camera and lens	-	-	-	-	
		AF-S NIKKOR 24-120mm f/4G ED VR	Camera and lens	-	-	-	-	
		AF-S NIKKOR 24mm f/1.4G ED	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap
		AF-S NIKKOR 24mm f/1.8G ED	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap
		AF-S NIKKOR 35mm f/1.4G	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap
		AF-S NIKKOR 50mm f/1.4G	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap
		Sigma 24-70mm f/2.8L DG	Camera and lens	√	√	√	√	Can be balanced at 24mm, need to remove eyepiece cap
		Sigma 35mm F1.4 DG	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap
		Sigma 50mm F1.4 DG	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap
		NIKKOR Z 24-70mm f/2.8S	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		NIKKOR Z 24-70mm f/4S	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		NIKKOR Z 35mm f/1.8S	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		NIKKOR Z 50mm f/1.8S	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		AF-S NIKKOR 14-24mm f/2.8G ED	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		AF-S NIKKOR 16-35mm f/4G ED VR	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		AF-S NIKKOR 24-70mm f/2.8E ED VR	Camera and lens	-	-	-	-	
		AF-S NIKKOR 24-70mm f/2.8G ED	Camera and lens	-	-	-	-	
		AF-S NIKKOR 24-120mm f/4G ED VR	Camera and lens	-	-	-	-	

Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Nikon	Z6 II, Z6 III	AF-S NIKKOR 24mm f/1.4G ED	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap
		AF-S NIKKOR 24mm f/1.8G ED	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap
		AF-S NIKKOR 35mm f/1.4G	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap
		AF-S NIKKOR 50mm f/1.4G	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap
		Sigma 24-70mm f/2.8L DG	Camera and lens	√	√	√	√	Can be balanced at 24mm, need to remove eyepiece cap
		Sigma 35mm F1.4 DG	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap
		Sigma 50mm F1.4 DG	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap
		AF-S NIKKOR 20mm f/1.8G ED	Camera and lens	√	√	-	-	
		NIKKOR Z 20mm f/1.8 S	Camera and lens	√	√	-	-	
		NIKKOR Z 24mm f/1.8 S	Camera and lens	√	√	-	-	
		NIKKOR Z 28mm f/2.8	Camera and lens	√	√	-	-	
		NIKKOR Z 35mm f/1.8 S	Camera and lens	√	√	-	-	
		NIKKOR Z 40mm f/2	Camera and lens	√	√	-	-	
		NIKKOR Z 50mm f/1.8 S	Camera and lens	√	√	-	-	
		NIKKOR Z 85mm f/1.8 S	Camera and lens	√	√	-	-	
		NIKKOR Z DX 16-50mm f/3.5-6.3 VR	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		NIKKOR Z 14-30mm f/4 S	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		AF-S NIKKOR 18-35mm f/3.5-4.5G ED	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		NIKKOR Z 17-28mm f/2.8	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		NIKKOR Z 24-50mm f/4-6.3	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap

Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Nikon	Z7	NIKKOR Z 24-70mm f/2.8S	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		NIKKOR Z 24-70mm f/4S	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		NIKKOR Z 35mm f/1.8S	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		NIKKOR Z 50mm f/1.8S	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		AF-S NIKKOR 14-24mm f/2.8G ED	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		AF-S NIKKOR 16-35mm f/4G ED VR	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		AF-S NIKKOR 24-70mm f/2.8E ED VR	Camera and lens	-	-	-	-	
		AF-S NIKKOR 24-70mm f/2.8G ED	Camera and lens	-	-	-	-	
		AF-S NIKKOR 24-120mm f/4G ED VR	Camera and lens	-	-	-	-	
		AF-S NIKKOR 24mm f/1.4G ED	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap
		AF-S NIKKOR 24mm f/1.8G ED	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap
		AF-S NIKKOR 35mm f/1.4G	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap
		AF-S NIKKOR 50mm f/1.4G	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap
		Sigma 24-70mm f/2.8L DG	Camera and lens	√	√	√	√	Can be balanced at 24mm, need to remove eyepiece cap
		Sigma 35mm F1.4 DG	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap
		Sigma 50mm F1.4 DG	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap
		AF-S NIKKOR 20mm f/1.8G ED	Camera and lens	√	√	-	-	
		NIKKOR Z 20mm f/1.8 S	Camera and lens	√	√	-	-	
		NIKKOR Z 24mm f/1.8 S	Camera and lens	√	√	-	-	
		NIKKOR Z 28mm f/2.8	Camera and lens	√	√	-	-	
		NIKKOR Z 35mm f/1.8 S	Camera and lens	√	√	-	-	
		NIKKOR Z 40mm f/2	Camera and lens	√	√	-	-	
		NIKKOR Z 50mm f/1.8 S	Camera and lens	√	√	-	-	
		NIKKOR Z 85mm f/1.8 S	Camera and lens	√	√	-	-	
		NIKKOR Z DX 16-50mm f/3.5-6.3 VR	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		NIKKOR Z 14-30mm f/4 S	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		AF-S NIKKOR 18-35mm f/3.5-4.5G ED	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		NIKKOR Z 17-28mm f/2.8	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		NIKKOR Z 24-50mm f/4-6.3	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap

Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Nikon	Z7 II	NIKKOR Z 24-70mm f/2.8S	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		NIKKOR Z 24-70mm f/4S	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		NIKKOR Z 35mm f/1.8S	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		NIKKOR Z 50mm f/1.8S	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		AF-S NIKKOR 14-24mm f/2.8G ED	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		AF-S NIKKOR 16-35mm f/4G ED VR	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		AF-S NIKKOR 24-70mm f/2.8E ED VR	Camera and lens	-	-	-	-	
		AF-S NIKKOR 24-70mm f/2.8G ED	Camera and lens	-	-	-	-	
		AF-S NIKKOR 24-120mm f/4G ED VR	Camera and lens	-	-	-	-	
		AF-S NIKKOR 24mm f/1.4G ED	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap
		AF-S NIKKOR 24mm f/1.8G ED	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap
		AF-S NIKKOR 35mm f/1.4G	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap
		AF-S NIKKOR 50mm f/1.4G	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap
		Sigma 24-70mm f/2.8L DG	Camera and lens	√	√	√	√	Can be balanced at 24mm, need to remove eyepiece cap
		Sigma 35mm F1.4 DG	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap
		Sigma 50mm F1.4 DG	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap
		AF-S NIKKOR 20mm f/1.8G ED	Camera and lens	√	√	-	-	
		NIKKOR Z 20mm f/1.8 S	Camera and lens	√	√	-	-	
		NIKKOR Z 24mm f/1.8 S	Camera and lens	√	√	-	-	
		NIKKOR Z 28mm f/2.8	Camera and lens	√	√	-	-	
		NIKKOR Z 35mm f/1.8 S	Camera and lens	√	√	-	-	
		NIKKOR Z 40mm f/2	Camera and lens	√	√	-	-	
		NIKKOR Z 50mm f/1.8 S	Camera and lens	√	√	-	-	
		NIKKOR Z 85mm f/1.8 S	Camera and lens	√	√	-	-	
		NIKKOR Z DX 16-50mm f/3.5-6.3 VR	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		NIKKOR Z 14-30mm f/4 S	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		AF-S NIKKOR 18-35mm f/3.5-4.5G ED	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		NIKKOR Z 17-28mm f/2.8	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		NIKKOR Z 24-50mm f/4-6.3	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap

Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Nikon	Z30	NIKKOR Z 24-70mm f/2.8S	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		NIKKOR Z 24-70mm f/4S	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		NIKKOR Z 35mm f/1.8S	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		NIKKOR Z 50mm f/1.8S	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		AF-S NIKKOR 14-24mm f/2.8G ED	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		AF-S NIKKOR 16-35mm f/4G ED VR	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		AF-S NIKKOR 24-70mm f/2.8E ED VR	Camera and lens	-	-	-	-	
		AF-S NIKKOR 24-70mm f/2.8G ED	Camera and lens	-	-	-	-	
		AF-S NIKKOR 24-120mm f/4G ED VR	Camera and lens	-	-	-	-	
		AF-S NIKKOR 24mm f/1.4G ED	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap
		AF-S NIKKOR 24mm f/1.8G ED	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap
		AF-S NIKKOR 35mm f/1.4G	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap
		AF-S NIKKOR 50mm f/1.4G	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap
		Sigma 24-70mm f/2.8L DG	Camera and lens	√	√	√	√	Can be balanced at 24mm, need to remove eyepiece cap
		Sigma 35mm F1.4 DG	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap
		Sigma 50mm F1.4 DG	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap
		AF-S NIKKOR 20mm f/1.8G ED	Camera and lens	√	√	-	-	
		NIKKOR Z 20mm f/1.8 S	Camera and lens	√	√	-	-	
		NIKKOR Z 24mm f/1.8 S	Camera and lens	√	√	-	-	
		NIKKOR Z 28mm f/2.8	Camera and lens	√	√	-	-	
		NIKKOR Z 35mm f/1.8 S	Camera and lens	√	√	-	-	
		NIKKOR Z 40mm f/2	Camera and lens	√	√	-	-	
		NIKKOR Z 50mm f/1.8 S	Camera and lens	√	√	-	-	
		NIKKOR Z 85mm f/1.8 S	Camera and lens	√	√	-	-	
		NIKKOR Z DX 16-50mm f/3.5-6.3 VR	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		NIKKOR Z 14-30mm f/4 S	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		AF-S NIKKOR 18-35mm f/3.5-4.5G ED	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		NIKKOR Z 17-28mm f/2.8	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		NIKKOR Z 24-50mm f/4-6.3	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap

Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Nikon	Z50	NIKKOR Z 24-70mm f/2.8S	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		NIKKOR Z 24-70mm f/4S	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		NIKKOR Z 35mm f/1.8S	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		NIKKOR Z 50mm f/1.8S	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		AF-S NIKKOR 14-24mm f/2.8G ED	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		AF-S NIKKOR 16-35mm f/4G ED VR	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		AF-S NIKKOR 24-70mm f/2.8E ED VR	Camera and lens	-	-	-	-	
		AF-S NIKKOR 24-70mm f/2.8G ED	Camera and lens	-	-	-	-	
		AF-S NIKKOR 24-120mm f/4G ED VR	Camera and lens	-	-	-	-	
		AF-S NIKKOR 24mm f/1.4G ED	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap
		AF-S NIKKOR 24mm f/1.8G ED	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap
		AF-S NIKKOR 35mm f/1.4G	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap
		AF-S NIKKOR 50mm f/1.4G	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap
		Sigma 24-70mm f/2.8L DG	Camera and lens	√	√	√	√	Can be balanced at 24mm, need to remove eyepiece cap
		Sigma 35mm F1.4 DG	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap
		Sigma 50mm F1.4 DG	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap
		AF-S NIKKOR 20mm f/1.8G ED	Camera and lens	√	√	-	-	
		NIKKOR Z 20mm f/1.8 S	Camera and lens	√	√	-	-	
		NIKKOR Z 24mm f/1.8 S	Camera and lens	√	√	-	-	
		NIKKOR Z 28mm f/2.8	Camera and lens	√	√	-	-	
		NIKKOR Z 35mm f/1.8 S	Camera and lens	√	√	-	-	
		NIKKOR Z 40mm f/2	Camera and lens	√	√	-	-	
		NIKKOR Z 50mm f/1.8 S	Camera and lens	√	√	-	-	
		NIKKOR Z 85mm f/1.8 S	Camera and lens	√	√	-	-	
		NIKKOR Z DX 16-50mm f/3.5-6.3 VR	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		NIKKOR Z 14-30mm f/4 S	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		AF-S NIKKOR 18-35mm f/3.5-4.5G ED	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		NIKKOR Z 17-28mm f/2.8	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		NIKKOR Z 24-50mm f/4-6.3	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap

Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Nikon	Z50 II	NIKKOR Z 24-70mm f/2.8S	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		NIKKOR Z 24-70mm f/4S	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		NIKKOR Z 35mm f/1.8S	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		NIKKOR Z 50mm f/1.8S	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		AF-S NIKKOR 14-24mm f/2.8G ED	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		AF-S NIKKOR 16-35mm f/4G ED VR	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		AF-S NIKKOR 24-70mm f/2.8E ED VR	Camera and lens	-	-	-	-	
		AF-S NIKKOR 24-70mm f/2.8G ED	Camera and lens	-	-	-	-	
		AF-S NIKKOR 24-120mm f/4G ED VR	Camera and lens	-	-	-	-	
		AF-S NIKKOR 24mm f/1.4G ED	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap
		AF-S NIKKOR 24mm f/1.8G ED	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap
		AF-S NIKKOR 35mm f/1.4G	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap
		AF-S NIKKOR 50mm f/1.4G	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap
		Sigma 24-70mm f/2.8L DG	Camera and lens	√	√	√	√	Can be balanced at 24mm, need to remove eyepiece cap
		Sigma 35mm F1.4 DG	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap
		Sigma 50mm F1.4 DG	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap
		AF-S NIKKOR 20mm f/1.8G ED	Camera and lens	√	√	-	-	
		NIKKOR Z 20mm f/1.8 S	Camera and lens	√	√	-	-	
		NIKKOR Z 24mm f/1.8 S	Camera and lens	√	√	-	-	
		NIKKOR Z 28mm f/2.8	Camera and lens	√	√	-	-	
		NIKKOR Z 35mm f/1.8 S	Camera and lens	√	√	-	-	
		NIKKOR Z 40mm f/2	Camera and lens	√	√	-	-	
		NIKKOR Z 50mm f/1.8 S	Camera and lens	√	√	-	-	
		NIKKOR Z 85mm f/1.8 S	Camera and lens	√	√	-	-	
		NIKKOR Z DX 16-50mm f/3.5-6.3 VR	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		NIKKOR Z 14-30mm f/4 S	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		AF-S NIKKOR 18-35mm f/3.5-4.5G ED	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		NIKKOR Z 17-28mm f/2.8	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		NIKKOR Z 24-50mm f/4-6.3	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap

Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Nikon	Z8	NIKKOR Z 24-70mm f/2.8S	Camera and lens	√	√	√	√	Horizontal: eyepiece cap slightly rubs against the camera at 24-35mm. Vertical: can be balanced at any focal length
		NIKKOR Z 24-70mm f/4S	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		NIKKOR Z 35mm f/1.8S	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		NIKKOR Z 50mm f/1.8S	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		AF-S NIKKOR 14-24mm f/2.8G ED	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		AF-S NIKKOR 16-35mm f/4G ED VR	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		AF-S NIKKOR 24-70mm f/2.8E ED VR	Camera and lens	-	-	-	-	
		AF-S NIKKOR 24-70mm f/2.8G ED	Camera and lens	-	-	-	-	
		AF-S NIKKOR 24-120mm f/4G ED VR	Camera and lens	-	-	-	-	
		AF-S NIKKOR 24mm f/1.4G ED	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap
		AF-S NIKKOR 24mm f/1.8G ED	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap
		AF-S NIKKOR 35mm f/1.4G	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap
		AF-S NIKKOR 50mm f/1.4G	Camera and lens	-	-	-	-	
		Sigma 24-70mm f/2.8L DG	Camera and lens	-	-	-	-	
		Sigma 35mm F1.4 DG	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap
		Sigma 50mm F1.4 DG	Camera and lens	-	-	-	-	
		AF-S NIKKOR 20mm f/1.8G ED	Camera and lens	√	√	-	-	
		NIKKOR Z 20mm f/1.8 S	Camera and lens	√	√	-	-	
		NIKKOR Z 24mm f/1.8 S	Camera and lens	√	√	-	-	
		NIKKOR Z 28mm f/2.8	Camera and lens	√	√	-	-	
		NIKKOR Z 35mm f/1.8 S	Camera and lens	√	√	-	-	
		NIKKOR Z 40mm f/2	Camera and lens	√	√	-	-	
		NIKKOR Z 50mm f/1.8 S	Camera and lens	√	√	-	-	
		NIKKOR Z 85mm f/1.8 S	Camera and lens	√	√	-	-	
		NIKKOR Z DX 16-50mm f/3.5-6.3 VR	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		NIKKOR Z 14-30mm f/4 S	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		AF-S NIKKOR 18-35mm f/3.5-4.5G ED	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		NIKKOR Z 17-28mm f/2.8	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		NIKKOR Z 24-50mm f/4-6.3	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap

Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Sony	α1	FE 16-35mm F2.8 GM	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 16-35mm F4 ZAISS	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 12-24mm F4 G	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 24mm f1.4GM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		FE 24-70mm F4 ZA OSS	Camera and lens	√	√	√	√	Can be balanced at 24-50mm, need to remove eyepiece cap
		FE 28mm F2	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		FE 50mm F1.8	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		FE 85mm F1.4 GM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Distagon T* FE 35mm F1.4 ZA	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Sonnar T* FE 35mm F2.8 ZA	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Sonnar® T* FE 55mm F1.8 ZA	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		E 10-18mm F4 OSS	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		E PZ 18-105mm F4 G OSS	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		E 18-200mm F3.5-6.3 OSS LE	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		Sigma 30mm f/1.4 DC DN	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Sigma 50mm f/1.4 DG	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Tamron 28-75mm f/2.8	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap

Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Sony	α1	sigma18-35mm f/1.8 DC HSM Art (+Canon adapter ring)	Camera and lens	√	-	√	-	Can be balanced at any focal length, no need to remove eyepiece cap
		E 20mm F2.8	Camera and lens	√	√	-	-	
		E 3.5-5.6/PZ 16-50 OSS	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		E 35 mm F1.8 OSS	Camera and lens	√	√	-	-	
		E PZ 10-20mm F4 G	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 14mm F1.8 GM	Camera and lens	√	√	-	-	
		FE 24mm F2.8 G	Camera and lens	√	√	-	-	
		FE 35mm F1.8	Camera and lens	√	√	-	-	
		FE 40mm F2.5 G	Camera and lens	√	√	-	-	
		FE 50mm F2.5 G	Camera and lens	√	√	-	-	
		FE 50mm F2.8 MACRO	Camera and lens	√	√	-	-	
		FE PZ 16-35mm F4 G	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 24-70mm F2.8 GM	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap(Roll axis slightly rub against the camera)
		FE 24-70mm F2.8 GM II	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap(Roll axis slightly rub against the camera)
		FE 24-105mm F4 G OSS	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap(Roll axis slightly rub against the camera)

Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Sony	α9	FE 16-35mm F2.8 GM	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 16-35mm F4 ZAISS	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 12-24mm F4 G	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 24mm f1.4GM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		FE 24–70mm F4 ZA OSS	Camera and lens	√	√	√	√	Can be balanced at 24-50mm, need to remove eyepiece cap
		FE 28mm F2	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		FE 50mm F1.8	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		FE 85mm F1.4 GM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Distagon T* FE 35mm F1.4 ZA	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Sonnar T* FE 35mm F2.8 ZA	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Sonnar® T* FE 55mm F1.8 ZA	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		E 10–18mm F4 OSS	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		E PZ 18–105mm F4 G OSS	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		E 18–200mm F3.5–6.3 OSS LE	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		Sigma 30mm f/1.4 DC DN	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Sigma 50mm f/1.4 DG	Camera and lens	√	√	√	√	no need to remove eyepiece cap
Tamron 28-75mm f/2.8	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap		



Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Sony	α9	sigma18-35mm f/1.8 DC HSM Art (+Canon adapter ring)	Camera and lens	√	-	√	-	Can be balanced at any focal length, no need to remove eyepiece cap
		E 20mm F2.8	Camera and lens	√	√	-	-	
		E 3.5-5.6/PZ 16-50 OSS	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		E 35 mm F1.8 OSS	Camera and lens	√	√	-	-	
		E PZ 10-20mm F4 G	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 14mm F1.8 GM	Camera and lens	√	√	-	-	
		FE 24mm F2.8 G	Camera and lens	√	√	-	-	
		FE 35mm F1.8	Camera and lens	√	√	-	-	
		FE 40mm F2.5 G	Camera and lens	√	√	-	-	
		FE 50mm F2.5 G	Camera and lens	√	√	-	-	
		FE 50mm F2.8 MACRO	Camera and lens	√	√	-	-	
		FE PZ 16-35mm F4 G	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 24-70mm F2.8 GM	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap(Roll axis slightly rub against the camera)
		FE 24-70mm F2.8 GM II	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap(Roll axis slightly rub against the camera)
		FE 24-105mm F4 G OSS	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap(Roll axis slightly rub against the camera)

Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Sony	α9 II、α9 III	FE 16-35mm F2.8 GM	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 16-35mm F4 ZAISS	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 12-24mm F4 G	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 24mm f1.4GM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		FE 24-70mm F4 ZA OSS	Camera and lens	√	√	√	√	Can be balanced at 24-50mm, need to remove eyepiece cap
		FE 28mm F2	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		FE 50mm F1.8	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		FE 85mm F1.4 GM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Distagon T* FE 35mm F1.4 ZA	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Sonnar T* FE 35mm F2.8 ZA	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Sonnar® T* FE 55mm F1.8 ZA	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		E 10-18mm F4 OSS	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		E PZ 18-105mm F4 G OSS	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		E 18-200mm F3.5-6.3 OSS LE	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		Sigma 30mm f/1.4 DC DN	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Sigma 50mm f/1.4 DG	Camera and lens	√	√	√	√	no need to remove eyepiece cap
Tamron 28-75mm f/2.8	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap		

Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Sony	α9 II、α9 III	sigma18-35mm f/1.8 DC HSM Art (+Canon adapter ring)	Camera and lens	√	-	√	-	Can be balanced at any focal length, no need to remove eyepiece cap
		E 20mm F2.8	Camera and lens	√	√	-	-	
		E 3.5-5.6/PZ 16-50 OSS	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		E 35 mm F1.8 OSS	Camera and lens	√	√	-	-	
		E PZ 10-20mm F4 G	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 14mm F1.8 GM	Camera and lens	√	√	-	-	
		FE 24mm F2.8 G	Camera and lens	√	√	-	-	
		FE 35mm F1.8	Camera and lens	√	√	-	-	
		FE 40mm F2.5 G	Camera and lens	√	√	-	-	
		FE 50mm F2.5 G	Camera and lens	√	√	-	-	
		FE 50mm F2.8 MACRO	Camera and lens	√	√	-	-	
		FE PZ 16-35mm F4 G	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 24-70mm F2.8 GM	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap(Roll axis slightly rub against the camera)
		FE 24-70mm F2.8 GM II	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap(Roll axis slightly rub against the camera)
		FE 24-105mm F4 G OSS	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap(Roll axis slightly rub against the camera)

Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Sony	α7M2	FE 16-35mm F2.8 GM	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 16-35mm F4 ZAISS	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 12-24mm F4 G	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 24mm f1.4GM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		FE 24–70mm F4 ZA OSS	Camera and lens	√	√	√	√	Can be balanced at 24-50mm, need to remove eyepiece cap
		FE 28mm F2	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		FE 50mm F1.8	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		FE 85mm F1.4 GM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Distagon T* FE 35mm F1.4 ZA	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Sonnar T* FE 35mm F2.8 ZA	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Sonnar® T* FE 55mm F1.8 ZA	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		E 10–18mm F4 OSS	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		E PZ 18–105mm F4 G OSS	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		E 18–200mm F3.5–6.3 OSS LE	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		Sigma 30mm f/1.4 DC DN	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Sigma 50mm f/1.4 DG	Camera and lens	√	√	√	√	no need to remove eyepiece cap
Tamron 28-75mm f/2.8	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap		

Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Sony	α7M2	sigma18-35mm f/1.8 DC HSM Art (+Canon adapter ring)	Camera and lens	√	-	√	-	Can be balanced at any focal length, no need to remove eyepiece cap
		E 20mm F2.8	Camera and lens	√	√	-	-	
		E 3.5-5.6/PZ 16-50 OSS	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		E 35 mm F1.8 OSS	Camera and lens	√	√	-	-	
		E PZ 10-20mm F4 G	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 14mm F1.8 GM	Camera and lens	√	√	-	-	
		FE 24mm F2.8 G	Camera and lens	√	√	-	-	
		FE 35mm F1.8	Camera and lens	√	√	-	-	
		FE 40mm F2.5 G	Camera and lens	√	√	-	-	
		FE 50mm F2.5 G	Camera and lens	√	√	-	-	
		FE 50mm F2.8 MACRO	Camera and lens	√	√	-	-	
		FE PZ 16-35mm F4 G	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 24-70mm F2.8 GM	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap(Roll axis slightly rub against the camera)
		FE 24-70mm F2.8 GM II	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap(Roll axis slightly rub against the camera)
		FE 24-105mm F4 G OSS	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap(Roll axis slightly rub against the camera)

Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Sony	α7R2	FE 16-35mm F2.8 GM	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 16-35mm F4 ZAISS	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 12-24mm F4 G	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 24mm f1.4GM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		FE 24-70mm F2.8 GM	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap (Roll axis slightly rub against the camera)
		FE 24-70mm F4 ZA OSS	Camera and lens	√	√	√	√	Can be balanced at 24-50mm, need to remove eyepiece cap
		FE 28mm F2	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		FE 50mm F1.8	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		FE 85mm F1.4 GM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Distagon T* FE 35mm F1.4 ZA	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Sonnar T* FE 35mm F2.8 ZA	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Sonnar® T* FE 55mm F1.8 ZA	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		E 10-18mm F4 OSS	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		E PZ 18-105mm F4 G OSS	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		E 18-200mm F3.5-6.3 OSS LE	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		Sigma 30mm f/1.4 DC DN	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Sigma 50mm f/1.4 DG	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Tamron 28-75mm f/2.8	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap

Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Sony	α7R2	sigma18-35mm f/1.8 DC HSM Art (+Canon adapter ring)	Camera and lens	√	-	√	-	Can be balanced at any focal length, no need to remove eyepiece cap
		E 20mm F2.8	Camera and lens	√	√	-	-	
		E 3.5-5.6/PZ 16-50 OSS	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		E 35 mm F1.8 OSS	Camera and lens	√	√	-	-	
		E PZ 10-20mm F4 G	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 14mm F1.8 GM	Camera and lens	√	√	-	-	
		FE 24mm F2.8 G	Camera and lens	√	√	-	-	
		FE 35mm F1.8	Camera and lens	√	√	-	-	
		FE 40mm F2.5 G	Camera and lens	√	√	-	-	
		FE 50mm F2.5 G	Camera and lens	√	√	-	-	
		FE 50mm F2.8 MACRO	Camera and lens	√	√	-	-	
		FE PZ 16-35mm F4 G	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 24-70mm F2.8 GM	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap (Roll axis slightly rub against the camera)
		FE 24-70mm F2.8 GM II	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap (Roll axis slightly rub against the camera)
		FE 24-105mm F4 G OSS	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap (Roll axis slightly rub against the camera)

Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Sony	α7S2	FE 16-35mm F2.8 GM	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 16-35mm F4 ZAISS	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 12-24mm F4 G	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 24mm f1.4GM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		FE 24-70mm F2.8 GM	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap (Roll axis slightly rub against the camera)
		FE 24-70mm F4 ZA OSS	Camera and lens	√	√	√	√	Can be balanced at 24-50mm, need to remove eyepiece cap
		FE 28mm F2	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		FE 50mm F1.8	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		FE 85mm F1.4 GM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Distagon T* FE 35mm F1.4 ZA	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Sonnar T* FE 35mm F2.8 ZA	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Sonnar® T* FE 55mm F1.8 ZA	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		E 10-18mm F4 OSS	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		E PZ 18-105mm F4 G OSS	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		E 18-200mm F3.5-6.3 OSS LE	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		Sigma 30mm f/1.4 DC DN	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Sigma 50mm f/1.4 DG	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Tamron 28-75mm f/2.8	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap

Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Sony	α7S2	sigma18-35mm f/1.8 DC HSM Art (+Canon adapter ring)	Camera and lens	√	-	√	-	Can be balanced at any focal length, no need to remove eyepiece cap
		E 20mm F2.8	Camera and lens	√	√	-	-	
		E 3.5-5.6/PZ 16-50 OSS	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		E 35 mm F1.8 OSS	Camera and lens	√	√	-	-	
		E PZ 10-20mm F4 G	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 14mm F1.8 GM	Camera and lens	√	√	-	-	
		FE 24mm F2.8 G	Camera and lens	√	√	-	-	
		FE 35mm F1.8	Camera and lens	√	√	-	-	
		FE 40mm F2.5 G	Camera and lens	√	√	-	-	
		FE 50mm F2.5 G	Camera and lens	√	√	-	-	
		FE 50mm F2.8 MACRO	Camera and lens	√	√	-	-	
		FE PZ 16-35mm F4 G	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 24-70mm F2.8 GM	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap (Roll axis slightly rub against the camera)
		FE 24-70mm F2.8 GM II	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap (Roll axis slightly rub against the camera)
		FE 24-105mm F4 G OSS	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap (Roll axis slightly rub against the camera)

Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Sony	α7M3	FE 16-35mm F2.8 GM	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 16-35mm F4 ZAISS	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 12-24mm F4 G	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 24mm f1.4GM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		FE 24-70mm F2.8 GM	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap (Roll axis slightly rub against the camera)
		FE 24-70mm F4 ZA OSS	Camera and lens	√	√	√	√	Can be balanced at 24-50mm, need to remove eyepiece cap
		FE 28mm F2	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		FE 50mm F1.8	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		FE 85mm F1.4 GM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Distagon T* FE 35mm F1.4 ZA	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Sonnar T* FE 35mm F2.8 ZA	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Sonnar® T* FE 55mm F1.8 ZA	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		E 10-18mm F4 OSS	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		E PZ 18-105mm F4 G OSS	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		E 18-200mm F3.5-6.3 OSS LE	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		Sigma 30mm f/1.4 DC DN	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Sigma 50mm f/1.4 DG	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Tamron 28-75mm f/2.8	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap



Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Sony	α7M3	sigma18-35mm f/1.8 DC HSM Art (+Canon adapter ring)	Camera and lens	√	-	√	-	Can be balanced at any focal length, no need to remove eyepiece cap
		E 20mm F2.8	Camera and lens	√	√	-	-	
		E 3.5-5.6/PZ 16-50 OSS	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		E 35 mm F1.8 OSS	Camera and lens	√	√	-	-	
		E PZ 10-20mm F4 G	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 14mm F1.8 GM	Camera and lens	√	√	-	-	
		FE 24mm F2.8 G	Camera and lens	√	√	-	-	
		FE 35mm F1.8	Camera and lens	√	√	-	-	
		FE 40mm F2.5 G	Camera and lens	√	√	-	-	
		FE 50mm F2.5 G	Camera and lens	√	√	-	-	
		FE 50mm F2.8 MACRO	Camera and lens	√	√	-	-	
		FE PZ 16-35mm F4 G	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 24-70mm F2.8 GM	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap (Roll axis slightly rub against the camera)
		FE 24-70mm F2.8 GM II	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap (Roll axis slightly rub against the camera)
		FE 24-105mm F4 G OSS	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap (Roll axis slightly rub against the camera)

Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Sony	α7M4	FE 16-35mm F2.8 GM	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 16-35mm F4 ZAISS	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 12-24mm F4 G	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 24mm f1.4GM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		FE 24-70mm F2.8 GM	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap (Roll axis slightly rub against the camera)
		FE 24-70mm F4 ZA OSS	Camera and lens	√	√	√	√	Can be balanced at 24-50mm, need to remove eyepiece cap
		FE 28mm F2	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		FE 50mm F1.8	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		FE 85mm F1.4 GM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Distagon T* FE 35mm F1.4 ZA	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Sonnar T* FE 35mm F2.8 ZA	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Sonnar® T* FE 55mm F1.8 ZA	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		E 10-18mm F4 OSS	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		E PZ 18-105mm F4 G OSS	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		E 18-200mm F3.5-6.3 OSS LE	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		Sigma 30mm f/1.4 DC DN	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Sigma 50mm f/1.4 DG	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Tamron 28-75mm f/2.8	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap

Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Sony	α7M4	sigma18-35mm f/1.8 DC HSM Art (+Canon adapter ring)	Camera and lens	√	-	√	-	Can be balanced at any focal length, no need to remove eyepiece cap
		E 20mm F2.8	Camera and lens	√	√	-	-	
		E 3.5-5.6/PZ 16-50 OSS	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		E 35 mm F1.8 OSS	Camera and lens	√	√	-	-	
		E PZ 10-20mm F4 G	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 14mm F1.8 GM	Camera and lens	√	√	-	-	
		FE 24mm F2.8 G	Camera and lens	√	√	-	-	
		FE 35mm F1.8	Camera and lens	√	√	-	-	
		FE 40mm F2.5 G	Camera and lens	√	√	-	-	
		FE 50mm F2.5 G	Camera and lens	√	√	-	-	
		FE 50mm F2.8 MACRO	Camera and lens	√	√	-	-	
		FE PZ 16-35mm F4 G	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 24-70mm F2.8 GM	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap (Roll axis slightly rub against the camera)
		FE 24-70mm F2.8 GM II	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap (Roll axis slightly rub against the camera)
		FE 24-105mm F4 G OSS	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap (Roll axis slightly rub against the camera)

Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Sony	α7R3	FE 16-35mm F2.8 GM	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 16-35mm F4 ZAISS	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 12-24mm F4 G	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 24mm f1.4GM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		FE 24-70mm F2.8 GM	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap (Roll axis slightly rub against the camera)
		FE 24-70mm F4 ZA OSS	Camera and lens	√	√	√	√	Can be balanced at 24-50mm, need to remove eyepiece cap
		FE 28mm F2	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		FE 50mm F1.8	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		FE 85mm F1.4 GM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Distagon T* FE 35mm F1.4 ZA	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Sonnar T* FE 35mm F2.8 ZA	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Sonnar® T* FE 55mm F1.8 ZA	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		E 10-18mm F4 OSS	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		E PZ 18-105mm F4 G OSS	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		E 18-200mm F3.5-6.3 OSS LE	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		Sigma 30mm f/1.4 DC DN	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Sigma 50mm f/1.4 DG	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Tamron 28-75mm f/2.8	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap

Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Sony	α7R3	sigma18-35mm f/1.8 DC HSM Art (+Canon adapter ring)	Camera and lens	√	-	√	-	Can be balanced at any focal length, no need to remove eyepiece cap
		E 20mm F2.8	Camera and lens	√	√	-	-	
		E 3.5-5.6/PZ 16-50 OSS	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		E 35 mm F1.8 OSS	Camera and lens	√	√	-	-	
		E PZ 10-20mm F4 G	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 14mm F1.8 GM	Camera and lens	√	√	-	-	
		FE 24mm F2.8 G	Camera and lens	√	√	-	-	
		FE 35mm F1.8	Camera and lens	√	√	-	-	
		FE 40mm F2.5 G	Camera and lens	√	√	-	-	
		FE 50mm F2.5 G	Camera and lens	√	√	-	-	
		FE 50mm F2.8 MACRO	Camera and lens	√	√	-	-	
		FE PZ 16-35mm F4 G	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 24-70mm F2.8 GM	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap (Roll axis slightly rub against the camera)
		FE 24-70mm F2.8 GM II	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap (Roll axis slightly rub against the camera)
		FE 24-105mm F4 G OSS	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap (Roll axis slightly rub against the camera)

Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Sony	α7R4	FE 16-35mm F2.8 GM	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 16-35mm F4 ZAISS	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 12-24mm F4 G	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 24mm f1.4GM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		FE 24-70mm F2.8 GM	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap (Roll axis slightly rub against the camera)
		FE 24-70mm F4 ZA OSS	Camera and lens	√	√	√	√	Can be balanced at 24-50mm, need to remove eyepiece cap
		FE 28mm F2	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		FE 50mm F1.8	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		FE 85mm F1.4 GM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Distagon T* FE 35mm F1.4 ZA	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Sonnar T* FE 35mm F2.8 ZA	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Sonnar® T* FE 55mm F1.8 ZA	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		E 10-18mm F4 OSS	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		E PZ 18-105mm F4 G OSS	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		E 18-200mm F3.5-6.3 OSS LE	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		Sigma 30mm f/1.4 DC DN	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Sigma 50mm f/1.4 DG	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Tamron 28-75mm f/2.8	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap

Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Sony	α7R4	sigma18-35mm f/1.8 DC HSM Art (+Canon adapter ring)	Camera and lens	√	-	√	-	Can be balanced at any focal length, no need to remove eyepiece cap
		E 20mm F2.8	Camera and lens	√	√	-	-	
		E 3.5-5.6/PZ 16-50 OSS	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		E 35 mm F1.8 OSS	Camera and lens	√	√	-	-	
		E PZ 10-20mm F4 G	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 14mm F1.8 GM	Camera and lens	√	√	-	-	
		FE 24mm F2.8 G	Camera and lens	√	√	-	-	
		FE 35mm F1.8	Camera and lens	√	√	-	-	
		FE 40mm F2.5 G	Camera and lens	√	√	-	-	
		FE 50mm F2.5 G	Camera and lens	√	√	-	-	
		FE 50mm F2.8 MACRO	Camera and lens	√	√	-	-	
		FE PZ 16-35mm F4 G	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 24-70mm F2.8 GM	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap (Roll axis slightly rub against the camera)
		FE 24-70mm F2.8 GM II	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap (Roll axis slightly rub against the camera)
		FE 24-105mm F4 G OSS	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap (Roll axis slightly rub against the camera)

Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Sony	α7R5	FE 16-35mm F2.8 GM	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 16-35mm F4 ZAISS	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 12-24mm F4 G	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 24mm f1.4GM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		FE 24-70mm F2.8 GM	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap (Roll axis slightly rub against the camera)
		FE 24-70mm F4 ZA OSS	Camera and lens	√	√	√	√	Can be balanced at 24-50mm, need to remove eyepiece cap
		FE 28mm F2	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		FE 50mm F1.8	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		FE 85mm F1.4 GM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Distagon T* FE 35mm F1.4 ZA	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Sonnar T* FE 35mm F2.8 ZA	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Sonnar® T* FE 55mm F1.8 ZA	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		E 10-18mm F4 OSS	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		E PZ 18-105mm F4 G OSS	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		E 18-200mm F3.5-6.3 OSS LE	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		Sigma 30mm f/1.4 DC DN	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Sigma 50mm f/1.4 DG	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Tamron 28-75mm f/2.8	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap

Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Sony	α7R5	sigma18-35mm f/1.8 DC HSM Art (+Canon adapter ring)	Camera and lens	√	-	√	-	Can be balanced at any focal length, no need to remove eyepiece cap
		E 20mm F2.8	Camera and lens	√	√	-	-	
		E 3.5-5.6/PZ 16-50 OSS	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		E 35 mm F1.8 OSS	Camera and lens	√	√	-	-	
		E PZ 10-20mm F4 G	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 14mm F1.8 GM	Camera and lens	√	√	-	-	
		FE 24mm F2.8 G	Camera and lens	√	√	-	-	
		FE 35mm F1.8	Camera and lens	√	√	-	-	
		FE 40mm F2.5 G	Camera and lens	√	√	-	-	
		FE 50mm F2.5 G	Camera and lens	√	√	-	-	
		FE 50mm F2.8 MACRO	Camera and lens	√	√	-	-	
		FE PZ 16-35mm F4 G	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 24-70mm F2.8 GM	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap (Roll axis slightly rub against the camera)
		FE 24-70mm F2.8 GM II	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap (Roll axis slightly rub against the camera)
		FE 24-105mm F4 G OSS	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap (Roll axis slightly rub against the camera)

Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Sony	α7S3	FE 16-35mm F2.8 GM	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 16-35mm F4 ZAISS	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 12-24mm F4 G	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 24mm f1.4GM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		FE 24-70mm F2.8 GM	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap (Roll axis slightly rub against the camera)
		FE 24-70mm F4 ZA OSS	Camera and lens	√	√	√	√	Can be balanced at 24-50mm, need to remove eyepiece cap
		FE 28mm F2	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		FE 50mm F1.8	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		FE 85mm F1.4 GM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Distagon T* FE 35mm F1.4 ZA	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Sonnar T* FE 35mm F2.8 ZA	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Sonnar® T* FE 55mm F1.8 ZA	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		E 10-18mm F4 OSS	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		E PZ 18-105mm F4 G OSS	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		E 18-200mm F3.5-6.3 OSS LE	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		Sigma 30mm f/1.4 DC DN	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Sigma 50mm f/1.4 DG	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Tamron 28-75mm f/2.8	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap

Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Sony	α7S3	sigma18-35mm f/1.8 DC HSM Art (+Canon adapter ring)	Camera and lens	√	-	√	-	Can be balanced at any focal length, no need to remove eyepiece cap
		E 20mm F2.8	Camera and lens	√	√	-	-	
		E 3.5-5.6/PZ 16-50 OSS	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		E 35 mm F1.8 OSS	Camera and lens	√	√	-	-	
		E PZ 10-20mm F4 G	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 14mm F1.8 GM	Camera and lens	√	√	-	-	
		FE 24mm F2.8 G	Camera and lens	√	√	-	-	
		FE 35mm F1.8	Camera and lens	√	√	-	-	
		FE 40mm F2.5 G	Camera and lens	√	√	-	-	
		FE 50mm F2.5 G	Camera and lens	√	√	-	-	
		FE 50mm F2.8 MACRO	Camera and lens	√	√	-	-	
		FE PZ 16-35mm F4 G	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 24-70mm F2.8 GM	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap (Roll axis slightly rub against the camera)
		FE 24-70mm F2.8 GM II	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap (Roll axis slightly rub against the camera)
		FE 24-105mm F4 G OSS	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap (Roll axis slightly rub against the camera)

Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Sony	α7C	FE 16-35mm F2.8 GM	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 16-35mm F4 ZAISS	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 12-24mm F4 G	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 24mm f1.4GM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		FE 24-70mm F2.8 GM	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap (Roll axis slightly rub against the camera)
		FE 24-70mm F4 ZA OSS	Camera and lens	√	√	√	√	Can be balanced at 24-50mm, need to remove eyepiece cap
		FE 28mm F2	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		FE 50mm F1.8	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		FE 85mm F1.4 GM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Distagon T* FE 35mm F1.4 ZA	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Sonnar T* FE 35mm F2.8 ZA	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Sonnar® T* FE 55mm F1.8 ZA	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		E 10-18mm F4 OSS	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		E PZ 18-105mm F4 G OSS	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		E 18-200mm F3.5-6.3 OSS LE	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		Sigma 30mm f/1.4 DC DN	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Sigma 50mm f/1.4 DG	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Tamron 28-75mm f/2.8	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap

Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Sony	α7C	sigma18-35mm f/1.8 DC HSM Art (+Canon adapter ring)	Camera and lens	√	-	√	-	Can be balanced at any focal length, no need to remove eyepiece cap
		E 20mm F2.8	Camera and lens	√	√	-	-	
		E 3.5-5.6/PZ 16-50 OSS	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		E 35 mm F1.8 OSS	Camera and lens	√	√	-	-	
		E PZ 10-20mm F4 G	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 14mm F1.8 GM	Camera and lens	√	√	-	-	
		FE 24mm F2.8 G	Camera and lens	√	√	-	-	
		FE 35mm F1.8	Camera and lens	√	√	-	-	
		FE 40mm F2.5 G	Camera and lens	√	√	-	-	
		FE 50mm F2.5 G	Camera and lens	√	√	-	-	
		FE 50mm F2.8 MACRO	Camera and lens	√	√	-	-	
		FE PZ 16-35mm F4 G	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 24-70mm F2.8 GM	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap (Roll axis slightly rub against the camera)
		FE 24-70mm F2.8 GM II	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap (Roll axis slightly rub against the camera)
		FE 24-105mm F4 G OSS	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap (Roll axis slightly rub against the camera)

Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Sony	α7C II	FE 16-35mm F2.8 GM	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 16-35mm F4 ZAISS	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 12-24mm F4 G	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 24mm f1.4GM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		FE 24-70mm F2.8 GM	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap (Roll axis slightly rub against the camera)
		FE 24-70mm F4 ZA OSS	Camera and lens	√	√	√	√	Can be balanced at 24-50mm, need to remove eyepiece cap
		FE 28mm F2	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		FE 50mm F1.8	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		FE 85mm F1.4 GM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Distagon T* FE 35mm F1.4 ZA	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Sonnar T* FE 35mm F2.8 ZA	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Sonnar® T* FE 55mm F1.8 ZA	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		E 10-18mm F4 OSS	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		E PZ 18-105mm F4 G OSS	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		E 18-200mm F3.5-6.3 OSS LE	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		Sigma 30mm f/1.4 DC DN	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Sigma 50mm f/1.4 DG	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Tamron 28-75mm f/2.8	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap

Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Sony	α7C II	sigma18-35mm f/1.8 DC HSM Art (+Canon adapter ring)	Camera and lens	√	-	√	-	Can be balanced at any focal length, no need to remove eyepiece cap
		E 20mm F2.8	Camera and lens	√	√	-	-	
		E 3.5-5.6/PZ 16-50 OSS	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		E 35 mm F1.8 OSS	Camera and lens	√	√	-	-	
		E PZ 10-20mm F4 G	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 14mm F1.8 GM	Camera and lens	√	√	-	-	
		FE 24mm F2.8 G	Camera and lens	√	√	-	-	
		FE 35mm F1.8	Camera and lens	√	√	-	-	
		FE 40mm F2.5 G	Camera and lens	√	√	-	-	
		FE 50mm F2.5 G	Camera and lens	√	√	-	-	
		FE 50mm F2.8 MACRO	Camera and lens	√	√	-	-	
		FE PZ 16-35mm F4 G	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 24-70mm F2.8 GM	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap (Roll axis slightly rub against the camera)
		FE 24-70mm F2.8 GM II	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap (Roll axis slightly rub against the camera)
		FE 24-105mm F4 G OSS	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap (Roll axis slightly rub against the camera)

Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Sony	α6700	FE 16-35mm F2.8 GM	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 16-35mm F4 ZAISS	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 12-24mm F4 G	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 24mm f1.4GM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		FE 24-70mm F2.8 GM	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap (Roll axis slightly rub against the camera)
		FE 24-70mm F4 ZA OSS	Camera and lens	√	√	√	√	Can be balanced at 24-50mm, need to remove eyepiece cap
		FE 28mm F2	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		FE 50mm F1.8	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		FE 85mm F1.4 GM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Distagon T* FE 35mm F1.4 ZA	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Sonnar T* FE 35mm F2.8 ZA	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Sonnar® T* FE 55mm F1.8 ZA	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		E 10-18mm F4 OSS	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		E PZ 18-105mm F4 G OSS	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		E 18-200mm F3.5-6.3 OSS LE	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		Sigma 30mm f/1.4 DC DN	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Sigma 50mm f/1.4 DG	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Tamron 28-75mm f/2.8	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap

Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Sony	α6700	sigma18-35mm f/1.8 DC HSM Art (+Canon adapter ring)	Camera and lens	√	-	√	-	Can be balanced at any focal length, no need to remove eyepiece cap
		E 20mm F2.8	Camera and lens	√	√	-	-	
		E 3.5-5.6/PZ 16-50 OSS	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		E 35 mm F1.8 OSS	Camera and lens	√	√	-	-	
		E PZ 10-20mm F4 G	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 14mm F1.8 GM	Camera and lens	√	√	-	-	
		FE 24mm F2.8 G	Camera and lens	√	√	-	-	
		FE 35mm F1.8	Camera and lens	√	√	-	-	
		FE 40mm F2.5 G	Camera and lens	√	√	-	-	
		FE 50mm F2.5 G	Camera and lens	√	√	-	-	
		FE 50mm F2.8 MACRO	Camera and lens	√	√	-	-	
		FE PZ 16-35mm F4 G	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 24-70mm F2.8 GM	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap (Roll axis slightly rub against the camera)
		FE 24-70mm F2.8 GM II	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap (Roll axis slightly rub against the camera)
		FE 24-105mm F4 G OSS	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap (Roll axis slightly rub against the camera)

Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Sony	α6600	FE 16-35mm F2.8 GM	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 16-35mm F4 ZAISS	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 12-24mm F4 G	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 24mm f1.4GM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		FE 24-70mm F2.8 GM	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap (Roll axis slightly rub against the camera)
		FE 24-70mm F4 ZA OSS	Camera and lens	√	√	√	√	Can be balanced at 24-50mm, need to remove eyepiece cap
		FE 28mm F2	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		FE 50mm F1.8	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		FE 85mm F1.4 GM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Distagon T* FE 35mm F1.4 ZA	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Sonnar T* FE 35mm F2.8 ZA	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Sonnar® T* FE 55mm F1.8 ZA	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		E 10-18mm F4 OSS	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		E PZ 18-105mm F4 G OSS	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		E 18-200mm F3.5-6.3 OSS LE	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		Sigma 30mm f/1.4 DC DN	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Sigma 50mm f/1.4 DG	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Tamron 28-75mm f/2.8	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap

Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Sony	α6600	sigma18-35mm f/1.8 DC HSM Art (+Canon adapter ring)	Camera and lens	√	-	√	-	Can be balanced at any focal length, no need to remove eyepiece cap
		E 20mm F2.8	Camera and lens	√	√	-	-	
		E 3.5-5.6/PZ 16-50 OSS	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		E 35 mm F1.8 OSS	Camera and lens	√	√	-	-	
		E PZ 10-20mm F4 G	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 14mm F1.8 GM	Camera and lens	√	√	-	-	
		FE 24mm F2.8 G	Camera and lens	√	√	-	-	
		FE 35mm F1.8	Camera and lens	√	√	-	-	
		FE 40mm F2.5 G	Camera and lens	√	√	-	-	
		FE 50mm F2.5 G	Camera and lens	√	√	-	-	
		FE 50mm F2.8 MACRO	Camera and lens	√	√	-	-	
		FE PZ 16-35mm F4 G	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 24-70mm F2.8 GM	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap (Roll axis slightly rub against the camera)
		FE 24-70mm F2.8 GM II	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap (Roll axis slightly rub against the camera)
		FE 24-105mm F4 G OSS	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap (Roll axis slightly rub against the camera)

Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Sony	α6500	FE 16-35mm F2.8 GM	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 16-35mm F4 ZAISS	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 12-24mm F4 G	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 24mm f1.4GM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		FE 24-70mm F2.8 GM	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap (Roll axis slightly rub against the camera)
		FE 24-70mm F4 ZA OSS	Camera and lens	√	√	√	√	Can be balanced at 24-50mm, need to remove eyepiece cap
		FE 28mm F2	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		FE 50mm F1.8	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		FE 85mm F1.4 GM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Distagon T* FE 35mm F1.4 ZA	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Sonnar T* FE 35mm F2.8 ZA	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Sonnar® T* FE 55mm F1.8 ZA	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		E 10-18mm F4 OSS	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		E PZ 18-105mm F4 G OSS	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		E 18-200mm F3.5-6.3 OSS LE	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		Sigma 30mm f/1.4 DC DN	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Sigma 50mm f/1.4 DG	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Tamron 28-75mm f/2.8	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		sigma18-35mm f/1.8 DC HSM Art (+Canon adapter ring)	Camera and lens	√	-	√	-	Can be balanced at any focal length, no need to remove eyepiece cap



Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Sony	α6500	E 20mm F2.8	Camera and lens	√	√	-	-	
		E 3.5-5.6/PZ 16-50 OSS	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		E 35 mm F1.8 OSS	Camera and lens	√	√	-	-	
		E PZ 10-20mm F4 G	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 14mm F1.8 GM	Camera and lens	√	√	-	-	
		FE 24mm F2.8 G	Camera and lens	√	√	-	-	
		FE 35mm F1.8	Camera and lens	√	√	-	-	
		FE 40mm F2.5 G	Camera and lens	√	√	-	-	
		FE 50mm F2.5 G	Camera and lens	√	√	-	-	
		FE 50mm F2.8 MACRO	Camera and lens	√	√	-	-	
		FE PZ 16-35mm F4 G	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 24-70mm F2.8 GM	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap (Roll axis slightly rub against the camera)
		FE 24-70mm F2.8 GM II	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap (Roll axis slightly rub against the camera)
		FE 24-105mm F4 G OSS	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap (Roll axis slightly rub against the camera)

Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Sony	α6400	FE 16-35mm F2.8 GM	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 16-35mm F4 ZAISS	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 12-24mm F4 G	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 24mm f1.4GM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		FE 24-70mm F2.8 GM	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap (Roll axis slightly rub against the camera)
		FE 24-70mm F4 ZA OSS	Camera and lens	√	√	√	√	Can be balanced at 24-50mm, need to remove eyepiece cap
		FE 28mm F2	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		FE 50mm F1.8	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		FE 85mm F1.4 GM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Distagon T* FE 35mm F1.4 ZA	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Sonnar T* FE 35mm F2.8 ZA	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Sonnar® T* FE 55mm F1.8 ZA	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		E 10-18mm F4 OSS	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		E PZ 18-105mm F4 G OSS	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		E 18-200mm F3.5-6.3 OSS LE	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		Sigma 30mm f/1.4 DC DN	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Sigma 50mm f/1.4 DG	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Tamron 28-75mm f/2.8	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		sigma18-35mm f/1.8 DC HSM Art (+Canon adapter ring)	Camera and lens	√	-	√	-	Can be balanced at any focal length, no need to remove eyepiece cap



Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Sony	α6400	E 20mm F2.8	Camera and lens	√	√	-	-	
		E 3.5-5.6/PZ 16-50 OSS	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		E 35 mm F1.8 OSS	Camera and lens	√	√	-	-	
		E PZ 10-20mm F4 G	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 14mm F1.8 GM	Camera and lens	√	√	-	-	
		FE 24mm F2.8 G	Camera and lens	√	√	-	-	
		FE 35mm F1.8	Camera and lens	√	√	-	-	
		FE 40mm F2.5 G	Camera and lens	√	√	-	-	
		FE 50mm F2.5 G	Camera and lens	√	√	-	-	
		FE 50mm F2.8 MACRO	Camera and lens	√	√	-	-	
		FE PZ 16-35mm F4 G	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 24-70mm F2.8 GM	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap (Roll axis slightly rub against the camera)
		FE 24-70mm F2.8 GM II	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap (Roll axis slightly rub against the camera)
		FE 24-105mm F4 G OSS	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap (Roll axis slightly rub against the camera)

Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Sony	α6300	FE 16-35mm F2.8 GM	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 16-35mm F4 ZAISS	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 12-24mm F4 G	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 24mm f1.4GM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		FE 24-70mm F2.8 GM	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap (Roll axis slightly rub against the camera)
		FE 24-70mm F4 ZA OSS	Camera and lens	√	√	√	√	Can be balanced at 24-50mm, need to remove eyepiece cap
		FE 28mm F2	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		FE 50mm F1.8	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		FE 85mm F1.4 GM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Distagon T* FE 35mm F1.4 ZA	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Sonnar T* FE 35mm F2.8 ZA	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Sonnar® T* FE 55mm F1.8 ZA	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		E 10-18mm F4 OSS	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		E PZ 18-105mm F4 G OSS	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		E 18-200mm F3.5-6.3 OSS LE	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		Sigma 30mm f/1.4 DC DN	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Sigma 50mm f/1.4 DG	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Tamron 28-75mm f/2.8	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap

Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Sony	α6300	sigma18-35mm f/1.8 DC HSM Art (+Canon adapter ring)	Camera and lens	√	-	√	-	Can be balanced at any focal length, no need to remove eyepiece cap
		E 20mm F2.8	Camera and lens	√	√	-	-	
		E 3.5-5.6/PZ 16-50 OSS	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		E 35 mm F1.8 OSS	Camera and lens	√	√	-	-	
		E PZ 10-20mm F4 G	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 14mm F1.8 GM	Camera and lens	√	√	-	-	
		FE 24mm F2.8 G	Camera and lens	√	√	-	-	
		FE 35mm F1.8	Camera and lens	√	√	-	-	
		FE 40mm F2.5 G	Camera and lens	√	√	-	-	
		FE 50mm F2.5 G	Camera and lens	√	√	-	-	
		FE 50mm F2.8 MACRO	Camera and lens	√	√	-	-	
		FE PZ 16-35mm F4 G	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 24-70mm F2.8 GM	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap (Roll axis slightly rub against the camera)
		FE 24-70mm F2.8 GM II	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap (Roll axis slightly rub against the camera)
FE 24-105mm F4 G OSS	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap (Roll axis slightly rub against the camera)		

Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Sony	α6100	FE 16-35mm F2.8 GM	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 16-35mm F4 ZAISS	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 12-24mm F4 G	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 24mm f1.4GM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		FE 24-70mm F2.8 GM	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap (Roll axis slightly rub against the camera)
		FE 24-70mm F4 ZA OSS	Camera and lens	√	√	√	√	Can be balanced at 24-50mm, need to remove eyepiece cap
		FE 28mm F2	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		FE 50mm F1.8	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		FE 85mm F1.4 GM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Distagon T* FE 35mm F1.4 ZA	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Sonnar T* FE 35mm F2.8 ZA	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Sonnar® T* FE 55mm F1.8 ZA	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		E 10-18mm F4 OSS	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		E PZ 18-105mm F4 G OSS	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		E 18-200mm F3.5-6.3 OSS LE	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		Sigma 30mm f/1.4 DC DN	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Sigma 50mm f/1.4 DG	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Tamron 28-75mm f/2.8	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap

Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Sony	α6100	sigma18-35mm f/1.8 DC HSM Art (+Canon adapter ring)	Camera and lens	√	-	√	-	Can be balanced at any focal length, no need to remove eyepiece cap
		E 20mm F2.8	Camera and lens	√	√	-	-	
		E 3.5-5.6/PZ 16-50 OSS	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		E 35 mm F1.8 OSS	Camera and lens	√	√	-	-	
		E PZ 10-20mm F4 G	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 14mm F1.8 GM	Camera and lens	√	√	-	-	
		FE 24mm F2.8 G	Camera and lens	√	√	-	-	
		FE 35mm F1.8	Camera and lens	√	√	-	-	
		FE 40mm F2.5 G	Camera and lens	√	√	-	-	
		FE 50mm F2.5 G	Camera and lens	√	√	-	-	
		FE 50mm F2.8 MACRO	Camera and lens	√	√	-	-	
		FE PZ 16-35mm F4 G	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 24-70mm F2.8 GM	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap (Roll axis slightly rub against the camera)
		FE 24-70mm F2.8 GM II	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap (Roll axis slightly rub against the camera)
FE 24-105mm F4 G OSS	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap (Roll axis slightly rub against the camera)		

Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Sony	ZV-E10、 ZV-E10 II	FE 16-35mm F2.8 GM	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 16-35mm F4 ZAISS	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 12-24mm F4 G	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 24mm f1.4GM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		FE 24-70mm F2.8 GM	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap (Roll axis slightly rub against the camera)
		FE 24-70mm F4 ZA OSS	Camera and lens	√	√	√	√	Can be balanced at 24-50mm, need to remove eyepiece cap
		FE 28mm F2	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		FE 50mm F1.8	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		FE 85mm F1.4 GM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Distagon T* FE 35mm F1.4 ZA	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Sonnar T* FE 35mm F2.8 ZA	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Sonnar® T* FE 55mm F1.8 ZA	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		E 10-18mm F4 OSS	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		E PZ 18-105mm F4 G OSS	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		E 18-200mm F3.5-6.3 OSS LE	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		Sigma 30mm f/1.4 DC DN	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Sigma 50mm f/1.4 DG	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Tamron 28-75mm f/2.8	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		sigma18-35mm f/1.8 DC HSM Art (+Canon adapter ring)	Camera and lens	√	-	√	-	Can be balanced at any focal length, no need to remove eyepiece cap



Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Sony	ZV-E10、 ZV-E10 II	E 20mm F2.8	Camera and lens	√	√	-	-	
		E 3.5-5.6/PZ 16-50 OSS	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		E 35 mm F1.8 OSS	Camera and lens	√	√	-	-	
		E PZ 10-20mm F4 G	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 14mm F1.8 GM	Camera and lens	√	√	-	-	
		FE 24mm F2.8 G	Camera and lens	√	√	-	-	
		FE 35mm F1.8	Camera and lens	√	√	-	-	
		FE 40mm F2.5 G	Camera and lens	√	√	-	-	
		FE 50mm F2.5 G	Camera and lens	√	√	-	-	
		FE 50mm F2.8 MACRO	Camera and lens	√	√	-	-	
		FE PZ 16-35mm F4 G	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 24-70mm F2.8 GM	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap (Roll axis slightly rub against the camera)
		FE 24-70mm F2.8 GM II	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap (Roll axis slightly rub against the camera)
		FE 24-105mm F4 G OSS	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap (Roll axis slightly rub against the camera)

Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Sony	ZV-E1	FE 16-35mm F2.8 GM	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 16-35mm F4 ZAISS	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 12-24mm F4 G	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 24mm f1.4GM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		FE 24-70mm F2.8 GM	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap (Roll axis slightly rub against the camera)
		FE 24-70mm F4 ZA OSS	Camera and lens	√	√	√	√	Can be balanced at 24-50mm, need to remove eyepiece cap
		FE 28mm F2	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		FE 50mm F1.8	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		FE 85mm F1.4 GM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Distagon T* FE 35mm F1.4 ZA	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Sonnar T* FE 35mm F2.8 ZA	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Sonnar® T* FE 55mm F1.8 ZA	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		E 10-18mm F4 OSS	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		E PZ 18-105mm F4 G OSS	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		E 18-200mm F3.5-6.3 OSS LE	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		Sigma 30mm f/1.4 DC DN	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Sigma 50mm f/1.4 DG	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Tamron 28-75mm f/2.8	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap

Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Sony	ZV-E1	sigma18-35mm f/1.8 DC HSM Art (+Canon adapter ring)	Camera and lens	√	-	√	-	Can be balanced at any focal length, no need to remove eyepiece cap
		E 20mm F2.8	Camera and lens	√	√	-	-	
		E 3.5-5.6/PZ 16-50 OSS	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		E 35 mm F1.8 OSS	Camera and lens	√	√	-	-	
		E PZ 10-20mm F4 G	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 14mm F1.8 GM	Camera and lens	√	√	-	-	
		FE 24mm F2.8 G	Camera and lens	√	√	-	-	
		FE 35mm F1.8	Camera and lens	√	√	-	-	
		FE 40mm F2.5 G	Camera and lens	√	√	-	-	
		FE 50mm F2.5 G	Camera and lens	√	√	-	-	
		FE 50mm F2.8 MACRO	Camera and lens	√	√	-	-	
		FE PZ 16-35mm F4 G	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 24-70mm F2.8 GM	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap (Roll axis slightly rub against the camera)
		FE 24-70mm F2.8 GM II	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap (Roll axis slightly rub against the camera)
FE 24-105mm F4 G OSS	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap (Roll axis slightly rub against the camera)		

Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark	
				Horizontal	Vertical	Horizontal	Vertical		
Sony	ZV-1	Comes with the lens	Standard quick release plate provided	√	-	√	-	Should be powered on to balance	
	ZV-1 II	Comes with the lens	Standard quick release plate provided	√	-	√	-	Should be powered on to balance	
	ILME-FX3	FE 16-35mm F2.8 GM	Camera and lens		√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 16-35mm F4 ZAISS	Camera and lens		√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 12-24mm F4 G	Camera and lens		√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 24mm f1.4GM	Camera and lens		√	√	√	√	no need to remove eyepiece cap
		FE 24-70mm F2.8 GM	Camera and lens		√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap (Roll axis slightly rub against the camera)
		FE 24-70mm F4 ZA OSS	Camera and lens		√	√	√	√	Can be balanced at 24-50mm, need to remove eyepiece cap
		FE 28mm F2	Camera and lens		√	√	√	√	no need to remove eyepiece cap
		FE 50mm F1.8	Camera and lens		√	√	√	√	no need to remove eyepiece cap
		FE 85mm F1.4 GM	Camera and lens		√	√	√	√	no need to remove eyepiece cap
		Distagon T* FE 35mm F1.4 ZA	Camera and lens		√	√	√	√	no need to remove eyepiece cap
		Sonnar T* FE 35mm F2.8 ZA	Camera and lens		√	√	√	√	no need to remove eyepiece cap
		Sonnar® T* FE 55mm F1.8 ZA	Camera and lens		√	√	√	√	no need to remove eyepiece cap
		E 10-18mm F4 OSS	Camera and lens		√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
E PZ 18-105mm F4 G OSS	Camera and lens		√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap		

Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Sony	ILME-FX3	E 18-200mm F3.5-6.3 OSS LE	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		Sigma 30mm f/1.4 DC DN	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Sigma 50mm f/1.4 DG	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Tamron 28-75mm f/2.8	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		sigma18-35mm f/1.8 DC HSM Art (+Canon adapter ring)	Camera and lens	√	-	√	-	Can be balanced at any focal length, no need to remove eyepiece cap
		E 20mm F2.8	Camera and lens	√	√	-	-	
		E 3.5-5.6/PZ 16-50 OSS	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		E 35 mm F1.8 OSS	Camera and lens	√	√	-	-	
		E PZ 10-20mm F4 G	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 14mm F1.8 GM	Camera and lens	√	√	-	-	
		FE 24mm F2.8 G	Camera and lens	√	√	-	-	
		FE 35mm F1.8	Camera and lens	√	√	-	-	
		FE 40mm F2.5 G	Camera and lens	√	√	-	-	
		FE 50mm F2.5 G	Camera and lens	√	√	-	-	
		FE 50mm F2.8 MACRO	Camera and lens	√	√	-	-	
		FE PZ 16-35mm F4 G	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 24-70mm F2.8 GM	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap (Roll axis slightly rub against the camera)
		FE 24-70mm F2.8 GM II	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap (Roll axis slightly rub against the camera)
		FE 24-105mm F4 G OSS	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap (Roll axis slightly rub against the camera)

Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Sony	ILME-FX30	FE 16-35mm F2.8 GM	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 16-35mm F4 ZAISS	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 12-24mm F4 G	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 24mm f1.4GM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		FE 24-70mm F2.8 GM	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap (Roll axis slightly rub against the camera)
		FE 24-70mm F4 ZA OSS	Camera and lens	√	√	√	√	Can be balanced at 24-50mm, need to remove eyepiece cap
		FE 28mm F2	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		FE 50mm F1.8	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		FE 85mm F1.4 GM	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Distagon T* FE 35mm F1.4 ZA	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Sonnar T* FE 35mm F2.8 ZA	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Sonnar® T* FE 55mm F1.8 ZA	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		E 10-18mm F4 OSS	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		E PZ 18-105mm F4 G OSS	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		E 18-200mm F3.5-6.3 OSS LE	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap

Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Sony	ILME-FX30	Sigma 30mm f/1.4 DC DN	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Sigma 50mm f/1.4 DG	Camera and lens	√	√	√	√	no need to remove eyepiece cap
		Tamron 28-75mm f/2.8	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		sigma18-35mm f/1.8 DC HSM Art (+Canon adapter ring)	Camera and lens	√	-	√	-	Can be balanced at any focal length, no need to remove eyepiece cap
		E 20mm F2.8	Camera and lens	√	√	-	-	
		E 3.5-5.6/PZ 16-50 OSS	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		E 35 mm F1.8 OSS	Camera and lens	√	√	-	-	
		E PZ 10-20mm F4 G	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 14mm F1.8 GM	Camera and lens	√	√	-	-	
		FE 24mm F2.8 G	Camera and lens	√	√	-	-	
		FE 35mm F1.8	Camera and lens	√	√	-	-	
		FE 40mm F2.5 G	Camera and lens	√	√	-	-	
		FE 50mm F2.5 G	Camera and lens	√	√	-	-	
		FE 50mm F2.8 MACRO	Camera and lens	√	√	-	-	
		FE PZ 16-35mm F4 G	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 24-70mm F2.8 GM	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap (Roll axis slightly rub against the camera)
		FE 24-70mm F2.8 GM II	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap (Roll axis slightly rub against the camera)
		FE 24-105mm F4 G OSS	Camera and lens	√	√	√	√	Can be balanced at any focal length, need to remove eyepiece cap (Roll axis slightly rub against the camera)

Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
FUJIFILM	X-T3	XF 16-55mm f/2.8 R LM WR	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		XF 18-55mm f/2.8-4 R OIS	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		XF 18-135mm f/3.5-5.6 R LM OIS WR	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		XF 35mm f/2 R WR	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		XF 56mm f/1.2 R	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		XC 15-45mm f/3.5-5.6 OIS	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		Super EBC XF 23mm f/1.4 R	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		XC 35mm F2	Camera and lens	√	√	-	-	
		XC15-45mm F3.5-5.6 OIS PZ	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		XF10-24mm F4 R OIS WR	Camera and lens	√	√	-	-	
		XF14mmF2.8 R	Camera and lens	√	√	-	-	
		XF16mm F1.4 R WR	Camera and lens	√	√	-	-	
		XF18mm F1.4 R LM WR	Camera and lens	√	√	-	-	
		XF18mm F2 R	Camera and lens	√	√	-	-	
		XF23mm F1.4 R	Camera and lens	√	√	-	-	
		XF23mm F2 R WR	Camera and lens	√	√	-	-	
		XF23mm F1.4 R LM WR	Camera and lens	√	√	-	-	
		XF27mm F2.8 R WR	Camera and lens	√	√	-	-	
		XF30mmF2.8 R LM WR Macro	Camera and lens	√	√	-	-	
		XF33mm F1.4 R LM WR	Camera and lens	√	√	-	-	
		XF35mm F1.4 R	Camera and lens	√	√	-	-	
XF50mm F2 R WR	Camera and lens	√	√	-	-			



Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
FUJIFILM	X-T4	XF 16-55mm f/2.8 R LM WR	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		XF 18-55mm f/2.8-4 R OIS	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		XF 18-135mm f/3.5-5.6 R LM OIS WR	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		XF 35mm f/2 R WR	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		XF 56mm f/1.2 R	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		XC 15-45mm f/3.5-5.6 OIS	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		Super EBC XF 23mm f/1.4 R	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		XC 35mm F2	Camera and lens	√	√	-	-	
		XC15-45mm F3.5-5.6 OIS PZ	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		XF10-24mm F4 R OIS WR	Camera and lens	√	√	-	-	
		XF14mmF2.8 R	Camera and lens	√	√	-	-	
		XF16mm F1.4 R WR	Camera and lens	√	√	-	-	
		XF18mm F1.4 R LM WR	Camera and lens	√	√	-	-	
		XF18mm F2 R	Camera and lens	√	√	-	-	
		XF23mm F1.4 R	Camera and lens	√	√	-	-	
		XF23mm F2 R WR	Camera and lens	√	√	-	-	
		XF23mm F1.4 R LM WR	Camera and lens	√	√	-	-	
		XF27mm F2.8 R WR	Camera and lens	√	√	-	-	
		XF30mmF2.8 R LM WR Macro	Camera and lens	√	√	-	-	
		XF33mm F1.4 R LM WR	Camera and lens	√	√	-	-	
		XF35mm F1.4 R	Camera and lens	√	√	-	-	
XF50mm F2 R WR	Camera and lens	√	√	-	-			



Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
FUJIFILM	X-T5	XF 16-55mm f/2.8 R LM WR	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		XF 18-55mm f/2.8-4 R OIS	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		XF 18-135mm f/3.5-5.6 R LM OIS WR	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		XF 35mm f/2 R WR	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		XF 56mm f/1.2 R	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		XC 15-45mm f/3.5-5.6 OIS	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		Super EBC XF 23mm f/1.4 R	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		XC 35mm F2	Camera and lens	√	√	-	-	
		XC15-45mm F3.5-5.6 OIS PZ	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		XF10-24mm F4 R OIS WR	Camera and lens	√	√	-	-	
		XF14mmF2.8 R	Camera and lens	√	√	-	-	
		XF16mm F1.4 R WR	Camera and lens	√	√	-	-	
		XF18mm F1.4 R LM WR	Camera and lens	√	√	-	-	
		XF18mm F2 R	Camera and lens	√	√	-	-	
		XF23mm F1.4 R	Camera and lens	√	√	-	-	
		XF23mm F2 R WR	Camera and lens	√	√	-	-	
		XF23mm F1.4 R LM WR	Camera and lens	√	√	-	-	
		XF27mm F2.8 R WR	Camera and lens	√	√	-	-	
		XF30mmF2.8 R LM WR Macro	Camera and lens	√	√	-	-	
		XF33mm F1.4 R LM WR	Camera and lens	√	√	-	-	
		XF35mm F1.4 R	Camera and lens	√	√	-	-	
		XF50mm F2 R WR	Camera and lens	√	√	-	-	



Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
FUJIFILM	X-H2	XF 16-55mm f/2.8 R LM WR	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		XF 18-55mm f/2.8-4 R OIS	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		XF 18-135mm f/3.5-5.6 R LM OIS WR	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		XF 35mm f/2 R WR	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		XF 56mm f/1.2 R	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		XC 15-45mm f/3.5-5.6 OIS	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		Super EBC XF 23mm f/1.4 R	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		XC 35mm F2	Camera and lens	√	√	-	-	
		XC15-45mm F3.5-5.6 OIS PZ	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		XF10-24mm F4 R OIS WR	Camera and lens	√	√	-	-	
		XF14mmF2.8 R	Camera and lens	√	√	-	-	
		XF16mm F1.4 R WR	Camera and lens	√	√	-	-	
		XF18mm F1.4 R LM WR	Camera and lens	√	√	-	-	
		XF18mm F2 R	Camera and lens	√	√	-	-	
		XF23mm F1.4 R	Camera and lens	√	√	-	-	
		XF23mm F2 R WR	Camera and lens	√	√	-	-	
		XF23mm F1.4 R LM WR	Camera and lens	√	√	-	-	
		XF27mm F2.8 R WR	Camera and lens	√	√	-	-	
		XF30mmF2.8 R LM WR Macro	Camera and lens	√	√	-	-	
		XF33mm F1.4 R LM WR	Camera and lens	√	√	-	-	
		XF35mm F1.4 R	Camera and lens	√	√	-	-	
XF50mm F2 R WR	Camera and lens	√	√	-	-			



Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
FUJIFILM	X-H2s, X-100 VI	XF 16-55mm f/2.8 R LM WR	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		XF 18-55mm f/2.8-4 R OIS	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		XF 18-135mm f/3.5-5.6 R LM OIS WR	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		XF 35mm f/2 R WR	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		XF 56mm f/1.2 R	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		XC 15-45mm f/3.5-5.6 OIS	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		Super EBC XF 23mm f/1.4 R	Camera and lens	√	√	√	√	Can be balanced at any focal length, no need to remove eyepiece cap
		XC 35mm F2	Camera and lens	√	√	-	-	
		XC15-45mm F3.5-5.6 OIS PZ	Camera and lens	√	√	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		XF10-24mm F4 R OIS WR	Camera and lens	√	√	-	-	
		XF14mmF2.8 R	Camera and lens	√	√	-	-	
		XF16mm F1.4 R WR	Camera and lens	√	√	-	-	
		XF18mm F1.4 R LM WR	Camera and lens	√	√	-	-	
		XF18mm F2 R	Camera and lens	√	√	-	-	
		XF23mm F1.4 R	Camera and lens	√	√	-	-	
		XF23mm F2 R WR	Camera and lens	√	√	-	-	
		XF23mm F1.4 R LM WR	Camera and lens	√	√	-	-	
		XF27mm F2.8 R WR	Camera and lens	√	√	-	-	
		XF30mmF2.8 R LM WR Macro	Camera and lens	√	√	-	-	
		XF33mm F1.4 R LM WR	Camera and lens	√	√	-	-	
		XF35mm F1.4 R	Camera and lens	√	√	-	-	
XF50mm F2 R WR	Camera and lens	√	√	-	-			

Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Panasonic	G9	LEICA DG MACRO 45mm f/2.8 OIS	Camera and lens	√	√	-	-	
		LEICA DG SUMMILUX 15mm f/1.7 ASPH	Camera and lens	√	√	-	-	
			Camera and lens	√	√	-	-	
		LEICA DG Vario-Elmarit 8-18mm f/2.8-4.0 ASPH	Camera and lens	√	√	-	-	
		LUMIX G X Vario 12-35mm f/2.8 II ASPH POWER OIS	Camera and lens	√	√	-	-	
		Olympus M.Zuiko Digital 17mm F1.8	Camera and lens	√	√	-	-	
		Olympus M.Zuiko Digital ED 12-45mm F4.0 PRO	Camera and lens	√	√	-	-	
		Olympus M.Zuiko Digital ED 12mm F2	Camera and lens	√	√	-	-	
		Olympus M.Zuiko Digital ED 17mm F1.2 PRO	Camera and lens	√	√	-	-	
		Olympus M.Zuiko Digital ED 25mm F1.2 PRO	Camera and lens	√	√	-	-	
		Panasonic Leica DG Summilux 12mm f/1.4 ASPH	Camera and lens	√	√	-	-	
		Panasonic Leica DG Summilux 25mm f/1.4 II ASPH	Camera and lens	√	√	-	-	
		Panasonic Leica DG Summilux 9mm F1.7 ASPH	Camera and lens	√	√	-	-	
		Panasonic LUMIX G 14mm / F2.5 ASPH	Camera and lens	√	√	-	-	
		Panasonic LUMIX G 20mm / F1.7 II ASPH	Camera and lens	√	√	-	-	
		Panasonic Lumix G 25mm f/1.7 ASPH	Camera and lens	√	√	-	-	
		Panasonic Lumix G 42.5mm f/1.7 ASPH. POWER O.I.S.	Camera and lens	√	√	-	-	
		Panasonic Lumix G Macro 30mm f/2.8 ASPH. MEGA O.I.S.	Camera and lens	√	√	-	-	
		Olympus M.ZUIKO DIGITAL 25mm F1.8	Camera and lens	√	√	-	-	
		Olympus M.Zuiko Digital ED 12-40mm F2.8 Pro	Camera and lens	√	√	-	-	
sigma 18-35mm f/1.8 DC HSM Art (+转接环)	Camera and lens	√	√	-	-			

Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Panasonic	GH5	LEICA DG MACRO 45mm f/2.8 OIS	Camera and lens	√	√	-	-	
		LEICA DG SUMMILUX 15mm f/1.7 ASPH	Camera and lens	√	√	-	-	
		LEICA DG Vario-Elmarit 12-60 f/2.8-4 Power OIS	Camera and lens	√	√	-	-	
		LEICA DG Vario-Elmarit 8-18mm f/2.8-4.0 ASPH	Camera and lens	√	√	-	-	
		LUMIX G X Vario 12-35mm f/2.8 II ASPH POWER OIS	Camera and lens	√	√	-	-	
		Olympus M.Zuiko Digital 17mm F1.8	Camera and lens	√	√	-	-	
		Olympus M.Zuiko Digital ED 12-45mm F4.0 PRO	Camera and lens	√	√	-	-	
		Olympus M.Zuiko Digital ED 12mm F2	Camera and lens	√	√	-	-	
		Olympus M.Zuiko Digital ED 17mm F1.2 PRO	Camera and lens	√	√	-	-	
		Olympus M.Zuiko Digital ED 25mm F1.2 PRO	Camera and lens	√	√	-	-	
		Panasonic Leica DG Summilux 12mm f/1.4 ASPH	Camera and lens	√	√	-	-	
		Panasonic Leica DG Summilux 25mm f/1.4 II ASPH	Camera and lens	√	√	-	-	
		Panasonic Leica DG Summilux 9mm F1.7 ASPH	Camera and lens	√	√	-	-	
		Panasonic LUMIX G 14mm / F2.5 ASPH	Camera and lens	√	√	-	-	
		Panasonic LUMIX G 20mm / F1.7 II ASPH	Camera and lens	√	√	-	-	
		Panasonic Lumix G 25mm f/1.7 ASPH	Camera and lens	√	√	-	-	
		Panasonic Lumix G 42.5mm f/1.7 ASPH. POWER O.I.S.	Camera and lens	√	√	-	-	
		Panasonic Lumix G Macro 30mm f/2.8 ASPH. MEGA O.I.S.	Camera and lens	√	√	-	-	
		Olympus M.ZUIKO DIGITAL 25mm F1.8	Camera and lens	√	√	-	-	
		Olympus M.Zuiko Digital ED 12-40mm F2.8 Pro	Camera and lens	√	√	-	-	

Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Panasonic	GH5s	LEICA DG MACRO 45mm f/2.8 OIS	Camera and lens	√	√	-	-	
		LEICA DG SUMMILUX 15mm f/1.7 ASPH	Camera and lens	√	√	-	-	
		LEICA DG Vario-Elmarit 12-60 f/2.8-4 Power OIS	Camera and lens	√	√	-	-	
		LEICA DG Vario-Elmarit 8-18mm f/2.8-4.0 ASPH	Camera and lens	√	√	-	-	
		LUMIX G X Vario 12-35mm f/2.8 II ASPH POWER OIS	Camera and lens	√	√	-	-	
		Olympus M.Zuiko Digital 17mm F1.8	Camera and lens	√	√	-	-	
		Olympus M.Zuiko Digital ED 12-45mm F4.0 PRO	Camera and lens	√	√	-	-	
		Olympus M.Zuiko Digital ED 12mm F2	Camera and lens	√	√	-	-	
		Olympus M.Zuiko Digital ED 17mm F1.2 PRO	Camera and lens	√	√	-	-	
		Olympus M.Zuiko Digital ED 25mm F1.2 PRO	Camera and lens	√	√	-	-	
		Panasonic Leica DG Summilux 12mm f/1.4 ASPH	Camera and lens	√	√	-	-	
		Panasonic Leica DG Summilux 25mm f/1.4 II ASPH	Camera and lens	√	√	-	-	
		Panasonic Leica DG Summilux 9mm F1.7 ASPH	Camera and lens	√	√	-	-	
		Panasonic LUMIX G 14mm / F2.5 ASPH	Camera and lens	√	√	-	-	
		Panasonic LUMIX G 20mm / F1.7 II ASPH	Camera and lens	√	√	-	-	
		Panasonic Lumix G 25mm f/1.7 ASPH	Camera and lens	√	√	-	-	
		Panasonic Lumix G 42.5mm f/1.7 ASPH. POWER O.I.S.	Camera and lens	√	√	-	-	
		Panasonic Lumix G Macro 30mm f/2.8 ASPH. MEGA O.I.S.	Camera and lens	√	√	-	-	
		Olympus M.ZUIKO DIGITAL 25mm F1.8	Camera and lens	√	√	-	-	
		Olympus M.Zuiko Digital ED 12-40mm F2.8 Pro	Camera and lens	√	√	-	-	

Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Panasonic	GH6	LEICA DG MACRO 45mm f/2.8 OIS	Camera and lens	√	√	-	-	
		LEICA DG SUMMILUX 15mm f/1.7 ASPH	Camera and lens	√	√	-	-	
		LEICA DG Vario-Elmarit 12-60 f/2.8-4 Power OIS	Camera and lens	√	√	-	-	
		LEICA DG Vario-Elmarit 8-18mm f/2.8-4.0 ASPH	Camera and lens	√	√	-	-	
		LUMIX G X Vario 12-35mm f/2.8 II ASPH POWER OIS	Camera and lens	√	√	-	-	
		Olympus M.Zuiko Digital 17mm F1.8	Camera and lens	√	√	-	-	
		Olympus M.Zuiko Digital ED 12-45mm F4.0 PRO	Camera and lens	√	√	-	-	
		Olympus M.Zuiko Digital ED 12mm F2	Camera and lens	√	√	-	-	
		Olympus M.Zuiko Digital ED 17mm F1.2 PRO	Camera and lens	√	√	-	-	
		Olympus M.Zuiko Digital ED 25mm F1.2 PRO	Camera and lens	√	√	-	-	
		Panasonic Leica DG Summilux 12mm f/1.4 ASPH	Camera and lens	√	√	-	-	
		Panasonic Leica DG Summilux 25mm f/1.4 II ASPH	Camera and lens	√	√	-	-	
		Panasonic Leica DG Summilux 9mm F1.7 ASPH	Camera and lens	√	√	-	-	
		Panasonic LUMIX G 14mm / F2.5 ASPH	Camera and lens	√	√	-	-	
		Panasonic LUMIX G 20mm / F1.7 II ASPH	Camera and lens	√	√	-	-	
		Panasonic Lumix G 25mm f/1.7 ASPH	Camera and lens	√	√	-	-	
		Panasonic Lumix G 42.5mm f/1.7 ASPH. POWER O.I.S.	Camera and lens	√	√	-	-	
		Panasonic Lumix G Macro 30mm f/2.8 ASPH. MEGA O.I.S.	Camera and lens	√	√	-	-	
		Olympus M.ZUIKO DIGITAL 25mm F1.8	Camera and lens	√	√	-	-	
		Olympus M.Zuiko Digital ED 12-40mm F2.8 Pro	Camera and lens	√	√	-	-	



Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Installation Remark
				Horizontal	Vertical	Horizontal	Vertical	
Panasonic	S5, S9	LUMIX S 24-105mm F/4 Macro OIS	Camera and lens	√	√	√	√	Can be balanced at 24mm, no need to remove eyepiece cap
		LUMIX S PRO 24-70mm f/2.8	Camera and lens	√	√	√	√	Can be balanced at 24mm, no need to remove eyepiece cap
		LUMIX S 18mm F1.8	Camera and lens	√	√	-	-	
		LUMIX S 20-60 mm F3.5-5.6	Camera and lens	√	√	-	-	
		LUMIX S 24mm F1.8	Camera and lens	√	√	-	-	
		LUMIX S 35mm F1.8	Camera and lens	√	√	-	-	
		LUMIX S 50mm F1.8	Camera and lens	√	√	-	-	
	S5 II	LUMIX S 24-105mm F/4 Macro OIS	Camera and lens	√	√	√	√	Can be balanced at 24mm, no need to remove eyepiece cap
		LUMIX S PRO 24-70mm f/2.8	Camera and lens	√	√	√	√	Can be balanced at 24mm, no need to remove eyepiece cap
		LUMIX S 18mm F1.8	Camera and lens	√	√	-	-	
		LUMIX S 20-60 mm F3.5-5.6	Camera and lens	√	√	-	-	
		LUMIX S 24mm F1.8	Camera and lens	√	√	-	-	
		LUMIX S 35mm F1.8	Camera and lens	√	√	-	-	
		LUMIX S 50mm F1.8	Camera and lens	√	√	-	-	
ZCAM	E2	LUMIX G X Vario 12-35mm f/2.8 II ASPH POWER OIS	Camera and lens	√	√	√	√	
SIGMA	fp	45mm F2.8	Camera and lens	√	√	√	√	