WEEBILL 3 Camera Compatibility List

Update Date: January 10th, 2024 Firmware Version: V1.76

Camera		Photo	١	/ideo	Live	Shutte Adjus	r Speed tment	Ape Adjus	rture tment	۱S Adjus	iO tment	E Adjus	V tment	Zoom	Halfway Press	Electronic Follow	HDMI	Camera Control Cable	Camera	
Model	Save	Playback	Save	Playback	Preview	Photo Mode	Video Mode	Photo Mode	Video Mode	Photo Mode	Video Mode	Photo Mode	Video Mode	(Digital/ Optical)	Shutter Button to Autofocus	Focus (Focus Wheel)	Cable Type	Туре	Firmware Version	
Sony α1	J	J	J	1	-	V	J	J	1	J	J	-	-	-	V	V	-	Type-C to Multi USB / Type-C to Type-C USB	V1.10	1. P fi > X 2. V t b e 3. lı s tt > a s
Sony α9 II	J	Y	J	J	-	J	J	J	J	J	J	-	-	-	J	J	-	Type-C to Multi USB	V2.00	4. T 4. T 5. W 5. W 6. W tl ta 1r
Sony α9	J	J	J	J	-	1	J	J	J	J	J	-	-	-	√	J	-	Type-C to Multi USB	V6.00	1. F C 2. F v C 3. V r r 4. T

ZHIYUN

V1.40

Note Please enable the "PC Remote" function of the camera first. The specific settings are as follows: Network->Transfer/Remote->PC Remote Function->On; or Network->PC Remote Function->On. When using the electronic focusing function, please set the lens to AF (auto-focusing) mode and the camera body to MF (manual focusing) mode, otherwise the electronic focusing function cannot be used. In video mode, the camera body's 5-axis antishake function will be automatically turned off. To turn it back on, go to Menu->Image Stabilization->SteadyShot->Enhanced/Standard. When used with a lens that has the anti-shake function, the lens antishake function is not affected. To use the camera playback function normally, please set the destination for saving static images in the PC remote function to "Computer+Shooting device" or "Only Shooting device". When using the photo function, to avoid discrepancies in the number of photos taken, please set it as follows: Network->Transfer/Remote->PC Remote Function->Static Image Save Destination->Only Shooting Device. When using HDMI (such as connecting to a monitor), the camera screen display settings are as follows: Go to the camera settings menu->External Output->HDMI Info Display->Off. Please select "PC Remote" for your camera's "USB For Sony cameras, after connecting gimbal and camera

Connection".

with control cable, power on the gimbal and then the camera. Make sure the camera is fully charged. When shooting Panorama or Timelapse, it is recommended to turn off the Sony camera's auto review.

To trigger electronic focus, please set "Manual Focus (MF)" under "focus mode".

Camera		Photo	۱ ۱	/ideo	Live	Shutter Adjus	r Speed tment	Apeı Adjus	rture tment	IS Adjus	0 tment	E Adjus	V tment	Zoom	Halfway Press	Electronic Follow	HDMI	Camera Control Cable	Camera	
Model	Save	Playback	Save	Playback	Preview	Photo Mode	Video Mode	Photo Mode	Video Mode	Photo Mode	Video Mode	Photo Mode	Video Mode	(Digital/ Optical)	Shutter Button to Autofocus	Focus (Focus Wheel)	Cable Type	Туре	Firmware Version	
Sony α7R5	1	Ţ	J	1	_	-	-	-	-	-	-	_	_	J	J	-	-	Type-C to Mulit USB	V1.00	1. Pl Ca 2. If fo 3. Fo W ca zc W ol Pl 4. W re re
Sony α7R4	J	J	J	J	-	V	J	J	J	\checkmark	J	_	_	-	J	J	-	Type-C to Multi USB	V1.20	1. Pl fir >7 N 2. W th bo el 3. In sh tu >5 a sh 4. To se re 70 5. W in N 5. W 6. W

ZHTVIIN

Note

Please select "PC Remote" for your camera's "USB Connection".

If using electronic focusing, set the "zoom setting" into "on: Digital zoom" in the menu and set the photo format into "JPEG".

For Sony cameras, after connecting gimbal and camera with control cable, power on the gimbal and then the camera. Make sure the camera is fully charged. Optical zoom control is available on the gimbal when used with motorized lens. Digital zoom control is available on the gimbal when used with non-motorized lens. Please select zoom option in your camera's settings. When shooting Panorama or Timelapse, it is recommended to turn off the Sony camera's auto review.

Please enable the "PC Remote" function of the camera first. The specific settings are as follows: Network->Transfer/Remote->PC Remote Function->On; or Network->PC Remote Function->On.

When using the electronic focusing function, please set the lens to AF (auto-focusing) mode and the camera body to MF (manual focusing) mode, otherwise the electronic focusing function cannot be used.

In video mode, the camera body's 5-axis antishake function will be automatically turned off. To turn it back on, go to Menu->Image Stabilization->SteadyShot->Enhanced/Standard. When used with a lens that has the anti-shake function. the lens antishake function is not affected.

To use the camera playback function normally, please set the destination for saving static images in the PC remote function to "Computer+Shooting device" or "Only Shooting device".

When using the photo function, to avoid discrepancies in the number of photos taken, please set it as follows: Network->Transfer/Remote->PC Remote Function->Static Image Save Destination->Only Shooting Device. When using HDMI (such as connecting to a monitor), the camera screen display settings are as follows: Go to the camera settings menu->External Output->HDMI Info Display->Off.

Comore		Photo	۱	/ideo	Live	Shutte Adjus	r Speed tment	Apeı Adjus	rture tment		0 tment	E Adjus	V tment	Zoom	Halfway Press	Electronic Follow	HDMI	Comore Control Cobla	Camera	
Camera Model	Save	Playback	Save	Playback	Preview	Photo	Video Mode	Photo	Video	1	Video	Photo	Video	(Digital/ Optical)	Shutter Button to Autofocus	Focus (Focus Wheel)	Cable Type	Camera Control Cable Type	Firmware Version	
Sony α7M4	1	V	V	V	-	-	-	-	-	-	-	-	-	\checkmark	V	-	-	Type-C to Multi USB	V1.01	1. P C
Sony ILME-FX3	1	V	-	-	-	V	1	1	1	1	\checkmark	-	-	-	1	V	-	Type-C to Multi USB	V1.00	ir fc 3. Fo w
Sony α7R3	1	V	V	1	-	-	-	-	-	-	-	-	-	\checkmark	1	-	-	Type-C to Multi USB	V3.01	- ca za w o P
Sony α7M3	V	V	1	1	-	-	-	-	-	-	-	-	-	V	1	-	-	Type-C to Multi USB	V3.10	4. W
Sony α7S3	J	1	J	J	-	V	J	J	J	J	J	-	-	-	J	J	-	Type-C to Multi USB / Type-C to Type-C USB	V1.01	1. P C "'' 2. Fo w ci 3. W re 4. To (N 5. P to
Sony α7S3	J	J	J	J	-	_	-	-	-	-	-	-	-	J	J	_	-	Type-C to Multi USB	V1.01	1. PI Ca "N "7 2. Fc W ca 3. W re re 4. Fc W ca zc V W 01 5. PI 5. PI

ZHIY

Note

Please select "PC Remote" for your camera's "USB Connection".

If using electronic focusing, set the "zoom setting" into "on: Digital zoom" in the menu and set the photo format into "JPEG".

For Sony cameras, after connecting gimbal and camera with control cable, power on the gimbal and then the camera. Make sure the camera is fully charged. Optical zoom control is available on the gimbal when used with motorized lens. Digital zoom control is available on the gimbal when used with non-motorized lens. Please select zoom option in your camera's settings. When shooting Panorama or Timelapse, it is recommended to turn off the Sony camera's auto review.

Please select "PC Remote" for your camera's "USB Connection". (To open a7s3 PC remote control, go to "Menu" and do the following selection : "Network" -"Transfer / Remote" - "PC remote control" - "Open") For Sony cameras, after connecting gimbal and camera with control cable, power on the gimbal and then the camera. Make sure the camera is fully charged. When shooting Panorama or Timelapse, it is recommended to turn off the Sony camera's auto review.

To trigger electronic focus, please set "Manual Focus (MF)" under "focus mode".

Please use Type-C to Type-C USB camera control cable to charge the camera.

Please select "PC Remote" for your camera's "USB Connection". (To open a7s3 PC remote control, go to "Menu" and do the following selection : "Network" -"Transfer / Remote" - "PC remote control" - "Open") For Sony cameras, after connecting gimbal and camera with control cable, power on the gimbal and then the camera. Make sure the camera is fully charged. When shooting Panorama or Timelapse, it is recommended to turn off the Sony camera's auto review.

For Sony cameras, after connecting gimbal and camera with control cable, power on the gimbal and then the camera. Make sure the camera is fully charged. Optical zoom control is available on the gimbal when used with motorized lens. Digital zoom control is available on the gimbal when used with non-motorized lens. Please select zoom option in your camera's settings. Please use Type-C to Type-C USB camera control cable to charge the camera.

Camera		Photo	, v	/ideo	Live	Shutte Adjus	r Speed tment	Ape Adjus	rture tment		iO tment	E Adjus	EV stment	Zoom	Halfway Press	Electronic Follow	HDMI	Camera Control Cable	Camera	
Model	Save	Playback	Save	Playback	Preview	Photo Mode	Video Mode			Photo Mode		Photo Mode		(Digital/ Optical)	Shutter Button to Autofocus	Focus (Focus Wheel)	Cable Type	Туре	Firmware Version	
Sony α7R2	V	V	V	V	-	-	-	-	-	-	-	-	-	V	V	-	-	Type-C to Multi USB	V4.01	1. 2.
Sony α7M2	V	1	J	J	-	-	-	-	-	-	-	-	-	V	1	-	_	Type-C to Multi USB	V4.00	3.
Sony α7S2	V	V	J	J	-	-	-	-	-	-	-	-	-	V	1	-	-	Type-C to Multi USB	V3.01	4.
Sony α7C	J	J	V	J	-	J	J	J	J	V	J	-	-	-	J	J	-	Type-C to Type-C USB	V1.00	1. 2. 3. 4.
Sony α7C II	\checkmark	\checkmark	V	V	-	\checkmark	\checkmark	V	V	1	\checkmark	-	-	-	\checkmark	-	-	Type-C to Type-C USB	V1.00	
Sony α6700	\checkmark	V	V	1	-	V	V	V	V	V	-	-	-	-	J	-	-	Type-C to Type-C USB	V1.00	
Sony a6600	\checkmark	V	V	J	-	-	-	-	-	-	-	-	-	J	J	-	-	Type-C to Multi USB	V1.10	1.
Sony a6500	\checkmark	V	V	J	-	-	-	-	-	-	-	-	-	J	√	-	-	Type-C to Multi USB	V1.06	2.
Sony a6400	\checkmark	V	J	J	-	-	-	-	-	-	_	-	-	1	1	-	-	Type-C to Multi USB	V2.00	
Sony a6300	1	V	1	√	-	-	-	-	-	-	_	-	-	1	√	-	_	Type-C to Multi USB	V2.01	
Sony a6100	\checkmark	1	J	J	-	-	-	-	-	-	-	-	-	J	1	-	-	Type-C to Multi USB	V1.00	- 4.

ZHTVIIN

Note

- Please select "PC Remote" for your camera's "USB Connection".
- If using electronic focusing, set the "zoom setting" into "on: Digital zoom" in the menu and set the photo format into "JPEG".
- For Sony cameras, after connecting gimbal and camera with control cable, power on the gimbal and then the camera. Make sure the camera is fully charged. Optical zoom control is available on the gimbal when used with motorized lens. Digital zoom control is available on the gimbal when used with non-motorized lens. Please select zoom option in your camera's settings.
- When shooting Panorama or Timelapse, it is recommended to turn off the Sony camera's auto review.
- Please select "PC Remote" for your camera's "USB Connection".
- For Sony cameras, after connecting gimbal and camera with control cable, power on the gimbal and then the camera. Make sure the camera is fully charged.
- When shooting Panorama or Timelapse, it is recommended to turn off the Sony camera's auto review.
- To trigger electronic focus, please set "Manual Focus (MF)" under "focus mode".

- Please select "PC Remote" for your camera's "USB Connection".
- If using electronic focusing, set the "zoom setting" into "on: Digital zoom" in the menu and set the photo format into "JPEG".
- For Sony cameras, after connecting gimbal and camera with control cable, power on the gimbal and then the camera. Make sure the camera is fully charged. Optical zoom control is available on the gimbal when used with motorized lens. Digital zoom control is available on the gimbal when used with non-motorized lens. Please select zoom option in your camera's settings.
- When shooting Panorama or Timelapse, it is recommended to turn off the Sony camera's auto review.

Camera		Photo	۱ ۱	/ideo	Live	Shutte Adjus	r Speed tment	Aper Adjus	rture tment	IS Adjus	50 tment	E Adjus	EV tment	Zoom	Halfway Press	Electronic Follow	HDMI	Camera Control Cable	Camera	
Model	Save	Playback	Save	Playback	Preview	Photo Mode	Video Mode	Photo Mode	Video Mode	Photo Mode		Photo Mode	Video Mode	(Digital/ Optical)	Shutter Button to Autofocus	Focus (Focus Wheel)	Cable Type	Туре	Firmware Version	
Sony ZV-E10	V	V	V	J	-	V	V	V	V	V	V	-	-	-	\checkmark	-	-	Type-C to Type-C USB	V1.00	
Sony ZV-1	V	J	J	J	-	V	V	V	V	1	1	-	-	-	J	J	-	Type-C to Type-C USB	V1.00	1.
Sony ZV-E1	V	J	V	J	-	V	V	V	V	V	V	-	-	-	J	J	-	Type-C to Type-C USB	V1.00	3.
Sony ZV-1 II	V	V	V	J	-	V	J	V	V	V	V	-	-	-	V	-	-	Type-C to Type-C USB LN-UCUC-A02	V1.00	4.
Sony FX30	J	J	J	J	-	J	J	J	J	J	J	-	-	-	J	-	-	Type-C to Type-C USB LN-UCUC-A02	V1.00	6.
Sony FX30	J	J	J	J	-	-	-	-	-	-	-	-	-		J	-	-	Type-C to Multi USB LN-UCUS-A03	V1.00	

Note

1. Please enable the "PC Remote" function of the camera first. The specific settings are as follows: Network->Transfer/Remote->PC Remote Function->On; or Network->PC Remote Function->On. 2. When using the electronic focusing function, please set the lens to AF (auto-focusing) mode and the camera body to MF (manual focusing) mode, otherwise the electronic focusing function cannot be used.

3. In video mode, the camera body's 5-axis antishake function will be automatically turned off. To turn it back on, go to Menu->Image Stabilization->SteadyShot->Enhanced/Standard. When used with a lens that has the anti-shake function, the lens antishake function is not affected.

4. To use the camera playback function normally, please set the destination for saving static images in the PC remote function to "Computer+Shooting device" or "Only Shooting device".

5. When using the photo function, to avoid discrepancies in the number of photos taken, please set it as follows: Network->Transfer/Remote->PC Remote Function->Static Image Save Destination->Only Shooting Device.

6. When using HDMI (such as connecting to a monitor), the camera screen display settings are as follows: Go to the camera settings menu->External Output->HDMI Info Display->Off.

Camera		Photo	۱	/ideo	Live	Shutte Adjus	r Speed tment	Apeı Adjus	rture tment		50 tment		:V tment	Zoom	Halfway Press	Electronic Follow	HDMI	Camera Control Cable	Camera	
Model	Save	Playback	Save	Playback	Preview	Photo Mode	Video Mode	Photo Mode	Video Mode	Photo Mode		Photo Mode	Video Mode	(Digital/ Optical)	Shutter Button to Autofocus	Focus (Focus Wheel)	Cable Type	Туре	Firmware Version	
Panasonic G9	\checkmark	\checkmark	V	1	-	\checkmark	\checkmark	V	V	1	V	-	-	-	V	V	-	Type-C to Micro USB	V2.1	
Panasonic GH5	V	\checkmark	1	1	-	V	\checkmark	V	V	V	V	-	-	-	V	V	-	Type-C to Type-C USB	V2.6	1.
Panasonic GH5S	V	\checkmark	1	√	-	V	\checkmark	1	1	1	V	-	-	-	V	\checkmark	-	Type-C to Type-C USB	V1.3	2.
Panasonic GH6	\checkmark	\checkmark	V	V	-	\checkmark	\checkmark	V	1	1	V	-	-	-	\checkmark	V	-	Type-C to Type-C USB	V1.20	- 3. 4.
Panasonic S5	\checkmark	\checkmark	1	1	-	V	\checkmark	V	1	1	\checkmark	-	-	-	\checkmark	V	-	Type-C to Type-C USB	V1.0	
Panasonic S5 II	\checkmark	\checkmark	V	V	-	\checkmark	\checkmark	V	1	1	V	-	-	-	\checkmark	V	-	Type-C to Type-C USB LN-UCUC-A02	V1.0	
Panasonic DC-BGH1	-	-	V	V	-	-	\checkmark	V	-	-	-	-	-	-	-	V	-	Type-C to Type-C USB	V1.0	1.
Canon EOS 5D Mark III	\checkmark	\checkmark	1	\checkmark	V	\checkmark	V	V	V	1	V	-	-	-	V	V	-	Type-C to Mini USB	V1.3.5	
Canon EOS 5D Mark IV	\checkmark	\checkmark	V	\checkmark	V	\checkmark	V	V	1	1	V	-	-	-	V	V	-	Type-C to Micro USB	V1.0.4	1.
Canon EOS 5DS	\checkmark	\checkmark	V	\checkmark	V	\checkmark	V	V	V	1	\checkmark	-	-	-	\checkmark	V	-	Type-C to Micro USB	V1.1.1	2. 3.
Canon EOS 5DS R	\checkmark	\checkmark	V	V	√	\checkmark	V	V	1	1	\checkmark	-	-	-	\checkmark	V	-	Type-C to Micro USB	V1.1.2R	4.
Canon EOS 6D Mark II	\checkmark	V	1	V	V	V	V	V	V	V	V	-	-	-	V	V	-	Type-C to Mini USB	V1.0.4	5.
Canon EOS 80D	\checkmark	V	1	1	V	V	V	V	1	1	V	-	-	-	V	V	-	Type-C to Mini USB	V1.0.2	
Canon EOS 90D	\checkmark	\checkmark	1	V	V	\checkmark	V	V	1	1	\checkmark	-	-	-	\checkmark	V	-	Type-C to Micro USB	V1.1.1	

Note

- 1. Please select "PC (Tether)" for your camera's "USB Connection".
- 2. When using electronic focusing, the camera lens should be in "MF" mode.
- 3. Before connecting with a control cable, please first turn off the USB Power Supply in camera settings. 4. When shooting Panorama or Timelapse, it is recommended to turn off auto review and duration time(photo) in the Panasonic camera.

1. In the camera IN/OUT setting, please choose PC (Tether) for the USB mode.

- 1. Please apply electronic follow focus function in AF mode of the lens and live view mode of the camera. 2. If using electronic focusing when recording a video, please "Disable" the " Movie Servo AF ".
- 3. The Canon DSLR cannot realize the halfway press shutter button to autofocus in Live Preview. If the feature is used, the camera Live Preview mode should be turned off.
- 4. When shooting Panorama or Timelapse, it is recommended to turn off image confirmation in the Canon camera.
- 5. The real-time preview function refers to pressing the LV button of the gimbal once to switch between the electronic viewfinder or optical viewfinder of a DSLR camera for framing.

Camera		Photo	<u>،</u>	/ideo	Live		r Speed tment		rture tment		50 tment	E Adjus	EV stment	Zoom	Halfway Press	Electronic Follow	НДМІ	Camera Control Cable	Camera	
Model	Save	Playback	Save	Playback	Preview	Photo Mode	Video Mode	Photo Mode	Video Mode	Photo Mode	Video Mode	Photo Mode		(Digital/ Optical)	Shutter Button to Autofocus	Focus (Focus Wheel)	Cable Type	Туре	Firmware Version	
Canon EOS 800D	V	\checkmark	V	V	V	V	V	V	1	√	V	-	-	-	√	\checkmark	-	Type-C to Mini USB	V1.0.1	1. 2. 3.
Canon EOS 850D	V	V	J	J	V	V	V	1	1	1	V	-	-	-	1	V	-	Type-C to Micro USB	V1.0.1	4.
Canon EOS R6 Mark II	V	1	1	J	V	V	1	1	V	J	1	-	-	-	J	V	-	Type-C to Type-C USB	V1.0.0	1. 2.
Canon EOS R50	\checkmark	V	√	V	V	V	\checkmark	\checkmark	V	1	V	-	-	-	\checkmark	\checkmark	-	Type-C to Type-C USB	V1.0.0	3.
Canon EOS 200D II	J	J	J	J	V	J	J	J	V	V	J	-	-	-	V	J	-	Type-C to Micro USB	V1.0.0	1. 2. 3. 4.
Canon 5D Mark III	\checkmark	1	1	V	-	V	V	V	V	1	1	-	-	-	√	V	-	Type-C to Mini USB	V1.3.5	
Canon 5D Mark IV	V	1	J	V	-	V	V	V	V	V	1	-	-	-	√	V	-	Type-C to Micro USB	V1.0.4	
Canon 5DS	V	1	J	J	-	V	V	V	V	V	1	-	-	-	1	1	-	Type-C to Micro USB	V1.1.1	1. 2.
Canon 5DS R	V	1	V	J	-	V	V	V	V	V	V	-	-	-	J	\checkmark	-	Type-C to Micro USB	V1.1.2R	3.
Canon 6D Mark II	V	1	V	1	-	V	V	1	V	V	1	-	-	-	1	\checkmark	-	Type-C to Mini USB	V1.0.4	4.
Canon 80D	V	1	V	J	-	V	V	V	V	V	V	-	-	-	J	\checkmark	-	Type-C to Mini USB	V1.0.2	_
Canon 90D	V	\checkmark	V	V	-	V	\checkmark	V	V	V	V	-	-	-	√	\checkmark	-	Type-C to Micro USB	V1.1.1	-

ZHTVIIN

Note

- Please apply electronic follow focus function in AF mode of the lens and live view mode of the camera. If using electronic focusing when recording a video, please "Disable" the "Movie Servo AF".
- The Canon DSLR cannot realize the halfway press shutter button to autofocus in Live Preview. If the feature is used, the camera Live Preview mode should be turned off.
- When shooting Panorama or Timelapse, it is recommended to turn off image confirmation in the Canon camera.
- Please apply electronic follow focus function in AF mode.
- If using electronic focusing when recording a video, please "Disable" the "Movie Servo AF". When shooting Panorama or Timelapse, it is recommended to turn off image confirmation in the Canon camera.
- Please apply electronic follow focus function in AF mode of the lens and live view mode of the camera.
- If using electronic focusing when recording a video, please "Disable" the " Movie Servo AF ".
- The Canon DSLR cannot realize the halfway press shutter button to autofocus in Live Preview. If the feature is used, the camera Live Preview mode should be turned off.
- When shooting Panorama or Timelapse, it is recommended to turn off image confirmation in the Canon camera.
- Please apply electronic follow focus function in AF mode of the lens and live view mode of the camera. If using electronic focusing when recording a video, please "Disable" the " Movie Servo AF ".
- The Canon DSLR cannot realize the halfway press shutter button to autofocus in Live Preview. If the feature is used, the camera Live Preview mode should be turned off.
- When shooting Panorama or Timelapse, it is recommended to turn off image confirmation in the Canon camera.

Camera		Photo	۱ ۱	/ideo	Live	Shutte Adjus	r Speed tment	Ape Adjus	rture tment	۱۹ Adjus	50 tment		V tment	Zoom	Halfway Press	Electronic Follow	НДМІ	Camera Control Cable	Camera	
Model	Save	Playback	Save	Playback	Preview	Photo Mode	Video Mode		Video Mode	Photo Mode		Photo Mode	Video Mode	(Digital/ Optical)	Shutter Button to Autofocus	Focus (Focus Wheel)	Cable Type	Туре	Firmware Version	
Canon M50	V	\checkmark	1	V	-	\checkmark	\checkmark	V	V	V	\checkmark	-	-	-	-	-	-	Type-C to Micro USB	V1.0.3	1. 2.
Canon EOS M6 Mark II	V	V	V	V	V	V	V	V	V	V	V	-	-	-	-	V	-	Type-C to Type-C USB	V1.1.1	3.
Canon EOS R5	V	V	1	V	-	V	V	V	1	V	V	-	-	-	\checkmark	V	-	Type-C to Type-C USB	V1.10	
Canon EOS R6	V	V	1	V	-	V	V	V	1	V	V	-	-	-	\checkmark	V	-	Type-C to Type-C USB	V1.3.1	
Canon EOS R7	V	V	1	V	-	V	V	V	V	V	V	-	-	-	\checkmark	V	-	Type-C to Type-C USB	V1.0.1	1.
Canon EOS R8	V	\checkmark	1	1	V	V	\checkmark	V	V	V	V	-	-	-	\checkmark	1	-	Type-C to Type-C USB	V1.0.0	2. 3.
Canon EOS R10	1	\checkmark	√	1	-	1	1	1	1	J	1	-	-	-	1	1	-	Type-C to Type-C USB	V1.0.1	
Canon EOS R	J	J	V	V	-	V	V	V	V	J	V	-	-	-	V	J	-	Type-C to Type-C USB	V1.3.0	1. 2. 3. 4.
Canon EOS RP	V	J	V	J	-	V	J	V	V	V	J	-	-	-	V	V	-	Type-C to Type-C USB	V1.3.0	

ZHTVIIN

Note

- I. Please apply electronic follow focus function in AF mode of the lens.
- 2. If using electronic focusing when recording a video, please "Disable" the " Movie Servo AF ".
- 3. When shooting Panorama or Timelapse, it is recommended to turn off image confirmation in the Canon camera.
- I. For Canon mirrorless cameras, switch the shooting mode to photo mode before taking photos. When shooting a video is needed, switch the shooting mode to movie mode. Please turn off your camera before switching modes. For EOS R/RP/R5/R6, shutter release can't be used to control video shooting in photo mode otherwise the camera may freeze. (In this case please take out the camera batteries and reinstall and turn on the camera again).
- L. Please apply electronic follow focus function in AF mode of the lens.
- 2. If using electronic focusing when recording a video, please "Disable" the "Movie Servo AF".
- 3. When shooting Panorama or Timelapse, it is recommended to turn off image confirmation in the Canon camera.
- L. Please apply electronic follow focus function in AF mode of the lens.
- 2. If using electronic focusing when recording a video, please "Disable" the " Movie Servo AF ".
- 3. When shooting Panorama or Timelapse, it is recommended to turn off image confirmation in the Canon camera.
- I. For Canon mirrorless cameras, switch the shooting mode to photo mode before taking photos. When shooting a video is needed, switch the shooting mode to movie mode. Please turn off your camera before switching modes. For EOS R/RP/R5/R6, shutter release can't be used to control video shooting in photo mode otherwise the camera may freeze. (In this case please take out the camera batteries and reinstall and turn on the camera again).

Comoro		Photo	۱ ۱	/ideo	Live	Shutte Adjus	r Speed tment	Apeı Adjus	rture tment		50 tment		EV tment	Zoom	Halfway Press	Electronic Follow	НДМІ	Camera Control Cable	Camera	
Camera Model	Save	Playback	Save	Playback	Preview	Photo Mode	Video Mode	Photo Mode	Video Mode	Photo Mode		Photo Mode		(Digital/ Optical)	Shutter Button to Autofocus	Focus (Focus Wheel)	Cable Type	Туре	Firmware Version	
Nikon D850	V	V	V	-	-	V	V	V	V	V	V	-	-	-	V	V	-	Type-C to Micro USB	V1.11	1. 2. 3.
Nikon D780	J	J	V	V	-	V	V	V	V	√	V	-	-	-	V	V	-	Type-C to Type-C USB	V1.01	4.
Nikon Z5	V	1	1	√	-	V	V	V	V	V	V	-	-	-	1	1	-	Type-C to Type-C USB	V1.00	
Nikon Z6	V	1	1	√	-	V	V	V	V	V	V	-	-	-	1	1	-	Type-C to Type-C USB	V3.00	
Nikon Z6 II	V	1	1	V	-	V	V	V	V	1	1	-	-	-	1	1	-	Type-C to Type-C USB	V1.00	
Nikon Z7	V	1	1	√	-	V	V	V	V	√	1	-	-	-	1	1	-	Type-C to Type-C USB	V2.01	
Nikon Z7 II	V	1	1	V	-	V	V	V	V	1	V	-	-	-	1	1	-	Type-C to Type-C USB	V1.00	1.
Nikon Z8	V	1	1	V	-	V	V	V	V	1	V	-	-	-	1	1	-	Type-C to Type-C USB	V1.00	2.
Nikon Z30	V	1	1	V	-	V	V	V	V	1	1	-	-	-	V	1	-	Type-C to Type-C USB	V1.00	- 3.
Nikon Z30	V	1	1	V	-	V	V	V	V	1	1	-	-	-	1	1	-	Type-C to Type-C USB	V1.0.0	
Nikon Z50	V	1	1	√	-	V	V	1	V	√	1	-	-	-	1	1	-	Type-C to Micro USB	V1.00	
Nikon Z fc	V	1	1	√	-	V	V	V	V	J	V	-	-	-	1	1	-	Type-C to Type-C USB	V1.00	
Nikon Zf	V	1	1	J	-	-	-	V	V	-	-	-	-	-	1	-	-	Type-C to Type-C USB LN-UCUC-A02	V1.00	
Olympus OM-DE-M1 Mark II	V	J	V	V	-	V	V	J	V	1	J	-	-	-	V	V	-	Type-C to Type-C USB	V3.1	1.

Note

- When using electronic focusing, the camera lens should be in A(AF) mode and select AF-S or AF-C in focusing mode.
- Nikon cameras don't support electronic focusing when recording.
- When shooting Panorama or Timelapse, it is recommended to turn off image review in the Nikon camera to reduce system latency.
- The "Real-time Preview" feature is for users to switch between electronic viewfinder and optical viewfinder in DSLR by single-clicking the LV button of the gimbal.

- When using electronic focusing, the camera lens should be in A(AF) mode and select AF-S or AF-C in focusing mode.
- Nikon cameras don't support electronic focusing when recording.
- When shooting Panorama or Timelapse, it is
- recommended to turn off image review in the Nikon camera to reduce system latency.

When connecting an Olympus camera to the gimbal, USB Mode will automatically pops up on the camera. Please select [🖵 📭] (PC (Tether)) and dial the mode to P, A, S, or M mode.

Comoro		Photo	۱ ۱	/ideo	Live	Shutte Adjus	r Speed tment	Aper Adjus	rture tment	IS Adjus	50 tment		V tment	Zoom	Halfway Press	Electronic Follow	НДМІ	Camera Control Cable	Camera	
Camera Model	Save	Playback	Save	Playback	Preview	Photo Mode	Video Mode	Photo Mode	Video Mode	Photo Mode		Photo Mode	Video Mode	(Digital/ Optical)	Shutter Button to Autofocus	Focus (Focus Wheel)	Cable Type	Туре	Firmware Version	
Fujifilm X-T3	V	V	J	J	-	V	-	-	-	V	V	-	-	-	J	-		Type-C to Type-C USB	V3.10	1.
Fujifilm X-T4	V	V	1	J	-	J	-	-	-	1	V	-	-	-	J	-	-	Type-C to Type-C USB	V1.01	2.
Fujifilm X-S20	V	J	J	J	-	V	-	-	-	V	V	-	-	-	J	-	-	Type-C to Type-C USB LN-UCUC-A02	V1.10	-
Fujifilm X-T5	V	J	J	J	-	V	-	-	-	V	J	-	-	-	J	-	-	Type-C to Type-C USB	V1.00	1. 2.
Fujifilm X-H2s	V	J	J	J	-	J	-	-	-	V	J	-	-	-	J	-	-	Type-C to Type-C USB	V1.0.0	1.
ZCAM E2	-	-	V	1	-	-	-	-	-	1	V	-	-	-	-	-	-	Type-C to Type-C USB	V0.93	1.
SIGMA fp	\checkmark	-	√	-	-	-	-	-	-	-	-	-	-	-	\checkmark	-	-	Type-C to Type-C USB	V2.00	

Note:

1. This table will be updated in line with firmware update and is subject to change without prior notice;

2. For Sony cameras, after connecting gimbal and camera with control cable, Please first power on the gimbal and then the camera. Make sure the camera has sufficient power to operate. Optical zoom control is available on the gimbal when used with motorized lens. Digital zoom control is available on the gimbal when used with non-motorized lens. Please select zoom option in your camera's settings;

3. When shooting Panorama or Timelapse, it is recommended to turn off the camera's auto review (Sony), image confirmation (Canon), auto review (Panasonic), image review (Nikon) to reduce system latency.

4. The Canon DSLR cannot realize the halfway press shutter button to autofocus in Live Preview. If the feature is used, the camera Live Preview mode should be turned off.

5. Before connecting Panasonic G9 with a control cable, please first turn off the USB Power Supply in camera settings

6. When connecting an Olympus camera to the gimbal, USB Mode will automatically pops up on the camera. Please select [🖵 🗖] (PC (Tether)) and dial the mode to P, A, S, or M mode.

7. " $\sqrt{}$ " means the camera can achieve the function after connecting to the gimbal; "×" means the camera currently cannot achieve the function after connecting to the gimbal, but there' re possibilities that the function may be available after the firmware upgrade or other ways. "-" means the function is not available after connecting to the gimbal due to the unopened camera protocol.

Note

 Please set the "connection mode" into "USB TETHER shooting auto" for camera connection settings.
 In Photo mode of Fujifilm, when the camera is connected to the gimbal, the camera parameter control from camera is disabled and you can only adjust camera parameters via gimbal. Restart the camera to resume parameter control from camera. Plug in and out the camera control cable to return to gimbal control; Fujifilm doesn't support saving photosin RAW format.

 Please set the "connection mode" into "USB TETHER shooting auto" for camera connection settings.
 Fujifilm doesn't support saving photos in RAW format.

L. Please set the "connection mode" into "USB TETHER shooting auto" for camera connection settings.

 Click [MENU], select [connect] and set [USB] to [serial]; Set [serial] to [controller].

				Balance A	djustment	Camera Ba	cking Base		
Camera Brand	Model	Lens Model	Mounting Status	Horizontal	Vertical	Horizontal	Vertical	Focus/Zoom Control Motor	
			Camera and Lens	√	-	√	-		Can be balanced at
			with Focus/Zoom Control Motor (For Focus Control)	1	-	V	-	Focus/Zoom Control Motor installed on left side	Can be balanced at
			with Focus/Zoom Control Motor (For Zoom Control)	1	-	V	-	Focus/Zoom Control Motor installed on left side	Can be balanced at
		EF 16-35mm f/4L IS USM	with transmission transmitter	1	-	1	-		Can be balanced at
			with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	1	-	√	-	Focus/Zoom Control Motor installed on left side	Can be balanced at a
			with transmission transmitter and Focus/Zoom Control Motor (For Zoom Control)	1	-	√	-	Focus/Zoom Control Motor installed on left side	Can be balanced at
			Camera and Lens	1	-	1	-		Can be balanced at
			with Focus/Zoom Control Motor (For Focus Control)	1	-	J	-	Focus/Zoom Control Motor installed on either side	Can be balanced at
			with Focus/Zoom Control Motor (For Zoom Control)	√	-	1	-	Focus/Zoom Control Motor installed on either side	Can be balanced at
	5DS、	EF 16-35mm f/2.8L III USM	with transmission transmitter	√	-	√	-		Can be balanced at
	5DS R、 5D Mark III、		with transmission transmitter and Focus/Zoom Control Motor	1	-	J	-		Can be balanced at
Canon	5D Mark IV、 6D Mark II、 6D、		(For Focus Control) with transmission transmitter and Focus/Zoom Control Motor (For Zoom Control)	√	-	√			Can be balanced at a
	90D、		Camera and Lens	J	-	1	-		Can be balanced at
	80D、 EOS 850D、		with Focus/Zoom Control Motor (For Focus Control)	√	-	√	-	Focus/Zoom Control Motor installed on either side	Can be balanced at
	EOS 800D、 200D II		with Focus/Zoom Control Motor (For Zoom Control)	√	-	V	-	Focus/Zoom Control Motor installed on either side	Can be balanced at
		EF 17-40mm f/4L USM	with transmission transmitter	√	-	√	-		Can be balanced at
			with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	1	-	√	-		Can be balanced at
			with transmission transmitter and Focus/Zoom Control Motor (For Zoom Control)	1	-	√	-		Can be balanced at
			Camera and Lens	1	-	1	-		Can be balanced at
			with Focus/Zoom Control Motor (For Focus Control)	√	-	V	-	Focus/Zoom Control Motor installed on left side	Can be balanced at
			with Focus/Zoom Control Motor (For Zoom Control)	√	-	V	-	Focus/Zoom Control Motor installed on left side	Can be balanced a
		EF 24-70mm f/2.8L II USM	with transmission transmitter	√	-	√	-		Can be balanced a
			with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	1	-	√	-	Focus/Zoom Control Motor installed on left side	Can be balanced at
			with transmission transmitter and Focus/Zoom Control Motor (For Zoom Control)	1	-	√	-	Focus/Zoom Control Motor installed on left side	Can be balanced a

Installation Remark

at any focal length, no need to remove eyepiece cap at any focal length, no need to remove eyepiece cap at any focal length, no need to remove eyepiece cap at any focal length, no need to remove eyepiece cap at any focal length, no need to remove eyepiece cap at any focal length, no need to remove eyepiece cap at any focal length, no need to remove eyepiece cap at any focal length, no need to remove eyepiece cap at any focal length, no need to remove eyepiece cap at any focal length, no need to remove eyepiece cap at any focal length, no need to remove eyepiece cap at any focal length, no need to remove eyepiece cap at any focal length, no need to remove eyepiece cap at any focal length, no need to remove eyepiece cap at any focal length, no need to remove eyepiece cap at any focal length, no need to remove eyepiece cap at any focal length, no need to remove eyepiece cap at any focal length, no need to remove eyepiece cap l at 24mm-50mm, no need to remove eyepiece cap l at 24mm-50mm, no need to remove eyepiece cap l at 24mm-50mm, no need to remove eyepiece cap l at 24mm-50mm, no need to remove eyepiece cap l at 24mm-50mm, no need to remove eyepiece cap

at 24mm-50mm, no need to remove eyepiece cap

_				Balance A	djustment	Camera Ba	cking Base		
Camera Brand	Model	Lens Model	Mounting Status	Horizontal	Vertical	Horizontal	Vertical	Focus/Zoom Control Motor	
			Camera and Lens	√	-	√	-		Can be balanced at
			with Focus/Zoom Control Motor (For Focus Control)	1	-	1	-	Focus/Zoom Control Motor installed on either side	Can be balanced at
			with Focus/Zoom Control Motor (For Zoom Control)	1	-	1	-	Focus/Zoom Control Motor installed on either side	Can be balanced at
		EF 24-70mm f/4L IS USM	with transmission transmitter	1	-	1	-		Can be balanced at
			with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	1	-	V	-		Can be balanced at
			with transmission transmitter and Focus/Zoom Control Motor (For Zoom Control)	1	-	√	-		Can be balanced at
			Camera and Lens	\checkmark	-	\checkmark	-		Can be balanced
			with Focus/Zoom Control Motor (For Focus Control)	1	-	1	-	Focus/Zoom Control Motor installed on left side	Can be balanced
	5DS、		with Focus/Zoom Control Motor (For Zoom Control)	-	-	-	-		
	5DS R、	EF 24-105mm f/4L IS II USM	with transmission transmitter	-	-	-	-		
	5D Mark III、 5D Mark IV、 6D Mark II、		with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	-	-	-	-		
Canon	6D、 90D、 80D、		with transmission transmitter and Focus/Zoom Control Motor (For Zoom Control)	-	-	-	-		
	EOS 850D、		Camera and Lens	1	-	1	-		Can be balanced at
	EOS 800D、 200D II		with Focus/Zoom Control Motor (For Focus Control)	1	-	V	-	Focus/Zoom Control Motor installed on either side	Can be balanced at
			with Focus/Zoom Control Motor (For Zoom Control)	-	-	-	-		
		EF 24-105mm f/3.5-5.6 IS STM	with transmission transmitter	\checkmark	-	\checkmark	-		Can be balanced at
			with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	1	-	√	-		Can be balanced at
			with transmission transmitter and Focus/Zoom Control Motor (For Zoom Control)	-	-	-	-		
			Camera and Lens	√	-	√	-		N
			with Focus/Zoom Control Motor (For Focus Control)	1	-	V	-	Focus/Zoom Control Motor installed on either side	Ν
		EF 24mm f/1.4L II USM	with transmission transmitter	√	-	√	-		Ν
			with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	J	-	V	-		Ν

Installation Remark

at any focal length, no need to remove eyepiece cap at any focal length, no need to remove eyepiece cap at any focal length, no need to remove eyepiece cap at any focal length, no need to remove eyepiece cap at any focal length, no need to remove eyepiece cap at any focal length, no need to remove eyepiece cap at any focal length, no need to remove eyepiece cap eed at 24mm-50mm, need to remove eyepiece cap teed at 24mm-50mm, need to remove eyepiece cap

at any focal length, no need to remove eyepiece cap

at any focal length, no need to remove eyepiece cap

at any focal length, no need to remove eyepiece cap

at any focal length, no need to remove eyepiece cap

Comore Drand	Madal	Long Madel	Mounting Status	Balance A	djustment	Camera Ba	cking Base	Forme/Zoom Control Motor	Installation Domovic
Camera Brand	Model	Lens Model	Mounting Status	Horizontal	Vertical	Horizontal	Vertical	Focus/Zoom Control Motor	Installation Remark
			Camera and Lens	\checkmark	-	√	-		No need to remove eyepiece cap
			with Focus/Zoom Control Motor (For Focus Control)	\checkmark	-	√	-	Focus/Zoom Control Motor installed on either side	No need to remove eyepiece cap
		EF 35mm f/1.4L II USM	with transmission transmitter	\checkmark	-	√	-		No need to remove eyepiece cap
			with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	V	-	√	-		No need to remove eyepiece cap
			Camera and Lens	\checkmark	-	√	-		No need to remove eyepiece cap
			with Focus/Zoom Control Motor (For Focus Control)	\checkmark	-	√	-	Focus/Zoom Control Motor installed on either side	No need to remove eyepiece cap
		EF 50mm f/1.4 USM	with transmission transmitter	\checkmark	-	√	-		No need to remove eyepiece cap
	5DS、		with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	V	-	1	-		No need to remove eyepiece cap
			Camera and Lens	\checkmark	-	\checkmark	-		No need to remove eyepiece cap
	5DS 5DS R 5D Mark III、	EF 85mm f/1.4L IS USM	with Focus/Zoom Control Motor (For Focus Control)		-	\checkmark	-	Focus/Zoom Control Motor installed on either side	No need to remove eyepiece cap
	5D Mark IV.		with transmission transmitter	\checkmark	-	\checkmark	-		No need to remove eyepiece cap
Canon	6D Mark II 、 6D、 90D、		with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	\checkmark	-	\checkmark	-		No need to remove eyepiece cap
	80D、		Camera and Lens		-	√	-		No need to remove eyepiece cap
	EOS 850D、 EOS 800D、		with Focus/Zoom Control Motor (For Focus Control)	\checkmark	-	√	-	Focus/Zoom Control Motor installed on either side	No need to remove eyepiece cap
	200D II	EF 85mm f/1.8 USM	with transmission transmitter	\checkmark	-	\checkmark	-		No need to remove eyepiece cap
			with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)		-	\checkmark	-		No need to remove eyepiece cap
			Camera and Lens		-	\checkmark	-	Can b	e balanced at any focal length, no need to remove eyepiece cap
			with Focus/Zoom Control Motor (For Focus Control)	-	-	-	-		
			with Focus/Zoom Control Motor (For Zoom Control)	-	-	-	-		
		Sigma 24-70mm f/2.8 DG HSM Art	with transmission transmitter	\checkmark	-	√	-	Can b	e balanced at any focal length, no need to remove eyepiece cap
			with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	-	-	-	-		
			with transmission transmitter and Focus/Zoom Control Motor (For Zoom Control)	-	-	-	-		

				Balance A	djustment	Camera Ba	cking Base		
Camera Brand	Model	Lens Model	Mounting Status	Horizontal	Vertical	Horizontal	Vertical	Focus/Zoom Control Motor	
			Camera and Lens	\checkmark	-	√	-		Ν
	5DS、		with Focus/Zoom Control Motor (For Focus Control)	\checkmark	-	\checkmark	-	Focus/Zoom Control Motor installed on either side	Ν
	5DS R、 5D Mark III、	Sigma 35mm f/1.4 DG HSM Art	with transmission transmitter	\checkmark	-	√	-		Ν
	5D Mark IIV 5D Mark IV 6D Mark II V 6D V		with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)		-	√	-		N
	90D、		Camera and Lens	\checkmark	-	\checkmark	-		Ν
	80D、 EOS 850D、		with Focus/Zoom Control Motor (For Focus Control)	\checkmark	-	V	-	Focus/Zoom Control Motor installed on either side	Ν
	EOS 800D、	Sigma 50mm f/1.4 DG HSM Art	with transmission transmitter	\checkmark	-	√	-		Ν
	200D II		with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	\checkmark	-	V	-	Focus/Zoom Control Motor installed on either side	Ν
			<u></u>						
			Camera and Lens	\checkmark	-	√	-		Can be balanced a
		EF 16-35mm f/4L IS USM	with Focus/Zoom Control Motor (For Focus Control)	\checkmark	-	√	-	Focus/Zoom Control Motor installed on either side	Can be balanced a
Canon			with Focus/Zoom Control Motor (For Zoom Control)	\checkmark	-	\checkmark	-	Focus/Zoom Control Motor installed on either side	Can be balanced a
			with transmission transmitter	\checkmark	-	\checkmark	-		Can be balanced a
	R50、		with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	\checkmark	-	√	-	Focus/Zoom Control Motor installed on either side	Can be balanced a
	EOS R、 EOS RP、 EOS R5、		with transmission transmitter and Focus/Zoom Control Motor (For Zoom Control)	\checkmark	-	V	-	Focus/Zoom Control Motor installed on either side	Can be balanced a
	EOS R6、		Camera and Lens	-	-	-	-		
	EOS R7、 EOS R8、		with Focus/Zoom Control Motor (For Focus Control)	-	-	-	-		
	EOS R10		with Focus/Zoom Control Motor (For Zoom Control)	-	-	-	-		
		EF 16-35mm f/2.8L III USM	with transmission transmitter	-	-	-	-		
		EF 16-35mm T/2.8L III USM	with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	-	-	-	-		
			with transmission transmitter and Focus/Zoom Control Motor (For Zoom Control)	-	-	-	-		

Installation Remark

No need to remove eyepiece cap

d at any focal length; Do not remove eyepiece cap

d at any focal length; Do not remove eyepiece cap

d at any focal length; Do not remove eyepiece cap

d at any focal length; Do not remove eyepiece cap

d at any focal length; Do not remove eyepiece cap

d at any focal length; Do not remove eyepiece cap

				Balance A	djustment	Camera Ba	cking Base		
Camera Brand	Model	Lens Model	Mounting Status	Horizontal	Vertical	Horizontal	Vertical	Focus/Zoom Control Motor	
			Camera and Lens		-	1	-		Can be balanced
			with Focus/Zoom Control Motor (For Focus Control)	\checkmark	-	√	-	Focus/Zoom Control Motor installed on either side	Can be balanced
			with Focus/Zoom Control Motor (For Zoom Control)	\checkmark	-	\checkmark	-	Focus/Zoom Control Motor installed on either side	Can be balanced
		EF 17-40mm f/4L USM	with transmission transmitter	\checkmark	-	\checkmark	-		Can be balanced a
			with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	-	-	-	-		
			with transmission transmitter and Focus/Zoom Control Motor (For Zoom Control)	-	-	-	-		
		EF 24-70mm f/2.8L II USM	Camera and Lens	-	-	-	-		
	R50、		with Focus/Zoom Control Motor (For Focus Control)	-	-	-	-		
	EOS R、 EOS RP、		with Focus/Zoom Control Motor (For Zoom Control)	-	-	-	-		
Canon	EOS R5、		with transmission transmitter	-	-	-	-		
	EOS R6、 EOS R7、 EOS R8、 EOS R10		with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	-	-	-	-		
			with transmission transmitter and Focus/Zoom Control Motor (For Zoom Control)	-	-	-	-		
			Camera and Lens	1	-	1	-		Can be balan
			with Focus/Zoom Control Motor (For Focus Control)	√	-	1	-	Focus/Zoom Control Motor installed on either side	Can be balar
			with Focus/Zoom Control Motor (For Zoom Control)	√	-	V	-	Focus/Zoom Control Motor installed on left side	Can be balar
		EF 24-70mm f/4L IS USM	with transmission transmitter	-	-	-	-		
		EF 24-70mm 1/4L IS USM	with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	-	-	-	-		
			with transmission transmitter and Focus/Zoom Control Motor (For Zoom Control)	-	-	-	-		

Installation Remark

ed at any focal length; Do not remove eyepiece cap

ed at any focal length; Do not remove eyepiece cap

ed at any focal length; Do not remove eyepiece cap

ed at any focal length; Do not remove eyepiece cap

lanced at 24mm; Do not remove eyepiece cap

alanced at 24mm; Do not remove eyepiece cap

alanced at 24mm; Do not remove eyepiece cap

				Balance A	djustment	Camera Ba	cking Base		
Camera Brand	Model	Lens Model	Mounting Status	Horizontal	Vertical	Horizontal	Vertical	Focus/Zoom Control Motor	
			Camera and Lens	√	-	√	-		Can be balan
			with Focus/Zoom Control Motor (For Focus Control)	-	-	-	-		
			with Focus/Zoom Control Motor (For Zoom Control)	-	-	-	-		
		EF 24-105mm f/4L IS II USM	with transmission transmitter	-	-	-	-		
			with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	-	-	-	-		
			with transmission transmitter and Focus/Zoom Control Motor (For Zoom Control)	-	-	-	-		
			Camera and Lens	1	-	1	-		Can be balanced
	R50、 EOS R、		with Focus/Zoom Control Motor (For Focus Control)	√	-	1	-	Focus/Zoom Control Motor installed on left side	Can be balanced
			with Focus/Zoom Control Motor (For Zoom Control)	√	-	V	-	Focus/Zoom Control Motor installed on left side	Can be balanced
	EOS RP.	EF 24-105mm f/3.5-5.6 IS STM	with transmission transmitter	-	-	-	-		
Canon	EOS R5、 EOS R6、 EOS R7、 EOS R8、 EOS R10		with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	-	-	-	-		
			with transmission transmitter and Focus/Zoom Control Motor (For Zoom Control)	-	-	-	-		
			Camera and Lens	√	-	√	-		
			with Focus/Zoom Control Motor (For Focus Control)	√	-	1	-	Focus/Zoom Control Motor installed on either side	
		EF 24mm f/1.4L II USM	with transmission transmitter	√	-	√	-		
			with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	√	-	√	-	Focus/Zoom Control Motor installed on either side	
			Camera and Lens	1	-	√	-		
			with Focus/Zoom Control Motor (For Focus Control)	1	-	V	-	Focus/Zoom Control Motor installed on either side	
		EF 35mm f/1.4L II USM	with transmission transmitter	√	-	√	-		
		-	with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	V	-	V	-	Focus/Zoom Control Motor installed on either side	

Installation Remark

anced at 24mm;Need to remove eyepiece cap

ed at any focal length; Do not remove eyepiece cap

ed at any focal length; Do not remove eyepiece cap

ed at any focal length; Do not remove eyepiece cap

				Balance A	djustment	Camera Ba	cking Base		
Camera Brand	Model	Lens Model	Mounting Status	Horizontal	Vertical	Horizontal	Vertical	Focus/Zoom Control Motor	Installation Remark
			Camera and Lens	√	-	1	-		Do not remove eyepiece cap
			with Focus/Zoom Control Motor (For Focus Control)	V	-	V	-	Focus/Zoom Control Motor installed on either side	Do not remove eyepiece cap
		EF 50mm f/1.2L USM	with transmission transmitter	1	-	\checkmark	-		Do not remove eyepiece cap
			with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	√	-	√	-	Focus/Zoom Control Motor installed on either side	Do not remove eyepiece cap
			Camera and Lens	√	-	√	-		Do not remove eyepiece cap
			with Focus/Zoom Control Motor (For Focus Control)	V	-	V	-	Focus/Zoom Control Motor installed on either side	Do not remove eyepiece cap
		EF 50mm f/1.4 USM	with transmission transmitter	√	-	√	-		Do not remove eyepiece cap
			with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	1	-	√	-	Focus/Zoom Control Motor installed on either side	Do not remove eyepiece cap
			Camera and Lens	√	-	√	-		Do not remove eyepiece cap
	R50、		with Focus/Zoom Control Motor (For Focus Control)	-	-	-	-		
	EOS R.	EF 85mm f/1.4L IS USM	with transmission transmitter	-	-	-	-		
Canon	EOS RP、 EOS R5、 EOS R6、		with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	-	-	-	-		
	EOS R7、 EOS R8、		Camera and Lens	1	-	√	-		Do not remove eyepiece cap
	EOS R10		with Focus/Zoom Control Motor (For Focus Control)	√	-	√	-	Focus/Zoom Control Motor installed on either side	Do not remove eyepiece cap
		EF 85mm f/1.8 USM	with transmission transmitter	-	-	-	-		
			with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	-	-	_	-		
			Camera and Lens	-	-	-	-		
			with Focus/Zoom Control Motor (For Focus Control)	-	-	-	-		
			with Focus/Zoom Control Motor (For Zoom Control)	-	-	-	-		
		Sigma 24-70mm f/2.8 DG HSM Art	with transmission transmitter	-	-	-	-		
			with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	-	-	-	-		
			with transmission transmitter and Focus/Zoom Control Motor (For Zoom Control)	-	-	-	-		

				Balance A	djustment	Camera Ba	cking Base		
Camera Brand	Model	Lens Model	Mounting Status	Horizontal	Vertical	Horizontal	Vertical	Focus/Zoom Control Motor	
			Camera and Lens	√	-	1	-		
			with Focus/Zoom Control Motor (For Focus Control)	√	-	V	-	Focus/Zoom Control Motor installed on either side	
		Sigma 35mm f/1.4 DG HSM Art	with transmission transmitter	√	-	√	-		
			with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	1	-	V	-	Focus/Zoom Control Motor installed on either side	
			Camera and Lens	√	-	1	-		
		Sigma 50mm f/1.4 DG HSM Art	with Focus/Zoom Control Motor (For Focus Control)	√	-	V	-	Focus/Zoom Control Motor installed on either side	
			with transmission transmitter	1	-	√	-		
			with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	√	-	V	-	Focus/Zoom Control Motor installed on either side	
			Camera and Lens	1	-	1	-		
		RF 24-70mm f/2.8 L IS USM	with Focus/Zoom Control Motor (For Focus Control)	√	-	√	-	Focus/Zoom Control Motor installed on right side	
			with Focus/Zoom Control Motor (For Zoom Control)	√	-	V	-	Focus/Zoom Control Motor installed on left side	
	R50、 EOS R、		with transmission transmitter	√	-	√	-		Can be balanced at 2
Canon	EOS RP, EOS R5, EOS R6, EOS R7, EOS R8, EOS R10		with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	√	-	√	-	Focus/Zoom Control Motor installed on right side	S
			with transmission transmitter and Focus/Zoom Control Motor (For Zoom Control)	√	-	V	-	Focus/Zoom Control Motor installed on left side	
	LOOKIO		Camera and Lens	\checkmark	-	\checkmark	-		Can be balanced at
			with Focus/Zoom Control Motor (For Focus Control)	-	-	-	-		
			with Focus/Zoom Control Motor (For Zoom Control)	-	-	-	-		
		RF 15-35mm f/2.8 L IS USM	with transmission transmitter	√	-	√	-		
			with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	-	-	-	-		
			with transmission transmitter and Focus/Zoom Control Motor (For Zoom Control)	-	-	-	-		
			Camera and Lens	√	-	√	-		
			with Focus/Zoom Control Motor (For Focus Control)	1	-	V	-	Focus/Zoom Control Motor installed on either side	
		RF50mm F1.2 L USM	with transmission transmitter	-	-	-	-		
			with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	-	-	-	-		

Installation Remar	k	
--------------------	---	--

Do not remove eyepiece cap

at 24mm; Do not remove eyepiece cap (eyepiece cap slightly rub against the camera)

at any focal length, no need to remove eyepiece cap

Do not remove eyepiece cap

Do not remove eyepiece cap

Do not remove eyepiece cap

				Balance A	djustment	Camera Ba	cking Base	_ /	
Camera Brand	Model	Lens Model	Mounting Status	Horizontal	Vertical	Horizontal	Vertical	Focus/Zoom Control Motor	
			Camera and Lens	1	-	1	-		
			with Focus/Zoom Control Motor (For Focus Control)	√	-	√	-		
		EF-M 32mm f/1.4 STM	with transmission transmitter	1	-	√	-		
			with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	V	-	1	-		
			Camera and Lens	1	-	√	-		
			with Focus/Zoom Control Motor (For Focus Control)	√	-	√	-		
			with Focus/Zoom Control Motor (For Zoom Control)	√	-	√	-		
		EF-M 11-22mm f/4-5.6 IS STM	with transmission transmitter	1	-	√	-		
			with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	1	-	√	-		
			with transmission transmitter and Focus/Zoom Control Motor (For Zoom Control)	1	-	\checkmark	-		
			Camera and Lens	1	-	1	-		
Canon	EOS M50、 EOS M6 Mark II		with Focus/Zoom Control Motor (For Focus Control)	√	-	√	-		
			with Focus/Zoom Control Motor (For Zoom Control)	1	-	1	-		
		EF-M 15-45mm f/3.5-6.3 IS STM	with transmission transmitter	1	-	√	-		
		LI -M 13-401111 / 3.5-0.3 13 5 1 M	with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	√	-	√	-		
			with transmission transmitter and Focus/Zoom Control Motor (For Zoom Control)	1	-	1	-		
			Camera and Lens	√	-	√	-		
			with Focus/Zoom Control Motor (For Focus Control)	√	-	√	-		
			with Focus/Zoom Control Motor (For Zoom Control)	√	-	√	-		
		EF-M 18-55mm f/3.5-5.6 IS STM	with transmission transmitter	\checkmark	-	√	-		
		EF-M 18-55mm 1/3.5-5.6 15 51M	with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	1	-	1	-		
			with transmission transmitter and Focus/Zoom Control Motor (For Zoom Control)	V	-	√	-		

Installation Remark

				Balance A	djustment	Camera Ba	cking Base		
Camera Brand	Model	Lens Model	Mounting Status	Horizontal	Vertical	Horizontal	Vertical	Focus/Zoom Control Motor	Installation Remark
			Camera and Lens	1	-	1	-		
			with Focus/Zoom Control Motor (For Focus Control)	1	-	1	-		
			with Focus/Zoom Control Motor (For Zoom Control)	1	-	√	-		
		EF-M 18-150mm f/3.5-6.3 IS STM	with transmission transmitter	√	-	√	-		
			with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	\checkmark	-	\checkmark	-		
			with transmission transmitter and Focus/Zoom Control Motor (For Zoom Control)	V	-	\checkmark	-		
			Camera and Lens	\checkmark	-	\checkmark	-		
		EF-M 55-200mm f/4.5-6.3 IS STM	with Focus/Zoom Control Motor (For Focus Control)	1	-	√	-		
			with Focus/Zoom Control Motor (For Zoom Control)	1	-	1	-		
	EOS M50、		with transmission transmitter	√	-	√	-		
Canon	EOS M6 Mark II		with transmission transmitter and Focus/ Zoom Control Motor (For Focus Control)	1	-	1	-		
			with transmission transmitter and Focus/Zoom Control Motor (For Zoom Control)	\checkmark	-	V	-		
			Camera and Lens	\checkmark	-	√	-		
			with Focus/Zoom Control Motor (For Focus Control)	1	-	√	-		
		EF-M 22mm f/2 STM	with transmission transmitter	\checkmark	-	\checkmark	-		
			with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	V	-	\checkmark	-		
			Camera and Lens	\checkmark	-	\checkmark	-		
			with Focus/Zoom Control Motor (For Focus Control)	1	-	~	-		
		EF-M 28mm f/3.5 IS STM	with transmission transmitter	\checkmark	-	\checkmark	-		
			with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	\checkmark	-	√	-		

				Balance A	djustment	Camera Ba	cking Base	- /	
Camera Brand	Model	Lens Model	Mounting Status	Horizontal	Vertical	Horizontal	Vertical	Focus/Zoom Control Motor	
			Camera and Lens	-	-	-	-		
			with Focus/Zoom Control Motor (For Focus Control)	-	-	-	-		
			with Focus/Zoom Control Motor (For Zoom Control)	-		-	-		
		AF-S NIKKOR 14-24mm f/2.8G ED	with transmission transmitter	-	-	-	-		
			with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	-	-	-	-		
			with transmission transmitter and Focus/Zoom Control Motor (For Zoom Control)	-	-	-	-		
			Camera and Lens	\checkmark	-	√	-		Can be balanced at
			with Focus/Zoom Control Motor (For Focus Control)	\checkmark	-	V	-		Can be balanced at
	with Focus/Zoom Control Motor (For Zoom Control)		\checkmark	-	V	-		Can be balanced at	
Nikon	D850、D780	AF-S NIKKOR 16-35mm f/4G ED VR	with transmission transmitter	√	-	√	-		Can be balanced at
	D850, D780		with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	√	-	V	-		Can be balanced at
			with transmission transmitter and Focus/Zoom Control Motor (For Zoom Control)	1	-	V	-		Can be balanced at
			Camera and Lens	-	-	-	-		
			with Focus/Zoom Control Motor (For Focus Control)	-	-	-	-		
			with Focus/Zoom Control Motor (For Zoom Control)	-	-	-	-		
		AF-S NIKKOR 24-70mm f/2.8E ED VR	with transmission transmitter	-	-	-	-		
		AF-S NIKKOR 24-70mm T/2.8E ED VR	with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	-	-	-	-		
			with transmission transmitter and Focus/Zoom Control Motor (For Zoom Control)	-	-	-	-		

Installation Remark

at any focal length, no need to remove eyepiece cap

at any focal length, no need to remove eyepiece cap

at any focal length, no need to remove eyepiece cap

at any focal length, no need to remove eyepiece cap

at any focal length, no need to remove eyepiece cap

				Balance A	djustment	Camera Ba	cking Base		
Camera Brand	Model	Lens Model	Mounting Status	Horizontal	Vertical	Horizontal	Vertical	Focus/Zoom Control Motor	
			Camera and Lens	-	-	-	-		
			with Focus/Zoom Control Motor (For Focus Control)	-	-	-	-		
			with Focus/Zoom Control Motor (For Zoom Control)	-	-	-	-		
		AF-S NIKKOR 24-70mm f/2.8G ED	with transmission transmitter	-	-	-	-		
			with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	-	-	-	-		
			with transmission transmitter and Focus/Zoom Control Motor (For Zoom Control)	-	-	_	-		
			Camera and Lens	√	-	√	-		Can be balanced at
		AF-S NIKKOR 24-120mm f/4G ED VR	with Focus/Zoom Control Motor (For Focus Control)	-	-	-	-		
			with Focus/Zoom Control Motor (For Zoom Control)	1	-	V	-		Can be balanced at
	Nikon D850、D780		with transmission transmitter	-	-	-	-		
Nikon			with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	-	-	-	-		
			with transmission transmitter and Focus/Zoom Control Motor (For Zoom Control)	-	-	-	-		
			Camera and Lens	1	-	1	-		N
			with Focus/Zoom Control Motor (For Focus Control)	1	-	V	-	Focus/Zoom Control Motor installed on either side	Ν
		AF-S NIKKOR 24mm f/1.4G ED	with transmission transmitter	√	-	√	-		Ν
			with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	1	-	V	-	Focus/Zoom Control Motor installed on either side	N
			Camera and Lens	1	-	1	-		N
			with Focus/Zoom Control Motor (For Focus Control)	1	-	V	-	Focus/Zoom Control Motor installed on either side	Ν
		AF-S NIKKOR 24mm f/1.8G ED	with transmission transmitter	\checkmark	-	√	-		Ν
		-	with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	√	-	V	-	Focus/Zoom Control Motor installed on either side	Ν

Installation Remark

at any focal length, no need to remove eyepiece cap

at any focal length, no need to remove eyepiece cap

	Madal			Balance A	djustment	Camera Bao	king Base	
Camera Brand	Model	Lens Model	Mounting Status	Horizontal	Vertical	Horizontal	Vertical	Focus/Zoom Control Motor Installation Remark
			Camera and Lens	1	-	1	-	No need to remove eyepiece cap
			with Focus/Zoom Control Motor (For Focus Control)	\checkmark	-	\checkmark	-	Focus/Zoom Control Motor installed on either side No need to remove eyepiece cap
		AF-S NIKKOR 35mm f/1.4G	with transmission transmitter	\checkmark	-	√	-	No need to remove eyepiece cap
			with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	V	-	√	-	Focus/Zoom Control Motor installed on either side No need to remove eyepiece cap
			Camera and Lens	\checkmark	-	√	-	No need to remove eyepiece cap
			with Focus/Zoom Control Motor (For Focus Control)	\checkmark	-	V	-	Focus/Zoom Control Motor installed on either side No need to remove eyepiece cap
		AF-S NIKKOR 50mm f/1.4G	with transmission transmitter	\checkmark	-	√	-	No need to remove eyepiece cap
	_		with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	V	-	\checkmark	-	Focus/Zoom Control Motor installed on either side No need to remove eyepiece cap
		AF-S NIKKOR 85mm f/1.4G	Camera and Lens	\checkmark	-	√	-	No need to remove eyepiece cap
			with Focus/Zoom Control Motor (For Focus Control)	\checkmark	-	\checkmark	-	Focus/Zoom Control Motor installed on either side No need to remove eyepiece cap
			with transmission transmitter	-	-	-	-	
Nikon	D850、D780		with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	-	-	-	-	
			Camera and Lens	\checkmark	-	√	-	No need to remove eyepiece cap
			with Focus/Zoom Control Motor (For Focus Control)	\checkmark	-	\checkmark	-	Focus/Zoom Control Motor installed on either side No need to remove eyepiece cap
		AF-S NIKKOR 85mm f/1.8G	with transmission transmitter	-	-	-	-	
			with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	-	-	-	-	
			Camera and Lens	\checkmark	-	√	-	No need to remove eyepiece cap
			with Focus/Zoom Control Motor (For Focus Control)	\checkmark	-	\checkmark	-	Focus/Zoom Control Motor installed on either side No need to remove eyepiece cap
			with Focus/Zoom Control Motor (For Zoom Control)	1	-	\checkmark	-	Focus/Zoom Control Motor installed on either side No need to remove eyepiece cap
		Sigma 24 70mm f/2.8L DG	with transmission transmitter	\checkmark	-	\checkmark	-	Can be balanced at any focal length, no need to remove eyepiece cap
			with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	-	-	-	-	
			with transmission transmitter and Focus/Zoom Control Motor (For Zoom Control)	-	-	-	-	

				Balance A	djustment	Camera Ba	cking Base		
Camera Brand	Model	Lens Model	Mounting Status	Horizontal	Vertical	Horizontal	Vertical	Focus/Zoom Control Motor	
			Camera and Lens	√	-	1	-		N
			with Focus/Zoom Control Motor (For Focus Control)	√	-	1	-	Focus/Zoom Control Motor installed on either side	No
		Sigma 35mm F1.4 DG	with transmission transmitter	1	-	1	-		Can be balanced at a
Nikon			with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	√	-	V	-		Can be balanced at a
NIKON	D850、D780		Camera and Lens	\checkmark	-	√	-		No
			with Focus/Zoom Control Motor (For Focus Control)	1	-	1	-	Focus/Zoom Control Motor installed on either side	No
		Sigma 50mm F1.4 DG	with transmission transmitter	1	-	√	-		Can be balanced at a
			with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	1	-	V	-		Can be balanced at a
		NIKKOR Z 24-70mm f/2.8S	Camera and Lens	√	-	√	-		Can be balanced at a
			with Focus/Zoom Control Motor (For Focus Control)	√	-	1	-	Focus/Zoom Control Motor installed on either side	Can be balanced at a
			with Focus/Zoom Control Motor (For Zoom Control)	√	-	V	-	Focus/Zoom Control Motor installed on either side	Can be balanced at a
			with transmission transmitter	√	-	\checkmark	-		Can be balanced at a
	Z30、 Z50、		with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	1	-	V	-	Focus/Zoom Control Motor installed on either side	Can be balanced at a
	Z5、 Z6、		with transmission transmitter and Focus/Zoom Control Motor (For Zoom Control)	1	-	√	-	Focus/Zoom Control Motor installed on either side	Can be balanced at a
Nikon	Z6 II、 Z7、		Camera and Lens	1	-	√	-		Can be balanced at a
	Z7 II. Z7 C.		with Focus/Zoom Control Motor (For Focus Control)	_	-	-	-		
	Zf		with Focus/Zoom Control Motor (For Zoom Control)	√	-	V	-		Can be balanced at a
		NIKKOR Z 24-70mm f/4S	with transmission transmitter	√	-	√	-		Can be balanced at a
			with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	-	-	-	-		
			with transmission transmitter and Focus/Zoom Control Motor (For Zoom Control)	1	-	√	-		Can be balanced at a

Installation Remark

No need to remove eyepiece cap

No need to remove eyepiece cap

at any focal length, no need to remove eyepiece cap

at any focal length, no need to remove eyepiece cap

No need to remove eyepiece cap

No need to remove eyepiece cap

at any focal length, no need to remove eyepiece cap

at any focal length, no need to remove eyepiece cap

at any focal length, no need to remove eyepiece cap

at any focal length, no need to remove eyepiece cap

at any focal length, no need to remove eyepiece cap

at any focal length, no need to remove eyepiece cap

at any focal length, no need to remove eyepiece cap

at any focal length, no need to remove eyepiece cap

at any focal length, no need to remove eyepiece cap

at any focal length, no need to remove eyepiece cap

at any focal length, no need to remove eyepiece cap

				Balance A	djustment	Camera Ba	cking Base	Earny/Zaam Cantus Matan	
Camera Brand	Model	Lens Model	Mounting Status	Horizontal	Vertical	Horizontal	Vertical	Focus/Zoom Control Motor	
			Camera and Lens	√	-	√	-		Can be balanced at
			with Focus/Zoom Control Motor (For Focus Control)	1	-	V	-	Focus/Zoom Control Motor installed on either side	Can be balanced at
		NIKKOR Z 35mm f/1.8S	with transmission transmitter	√	-	√	-		Can be balanced at
			with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	V	-	V	-	Focus/Zoom Control Motor installed on either side	Can be balanced at a
			Camera and Lens	√	-	√	-		Can be balanced at
		NIKKOR Z 50mm f/1.8S	with Focus/Zoom Control Motor (For Focus Control)	√	-	V	-	Focus/Zoom Control Motor installed on either side	Can be balanced at a
			with transmission transmitter	√	-	√	-		Can be balanced at
			with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	1	-	V	-	Focus/Zoom Control Motor installed on either side	Can be balanced at a
	Z30、	AF-S NIKKOR 14-24mm f/2.8G ED	Camera and Lens	1	-	1	-		Can be balanced at a
	Z50、 Z5、		with Focus/Zoom Control Motor (For Focus Control)	-	-	-	-		
Nikon	Z6、 Z6 II、		with Focus/Zoom Control Motor (For Zoom Control)	-	-	-	-		
	Ζ7、		with transmission transmitter	\checkmark	-	√	-		Can be balanced at
	Z7 II、 Z fc、 Zf		with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	-	-	-	-		
			with transmission transmitter and Focus/Zoom Control Motor (For Zoom Control)	-	-	-	-		
			Camera and Lens	\checkmark	-	√	-		Can be balanced at
			with Focus/Zoom Control Motor (For Focus Control)	1	-	V	-		Can be balanced at a
			with Focus/Zoom Control Motor (For Zoom Control)	√	-	√	-		Can be balanced at
		AF-S NIKKOR 16-35mm f/4G ED VR	with transmission transmitter	√	-	√	-		Can be balanced at
			with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	-	-	_	-		
			with transmission transmitter and Focus/Zoom Control Motor (For Zoom Control)	-	-	-	_		

Installation Remark

at any focal length, no need to remove eyepiece cap at any focal length, no need to remove eyepiece cap at any focal length, no need to remove eyepiece cap at any focal length, no need to remove eyepiece cap at any focal length, no need to remove eyepiece cap at any focal length, no need to remove eyepiece cap at any focal length, no need to remove eyepiece cap at any focal length, no need to remove eyepiece cap at any focal length, no need to remove eyepiece cap at any focal length, no need to remove eyepiece cap at any focal length, no need to remove eyepiece cap

at any focal length, no need to remove eyepiece cap

at any focal length, no need to remove eyepiece cap

at any focal length, no need to remove eyepiece cap

at any focal length, no need to remove eyepiece cap

at any focal length, no need to remove eyepiece cap

				Balance Ad	djustment	Camera Bao	cking Base		
Camera Brand	Model	Lens Model	Mounting Status	Horizontal	Vertical	Horizontal	Vertical	Focus/Zoom Control Motor	
			Camera and Lens	-	-	-	-		
			with Focus/Zoom Control Motor (For Focus Control)	-	-	-	-		
			with Focus/Zoom Control Motor (For Zoom Control)	-	-	-	-		
		AF-S NIKKOR 24-70mm f/2.8E ED VR	with transmission transmitter	-	-	-	-		
			with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	-	-	-	-		
			with transmission transmitter and Focus/Zoom Control Motor (For Zoom Control)	-	-	-	-		
			Camera and Lens	-	-	-	-		
			with Focus/Zoom Control Motor (For Focus Control)	-	-	-	-		
			with Focus/Zoom Control Motor (For Zoom Control)	-	-	-	-		
	Z30、	AF-S NIKKOR 24-70mm f/2.8G ED	with transmission transmitter	-	-	-	-		
	Z50、 Z5、 Z6、		with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	-	-	-	-		
Nikon	Z6 II、 Z7、 Z7 II、		with transmission transmitter and Focus/Zoom Control Motor (For Zoom Control)	-	-	-	-		
	Z fc、		Camera and Lens	-	-	-	-		
	Zf		with Focus/Zoom Control Motor (For Focus Control)	-	-	-	-		
			with Focus/Zoom Control Motor (For Zoom Control)	-	-	-	-		
		AF-S NIKKOR 24-120mm f/4G ED VR	with transmission transmitter	-	-	-	-		
			with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	-	-	-	-		
			with transmission transmitter and Focus/Zoom Control Motor (For Zoom Control)	-	-	-	-		
			Camera and Lens	\checkmark	-	\checkmark	-		
			with Focus/Zoom Control Motor (For Focus Control)	1	-	√	-		
		AF-S NIKKOR 24mm f/1.4G ED	with transmission transmitter	\checkmark	-	√	-		Can be balanced a
			with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	V	-	√	-		

Installation Remark
at any focal length; Need to remove eyepiece cap

				Balance A	djustment	Camera Ba	cking Base		
Camera Brand	Model	Lens Model	Mounting Status	Horizontal	Vertical	Horizontal	Vertical	Focus/Zoom Control Motor	
			Camera and Lens	√	-	√	-		
			with Focus/Zoom Control Motor (For Focus Control)	1	-	V	-		
		AF-S NIKKOR 24mm f/1.8G ED	with transmission transmitter	\checkmark	-	\checkmark	-		
			with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	V	-	√	-		
			Camera and Lens	\checkmark	-	\checkmark	-		
			with Focus/Zoom Control Motor (For Focus Control)	1	-	√	-		
		AF-S NIKKOR 35mm f/1.4G	with transmission transmitter	\checkmark	-	√	-		Can be balanced a
			with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	V	-	\checkmark	-		
			Camera and Lens	√	-	√	-		
	Z30、 Z50、		with Focus/Zoom Control Motor (For Focus Control)	1	-	V	-		
	Z5、	AF-S NIKKOR 50mm f/1.4G	with transmission transmitter	\checkmark	-	\checkmark	-		
Nikon	Z6、 Z6 II、 Z7、 Z7 II、 Z fc、 Zf		with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	V	-	V	-		
			Camera and Lens	√	-	√	-		Can be balanced at
			with Focus/Zoom Control Motor (For Focus Control)	-	-	-	-		
			with Focus/Zoom Control Motor (For Zoom Control)	-	-	-	-		
		Sigma 24 70mm f/2.8L DG	with transmission transmitter	√	-	√	-		Can be balanced at
			with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	-	-	-	-		
			with transmission transmitter and Focus/Zoom Control Motor (For Zoom Control)	-	-	-	-		
			Camera and Lens	1	-	1	-		Can be balanced a
			with Focus/Zoom Control Motor (For Focus Control)	√	-	√	-		Can be balanced a
		Sigma 35mm F1.4 DG	with transmission transmitter	√	-	1	-		Can be balanced at
		wi	with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	V	-	V	-		Can be balanced at

d at any focal length; Need to remove eyepiece cap

at any focal length, no need to remove eyepiece cap

at any focal length, no need to remove eyepiece cap

d at any focal length; Need to remove eyepiece cap

d at any focal length; Need to remove eyepiece cap

at any focal length, no need to remove eyepiece cap

				Balance A	djustment	Camera Ba	cking Base	_ /	
Camera Brand	Model	Lens Model	Mounting Status	Horizontal	Vertical	Horizontal	Vertical	Focus/Zoom Control Motor	
	Z30、 Z50、		Camera and Lens	1	-	√	-		Can be balanced a
	Z5、 Z6、		with Focus/Zoom Control Motor (For Focus Control)	1	-	√	-		Can be balanced a
	Z6 II、 Z7、 Z7 II、	Sigma 50mm F1.4 DG	with transmission transmitter	1	-	√	-		Can be balanced at
	Z fc. Zf		with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	1	-	√	-		Can be balanced at
			Camera and lens	\checkmark	\checkmark	V	\checkmark		Landscape: eyepiece Portrait
			with zoom/focus motor (for focus control)	√	\checkmark	1	\checkmark	Zoom/focus motor installed on right side	Landscape: eyepiece Portrai
		NIKKOR Z 24-70mm f/2.8S	with zoom/focus motor (for zoom control)	-	-	-	-	Zoom/focus motor installed on right side	Can be balanced at
			with transmission transmitter	-	-	-	-		Can be balanced at
			with transmission transmitter and zoom/focus motor (for focus control)	-	-	-	-	Zoom/focus motor installed on right side	Can be balanced at
			with transmission transmitter and zoom/focus motor (for zoom control)	-	-	-	-	Zoom/focus motor installed on right side	Can be balanced at
Nikon			Camera and lens	\checkmark	\checkmark	√	\checkmark		Can be balanced at
NIKON			with zoom/focus motor (for focus control)	√	\checkmark	V	\checkmark	Zoom/focus motor installed on right side	
			with zoom/focus motor (for zoom control)	-	-	-	-		
	Z8	NIKKOR Z 24-70mm f/4S	with transmission transmitter	1	-	√	-		Can be balanced at
	20		with transmission transmitter and zoom/focus motor (for focus control)	√	-	V	-	Zoom/focus motor installed on right side	
			with transmission transmitter and zoom/focus motor (for zoom control)	-	-	-	-		Can be balanced at
			Camera and lens	\checkmark	\checkmark	\checkmark	\checkmark		Can be balanced at
			with zoom/focus motor (for focus control)	√	V	V	V	Zoom/focus motor installed on right side	Can be balanced at
		NIKKOR Z 35mm f/1.8S	with transmission transmitter	1	-	1	-		Can be balanced at
			with transmission transmitter and zoom/focus motor (for focus control)	1	-	1	-	Zoom/focus motor installed on right side	Can be balanced at
			Camera and lens	1	1	1	1		Can be balanced at
		-	with zoom/focus motor (for focus control)	√	√	 √	1	Zoom/focus motor installed on right side	Can be balanced at
		NIKKOR Z 50mm f/1.8S	with transmission transmitter	1	-	1	-		Can be balanced at
		1 1	with transmission transmitter and zoom/focus motor (for focus control)	1	-	√	-	Zoom/focus motor installed on right side	Can be balanced at

Installation Remark

d at any focal length; Need to remove eyepiece cap

d at any focal length; Need to remove eyepiece cap

at any focal length, no need to remove eyepiece cap

at any focal length, no need to remove eyepiece cap

ece cap slightly rubs against the camera at 24-35mm. rait: can be balanced at any focal length

iece cap slightly rubs against the camera at 24-35mm. rrait: can be balanced at any focal length

at any focal length, no need to remove eyepiece cap

at any focal length, no need to remove eyepiece cap

at any focal length, no need to remove eyepiece cap

at any focal length, no need to remove eyepiece cap

at any focal length, no need to remove eyepiece cap

at any focal length, no need to remove eyepiece cap

at any focal length, no need to remove eyepiece cap at any focal length, no need to remove eyepiece cap at any focal length, no need to remove eyepiece cap at any focal length, no need to remove eyepiece cap at any focal length, no need to remove eyepiece cap at any focal length, no need to remove eyepiece cap at any focal length, no need to remove eyepiece cap at any focal length, no need to remove eyepiece cap at any focal length, no need to remove eyepiece cap at any focal length, no need to remove eyepiece cap at any focal length, no need to remove eyepiece cap at any focal length, no need to remove eyepiece cap

				Balance A	djustment	Camera Ba	cking Base	2 Forma / Zoom Control Mater	
Camera Brand	Model	Lens Model	Mounting Status	Horizontal	Vertical	Horizontal	Vertical	Focus/Zoom Control Motor	
			Camera and lens	1	\checkmark	1	\checkmark		Can be balanced at
			with zoom/focus motor (for focus control)	-	-	-	-		
		AF-S NIKKOR 14-24mm f/2.8G ED	with zoom/focus motor (for zoom control)	-	-	-	-		
		AF-3 NIKKOR 14-2411111 1/2.86 ED	with transmission transmitter	\checkmark	\checkmark	√	\checkmark		Can be balanced at
			with transmission transmitter and	-	_	_	-		
			zoom/focus motor (for focus control) with transmission transmitter and						
			zoom/focus motor (for zoom control)		-	-	-		
			Camera and lens	\checkmark	\checkmark	1	\checkmark		Can be balanced at
			with zoom/focus motor (for focus control)	√	V	1	\checkmark	Zoom/focus motor installed on right side	Can be balanced at
			with zoom/focus motor (for zoom control)	√	-	V	-	Zoom/focus motor installed on right side	Can be balanced at
		AF-S NIKKOR 16-35mm f/4G ED VR	with transmission transmitter	1	-	1	-		Can be balanced at
			with transmission transmitter and zoom/focus motor (for focus control)	-	-	-	-		
			with transmission transmitter and zoom/focus motor (for zoom control)	-	-	_	-		
			Camera and lens	-	-	-	-		
Nikon	Z8	AF-S NIKKOR 24-70mm f/2.8E ED VR	with zoom/focus motor (for focus control)	-	-	-	-		
NIKON	20		with zoom/focus motor (for zoom control)	-	-	-	-		
			with transmission transmitter	-	-	-	-		
			with transmission transmitter and zoom/focus motor (for focus control)	-	-	-	-		
			with transmission transmitter and zoom/focus motor (for zoom control)	-	-	-	-		
			Camera and lens	-	-	-	-		
			with zoom/focus motor (for focus control)	-	-	-	-		
		AF-S NIKKOR 24-70mm f/2.8G ED	with zoom/focus motor (for zoom control)	-	-	-	-		
		AF-3 NIKKOK 24-7011111/2.80 ED	with transmission transmitter	-	-	-	-		
			with transmission transmitter and zoom/focus motor (for focus control)	-	-	-	-		
			with transmission transmitter and zoom/focus motor (for zoom control)		-	-	-		
			Camera and lens	-	-	-	-		
			with zoom/focus motor (for focus control)	-	-	-	-		
		AF-S NIKKOR 24-120mm f/4G ED VR	with zoom/focus motor (for zoom control)	-	-	-	-		
			with transmission transmitter	-	-	-	-		
			with transmission transmitter and zoom/focus motor (for focus control)	-	-	-	-		
			with transmission transmitter and zoom/focus motor (for zoom control)	-	-	-	-		

Installation Remark

at any focal length, no need to remove eyepiece cap

l at any focal length, no need to remove eyepiece cap

l at any focal length, no need to remove eyepiece cap

l at any focal length, no need to remove eyepiece cap

d at any focal length, no need to remove eyepiece cap

				Balance A	djustment	Camera Ba	cking Base	Eacus/Zoom Control Motor	
Camera Brand	Model	Lens Model	Mounting Status	Horizontal	Vertical	Horizontal	Vertical	Focus/Zoom Control Motor	
			Camera and lens	1	\checkmark	1	\checkmark		Can be balanced a
			with zoom/focus motor (for focus control)	1	\checkmark	1	\checkmark	Zoom/focus motor installed on right side	Can be balanced a
		AF-S NIKKOR 24mm f/1.4G ED	with transmission transmitter	\checkmark	-	√	-		Can be balanced a
			with transmission transmitter and zoom/focus motor (for focus control)	\checkmark	-	V	-	Zoom/focus motor installed on right side	Can be balanced a
			Camera and lens	\checkmark	\checkmark	√	\checkmark		Can be balanced a
			with zoom/focus motor (for focus control)	\checkmark	\checkmark	√	\checkmark	Zoom/focus motor installed on right side	Can be balanced a
		AF-S NIKKOR 24mm f/1.8G ED	with transmission transmitter	√	-	√	-		Can be balanced a
			with transmission transmitter and zoom/focus motor (for focus control)	1	-	V	-	Zoom/focus motor installed on right side	Can be balanced a
			Camera and lens	1	\checkmark	√	\checkmark		Can be balanced at
		AF-S NIKKOR 35mm f/1.4G	with zoom/focus motor (for focus control)	1	\checkmark	V	\checkmark	Zoom/focus motor installed on right side	Can be balanced a
			with transmission transmitter	\checkmark	-	√	-		Can be balanced a
			with transmission transmitter and zoom/focus motor (for focus control)	\checkmark	-	V	-	Zoom/focus motor installed on right side	Can be balanced a
			Camera and lens	-		-	-		
		AF-S NIKKOR 50mm f/1.4G	with zoom/focus motor (for focus control)	-	-	-	-		
Nikon	Z8		with transmission transmitter	-	-	-	-		
			with transmission transmitter and zoom/focus motor (for focus control)	-	-	-	-		
		Sigma 24-70mm f/2.8L DG	Camera and lens	-	-	-	-		
			with zoom/focus motor (for focus control)	-	-	-	-		
			with zoom/focus motor (for zoom control)	-	-	-	-		
		51gma 24-70mm1/2.0L DG	with transmission transmitter	-	-	-	-		
			with transmission transmitter and zoom/focus motor (for focus control)	-	-	-	-		
			with transmission transmitter and zoom/focus motor (for zoom control)	-	-	-	-		
			Camera and lens	\checkmark	\checkmark	√	\checkmark		Can be balanced a
		Ciana 25mm 51.4 DC	with zoom/focus motor (for focus control)	\checkmark	-	\checkmark	-	Zoom/focus motor installed on right side	Can be balanced a
		Sigma 35mm F1.4 DG	with transmission transmitter	\checkmark	-	√	-		Can be balanced at
			with transmission transmitter and zoom/focus motor (for focus control)	1	-	\checkmark	-	Zoom/focus motor installed on right side	Can be balanced at
			Camera and lens	-	-	-	-		
		Cierce FOurier F1 4 D.C.	with zoom/focus motor (for focus control)	-	-	-	-		
		Sigma 50mm F1.4 DG	with transmission transmitter	-	-	-	-		
			with transmission transmitter and zoom/focus motor (for focus control)	-	-	-	-		

Installation Remark

d at any focal length, need to remove eyepiece cap d at any focal length, need to remove eyepiece cap d at any focal length, need to remove eyepiece cap d at any focal length, need to remove eyepiece cap d at any focal length, need to remove eyepiece cap d at any focal length, need to remove eyepiece cap d at any focal length, need to remove eyepiece cap d at any focal length, need to remove eyepiece cap d at any focal length, need to remove eyepiece cap d at any focal length, need to remove eyepiece cap d at any focal length, need to remove eyepiece cap d at any focal length, need to remove eyepiece cap d at any focal length, need to remove eyepiece cap d at any focal length, need to remove eyepiece cap

at any focal length, need to remove eyepiece cap

l at any focal length, need to remove eyepiece cap

at any focal length, need to remove eyepiece cap

at any focal length, no need to remove eyepiece cap

				Balance Ad	djustment	Camera Bac	king Base	
Camera Brand	Model	Lens Model	Mounting Status	Horizontal	Vertical	Horizontal	Vertical	Focus/Zoom Control Motor
			Camera and Lens	\checkmark	-	\checkmark	-	
			with Focus/Zoom Control Motor (For Focus Control)	√	-	√	-	Focus/Zoom Control Motor installed on either side
			with Focus/Zoom Control Motor (For Zoom Control)	1	-	1	-	Focus/Zoom Control Motor installed on either side
		FE 16-35mm F2.8 GM	with transmission transmitter	√	-	√	-	
	α9、 α9 ΙΙ 、		with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	1	-	1	-	Focus/Zoom Control Motor installed on either side
	α7M2、 α7R2、 α7S2、		with transmission transmitter and Focus/Zoom Control Motor (For Zoom Control)	\checkmark	-	V	-	Focus/Zoom Control Motor installed on either side
	α7M3、 α7R3、		Camera and Lens	\checkmark	-	\checkmark	-	
	α7S3、 α7R4、 α7M4、	4、	with Focus/Zoom Control Motor (For Focus Control)	√	-	1	-	Focus/Zoom Control Motor installed on either side
	α7R5、 α7C、		with Focus/Zoom Control Motor (For Zoom Control)	\checkmark	-	\checkmark	-	Focus/Zoom Control Motor installed on either side
Sony	α7C II、 α6700、	FE 16-35mm F4 ZAISS	with transmission transmitter	\checkmark	-	\checkmark	-	
	α6600、 α6500、 α6400、		with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	1	-	1	-	Focus/Zoom Control Motor installed on either side
	α6300、 α6100、 ZV -E10、		with transmission transmitter and Focus/Zoom Control Motor (For Zoom Control)	1	-	\checkmark	-	Focus/Zoom Control Motor installed on either side
	ZV -E1、 ZV -1、		Camera and Lens	√	-	√	-	
	ILME-FX3、 FX30、		with Focus/Zoom Control Motor (For Focus Control)	1	-	1	-	Focus/Zoom Control Motor installed on either side
	ZV-1 II		with Focus/Zoom Control Motor (For Zoom Control)	1	-	1	-	Focus/Zoom Control Motor installed on either side
		FE 12-24mm F4 G	with transmission transmitter	\checkmark	-	\checkmark	-	
		v	with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	√	-	1	-	Focus/Zoom Control Motor installed on either side
			with transmission transmitter and Focus/Zoom Control Motor (For Zoom Control)	1	-	V	-	Focus/Zoom Control Motor installed on either side

Can be balanced at any focal length, no need to remove eyepiece cap

Installation Remark

				Balance A	djustment	Camera Ba	cking Base	_ /	
Camera Brand	Model	Lens Model	Mounting Status	Horizontal	Vertical	Horizontal	Vertical	Focus/Zoom Control Motor	
			Camera and Lens	1	-	1	-		No
			with Focus/Zoom Control Motor (For Focus Control)	1	-	1	-	Focus/Zoom Control Motor installed on either side	N
		FE 24mm f1.4GM	with transmission transmitter	\checkmark	-	\checkmark	-		Can be balanced at a
			with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	1	-	V	-	Focus/Zoom Control Motor installed on either side	Can be balanced at a
			Camera and Lens	1	-	1	-		
			with Focus/Zoom Control Motor (For Focus Control)	1	-	1	-	Focus/Zoom Control Motor installed on either side	
	α9、 α9 ΙΙ、	FE 24-70mm F2.8 GM	with Focus/Zoom Control Motor (For Zoom Control)	1	-	1	-	Focus/Zoom Control Motor installed on either side	
	α7M2、		with transmission transmitter	\checkmark	-	\checkmark	-		Can be balanced at
α7R2、 α7S2、 α7M3、 α7R3、 α7S3、 α7R4、	1 L 24-1011111 L 2.0 GM	with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	1	-	V	-	Focus/Zoom Control Motor installed on either side	(Roll a	
			with transmission transmitter and Focus/Zoom Control Motor (For Zoom Control)	1	-	V	-	Focus/Zoom Control Motor installed on either side	
		α7M4、 α7R5、 α7C、 α7C ΙΙ、 α6700、	Camera and Lens	1	-	1	-		Can be balanced
			with Focus/Zoom Control Motor (For Focus Control)	1	-	1	-	Focus/Zoom Control Motor installed on either side	Can be balanced
Sony			with Focus/Zoom Control Motor (For Zoom Control)	1	-	1	-	Focus/Zoom Control Motor installed on either side	Can be balanced
	α6600、	FE 24–70mm F4 ZA OSS	with transmission transmitter	1	-	1	-		Can be balanced
	α6500、 α6400、 α6300、	500、 400、 300、 100、 E10、	with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	1	-	V	-	Focus/Zoom Control Motor installed on either side	Can be balanced a
	α6100、 ZV -E10、 ZV -E1、		with transmission transmitter and Focus/Zoom Control Motor (For Zoom Control)	\checkmark	-	\checkmark	-	Focus/Zoom Control Motor installed on either side	Can be balanced
	ZV -1、		Camera and Lens	\checkmark	-	\checkmark	-		N
	ILME-FX3、 FX30、		with Focus/Zoom Control Motor (For Focus Control)	1	-	√	-	Focus/Zoom Control Motor installed on either side	No
	ZV-1 II	FE 28mm F2	with transmission transmitter	1	-	√	-		N
			with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	1	-	V	-	Focus/Zoom Control Motor installed on either side	Ne
			Camera and Lens	1	-	√	-		N
			with Focus/Zoom Control Motor (For Focus Control)	1	-	1	-	Focus/Zoom Control Motor installed on either side	Ν
		FE 50mm F1.8	with transmission transmitter	1	-	1	-		N
		with	with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	1	-	V	-	Focus/Zoom Control Motor installed on either side	N

Installation Remark

No need to remove eyepiece cap

No need to remove eyepiece cap

at any focal length, no need to remove eyepiece cap

at any focal length, no need to remove eyepiece cap

l at any focal length; Need to remove eyepiece cap ll axis slightly rub against the camera)

ed at 24mm-50mm, need to remove eyepiece cap

No need to remove eyepiece cap

Comore Drand	Madal	Long Madel	Mounting Status	Balance A	djustment	Camera Ba	cking Base	Forme/Zoom Control Motor	Installation Domonic
Camera Brand	Model	Lens Model	Mounting Status	Horizontal	Vertical	Horizontal	Vertical	Focus/Zoom Control Motor	Installation Remark
			Camera and Lens	\checkmark	-	√	-		No need to remove eyepiece cap
			with Focus/Zoom Control Motor (For Focus Control)	\checkmark	-	V	-	Focus/Zoom Control Motor installed on either side	No need to remove eyepiece cap
		FE 85mm F1.4 GM	with transmission transmitter	\checkmark	-	√	-		No need to remove eyepiece cap
			with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	V	-	√	-	Focus/Zoom Control Motor installed on either side	No need to remove eyepiece cap
			Camera and Lens	\checkmark	-	√	-		No need to remove eyepiece cap
	α9、 α9 ΙΙ、		with Focus/Zoom Control Motor (For Focus Control)	\checkmark	-	√	-	Focus/Zoom Control Motor installed on left side	No need to remove eyepiece cap
	α7M2、 α7R2、	Distagon T* FE 35mm F1.4 ZA	with transmission transmitter	\checkmark	-	√	-		No need to remove eyepiece cap
	α7S2、 α7M3、		with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	V	-	V	-	Focus/Zoom Control Motor installed on left side	No need to remove eyepiece cap
	α7R3、 α7S3、		Camera and Lens	\checkmark	-	√	-		No need to remove eyepiece cap
	α7R4、 α7M4、		with Focus/Zoom Control Motor (For Focus Control)	\checkmark	-	V	-	Focus/Zoom Control Motor installed on right side	No need to remove eyepiece cap
	α7R5、	5. Sonnar T* FE 35mm F2.8 ZA	with transmission transmitter	\checkmark	-	√	-		No need to remove eyepiece cap
Sony	α7C、 α7C ΙΙ、 α6700、		with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	V	-	V	-	Focus/Zoom Control Motor installed on right side	No need to remove eyepiece cap
	α6600、		Camera and Lens	\checkmark	-	√	-		No need to remove eyepiece cap
	α6500、 α6400、		with Focus/Zoom Control Motor (For Focus Control)	V	-	V	-	Focus/Zoom Control Motor installed on either side	No need to remove eyepiece cap
	α6300、	Sonnar [®] T* FE 55mm F1.8 ZA	with transmission transmitter	\checkmark	-	√	-		No need to remove eyepiece cap
	α6100、 ZV -E10、 ZV -E1、		with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	\checkmark	-	V	-	Focus/Zoom Control Motor installed on either side	No need to remove eyepiece cap
	ZV -1、		Camera and Lens	\checkmark	-	√	-		Can be balanced at any focal length, no need to remove eyepiece cap
	ILME-FX3、 FX30、		with Focus/Zoom Control Motor (For Focus Control)	\checkmark	-	1	-	Focus/Zoom Control Motor installed on either side	Can be balanced at any focal length, no need to remove eyepiece cap
	ZV-1 II		with Focus/Zoom Control Motor (For Zoom Control)	\checkmark	-	1	-	Focus/Zoom Control Motor installed on either side	Can be balanced at any focal length, no need to remove eyepiece cap
		E 10–18mm F4 OSS	with transmission transmitter	\checkmark	-	1	-		Can be balanced at any focal length, no need to remove eyepiece cap
			with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	V	-	√	-	Focus/Zoom Control Motor installed on either side	Can be balanced at any focal length, no need to remove eyepiece cap
			with transmission transmitter and Focus/Zoom Control Motor (For Zoom Control)	V	-	√	-	Focus/Zoom Control Motor installed on either side	Can be balanced at any focal length, no need to remove eyepiece cap

				Balance A	djustment	Camera Ba	cking Base		
Camera Brand	Model	Lens Model	Mounting Status	Horizontal	Vertical	Horizontal	Vertical	Focus/Zoom Control Motor	
			Camera and Lens	√	-	√	-		Can be balanced at
			with Focus/Zoom Control Motor (For Focus Control)	1	-	V	-	Focus/Zoom Control Motor installed on either side	Can be balanced at
			with Focus/Zoom Control Motor (For Zoom Control)	1	-	V	-	Focus/Zoom Control Motor installed on either side	Can be balanced at
		E PZ 18–105mm F4 G OSS	with transmission transmitter	\checkmark	-	√	-		Can be balanced at
	α9、 α9 ΙΙ、		with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	1	-	√	-	Focus/Zoom Control Motor installed on either side	Can be balanced at
	α7M2、 α7R2、 α7S2、		with transmission transmitter and Focus/Zoom Control Motor (For Zoom Control)	J	-	√	-	Focus/Zoom Control Motor installed on either side	Can be balanced at
	α7M3、		Camera and Lens	√	-	√	-		Can be balanced at
	α7R3、 α7S3、		with Focus/Zoom Control Motor (For Focus Control)	1	-	1	-	Focus/Zoom Control Motor installed on left side	Can be balanced at
	α7R4、 α7M4、		with Focus/Zoom Control Motor (For Zoom Control)	1	-	V	-	Focus/Zoom Control Motor installed on left side	Can be balanced at
	α7R5、 α7C、	E 18–200mm F3.5–6.3 OSS LE	with transmission transmitter	\checkmark	-	√	-		Can be balanced at
Sony	α7C ΙΙ、 α6700、 α6600、 α6500、 α6400、		with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	1	-	√	-	Focus/Zoom Control Motor installed on either side	Can be balanced at
			with transmission transmitter and Focus/Zoom Control Motor (For Zoom Control)	√	-	√	-	Focus/Zoom Control Motor installed on either side	Can be balanced at
	α6300、		Camera and Lens	√	-	√	-		Ν
	α6100、 ZV -E10、 ZV -E1、		with Focus/Zoom Control Motor (For Focus Control)	1	-	V	-	Focus/Zoom Control Motor installed on either side	Ν
	ZV -E1、 ZV -1、	Sigma 30mm f/1.4 DC DN	with transmission transmitter	1	-	1	-		Can be balanced at
	ILME-FX3、 FX30、 ZV-1 II	(3,	with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	1	-	V	-	Focus/Zoom Control Motor installed on either side	Can be balanced at
			Camera and Lens	1	-	1	-		N
		Sigma 50mm f/1.4 DG	with Focus/Zoom Control Motor (For Focus Control)	1	-	V	-	Focus/Zoom Control Motor installed on left side	Ν
			with transmission transmitter	\checkmark	-	√	-		Can be balanced at
			with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	J	-	√	-	Focus/Zoom Control Motor installed on either side	Can be balanced at

Installation Remark

at any focal length, no need to remove eyepiece cap at any focal length, no need to remove eyepiece cap at any focal length, no need to remove eyepiece cap at any focal length, no need to remove eyepiece cap at any focal length, no need to remove eyepiece cap at any focal length, no need to remove eyepiece cap at any focal length, no need to remove eyepiece cap at any focal length, no need to remove eyepiece cap at any focal length, no need to remove eyepiece cap at any focal length, no need to remove eyepiece cap at any focal length, no need to remove eyepiece cap at any focal length, no need to remove eyepiece cap at any focal length, no need to remove eyepiece cap at any focal length, no need to remove eyepiece cap

at any focal length, no need to remove eyepiece cap

No need to remove eyepiece cap

No need to remove eyepiece cap

at any focal length, no need to remove eyepiece cap

at any focal length, no need to remove eyepiece cap

No need to remove eyepiece cap

No need to remove eyepiece cap

at any focal length, no need to remove eyepiece cap

6	Madul		Manuti et l	Balance A	djustment	Camera Ba	cking Base	F	
Camera Brand	Model	Lens Model	Mounting Status	Horizontal	Vertical	Horizontal	Vertical	Focus/Zoom Control Motor	
	α9、		Camera and Lens	1	-	√	-		
	α9 ΙΙ、 α7Μ2、		with Focus/Zoom Control Motor (For Focus Control)	1	-	V	-	Focus/Zoom Control Motor installed on left side	
	α7R2、 α7S2、		with Focus/Zoom Control Motor (For Zoom Control)	1	-	1	-	Focus/Zoom Control Motor installed on left side	
	α7Μ3、	Tamron 28-75mm f/2.8	with transmission transmitter	1	-	√	-		Can be balanced at a
α7R3、 α7S3、 α7R4、 α7M4、 α7R5、 α7C、	α7S3、 α7R4、		with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	1	-	V	-	Focus/Zoom Control Motor installed on either side	
	α7R5、 α7C、		with transmission transmitter and Focus/Zoom Control Motor (For Zoom Control)	V	-	V	-	Focus/Zoom Control Motor installed on either side	
Sony	α7C II、		Camera and Lens	1	-	√	-		Can be balanced at a
	α6700、 α6600、 α6500、		with Focus/Zoom Control Motor (For Focus Control)	-	-	-	-		
	α6400、 α6300、		with Focus/Zoom Control Motor (For Zoom Control)	-	-	-	-		
	α6100、	sigma18-35mm f/1.8 DC HSM Art	with transmission transmitter	-	-	-	-		
	ZV -E10、 ZV -E1、	ZV -E10、 (+Canon adapter) ZV -E1、	with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	-	-	-	-		
	ILME-FX3、 FX30、 ZV-1 II		with transmission transmitter and Focus/Zoom Control Motor (For Zoom Control)	-	_	-	-		
			Camera and Lens	1	-	√	-		
	Х-Н1、		with Focus/Zoom Control Motor (For Focus Control)	1	-	V	-	Focus/Zoom Control Motor installed on either side	
	Х-Т2、 Х-Т3、		with Focus/Zoom Control Motor (For Zoom Control)	1	-	1	-	Focus/Zoom Control Motor installed on either side	
FUJIFILM	X-T4、 X T5	XF 16-55mm f/2.8 R LM WR	with transmission transmitter	√	-	√	-		Can be balanced at a
	X-T5、 X-T30、 X-H2S、		with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	\checkmark	-	\checkmark	-	Focus/Zoom Control Motor installed on either side	
	X-S20	-	with transmission transmitter and Focus/Zoom Control Motor (For Zoom Control)	1	-	√	-	Focus/Zoom Control Motor installed on either side	

at any focal length, no need to remove eyepiece cap

at any focal length, no need to remove eyepiece cap

				Balance A	djustment	Camera Ba	cking Base		
Camera Brand	Model	Lens Model	Mounting Status	Horizontal	Vertical	Horizontal	Vertical	Focus/Zoom Control Motor	
			Camera and Lens	1	-	√	-		
			with Focus/Zoom Control Motor (For Focus Control)	√	-	√	-	Focus/Zoom Control Motor installed on either side	
			with Focus/Zoom Control Motor (For Zoom Control)	1	-	√	-	Focus/Zoom Control Motor installed on either side	
		XF 18-55mm f/2.8-4 R OIS	with transmission transmitter	\checkmark	-	√	-		
			with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	1	-	√	-	Focus/Zoom Control Motor installed on either side	
			with transmission transmitter and Focus/Zoom Control Motor (For Zoom Control)	V	-	√	-	Focus/Zoom Control Motor installed on either side	
			Camera and Lens	\checkmark	-	√	-		
			with Focus/Zoom Control Motor (For Focus Control)	1	-	√	-	Focus/Zoom Control Motor installed on either side	
	X-H1、 X-T2、		with Focus/Zoom Control Motor (For Zoom Control)	√	-	√	-	Focus/Zoom Control Motor installed on either side	
	Х-ТЗ,	XF 18-135mm f/3.5-5.6 R LM OIS WR	with transmission transmitter	\checkmark	-	√	-		
FUJIFILM	X-T4、 X-T5、 X-T30、		with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	\checkmark	-	√	-	Focus/Zoom Control Motor installed on either side	
	X-H2S、 X-S20		with transmission transmitter and Focus/Zoom Control Motor (For Zoom Control)	V	-	√	-	Focus/Zoom Control Motor installed on either side	
			Camera and Lens	\checkmark	-	√	-		
			with Focus/Zoom Control Motor (For Focus Control)	1	-	1	-	Focus/Zoom Control Motor installed on either side	
		XF 35mm f/2 R WR	with transmission transmitter	\checkmark	-	√	-		
			with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	V	-	√	-	Focus/Zoom Control Motor installed on either side	
			Camera and Lens	1	-	√	-		
			with Focus/Zoom Control Motor (For Focus Control)	1	-	1	-	Focus/Zoom Control Motor installed on either side	
		XF 56mm f/1.2 R	with transmission transmitter	\checkmark	-	√	-		
			with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	V	-	1	-	Focus/Zoom Control Motor installed on either side	

Can be balanced at any focal length, no need to remove eyepiece cap

Installation Remark

WEEBILL 3 Camera Compatibility List

				Balance A	djustment	Camera Ba	cking Base		
Camera Brand	Model	Lens Model	Mounting Status	Horizontal	Vertical	Horizontal	Vertical	Focus/Zoom Control Motor	
			Camera and Lens	1	-	√	-		
			with Focus/Zoom Control Motor (For Focus Control)	√	-	1	-	Focus/Zoom Control Motor installed on either side	
			with Focus/Zoom Control Motor (For Zoom Control)	√	-	V	-	Focus/Zoom Control Motor installed on either side	
	Х-Н1、	XC 15-45mm f/3.5-5.6 OIS	with transmission transmitter	\checkmark	-	√	-		
	X-T2、 X-T3、		with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	√	-	√	-	Focus/Zoom Control Motor installed on either side	
FUJIFILM X-T4, X-T5, X-T30, X-H2S, X-S20	Х-Т5、 Х-Т30、		with transmission transmitter and Focus/Zoom Control Motor (For Zoom Control)	\checkmark	-	√	-	Focus/Zoom Control Motor installed on either side	Can be balanced a
	Х-520	Super EBC XF 23mm f/1.4 R	Camera and Lens	\checkmark	-	√	-		
			with Focus/Zoom Control Motor (For Focus Control)	√	-	√	-	Focus/Zoom Control Motor installed on either side	
			with transmission transmitter	\checkmark	-	√	-		
			with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	1	-	V	-	Focus/Zoom Control Motor installed on either side	
					x				
			Camera and Lens	√	-	√	-		
			with Focus/Zoom Control Motor (For Focus Control)	√	-	V	-	Focus/Zoom Control Motor installed on either side	
			with Focus/Zoom Control Motor (For Zoom Control)	√	-	√	-	Focus/Zoom Control Motor installed on either side	
Panasonic	G9、GH5s、GH5、	Vario-Elmarit 8-18mm f/2.8-4.0	with transmission transmitter	\checkmark	-	√	-		Can be balanced at
	GH6		with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	\checkmark	-	√	-	Focus/Zoom Control Motor installed on either side	
			with transmission transmitter and Focus/Zoom Control Motor (For Zoom Control)	1	-	V	-	Focus/Zoom Control Motor installed on either side	

ZHIYUN

Installation Remark

d at any focal length, no need to remove eyepiece cap

				Balance A	djustment	Camera Ba	cking Base		
Camera Brand	Model	Lens Model	Mounting Status	Horizontal	Vertical	Horizontal	Vertical	Focus/Zoom Control Motor	
			Camera and Lens	1	-	1	-		
			with Focus/Zoom Control Motor (For Focus Control)	1	-	1	-	Focus/Zoom Control Motor installed on either side	
			with Focus/Zoom Control Motor (For Zoom Control)	V	-	V	-	Focus/Zoom Control Motor installed on either side	
		Vario 12-35mm f/2.8 II	with transmission transmitter	1	-	√	-		
			with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	V	-	V	-	Focus/Zoom Control Motor installed on either side	
			with transmission transmitter and Focus/Zoom Control Motor (For Zoom Control)	1	-	V	-	Focus/Zoom Control Motor installed on either side	
			Camera and Lens	√	-	√	-		
			with Focus/Zoom Control Motor (For Focus Control)	1	-	1	-	Focus/Zoom Control Motor installed on either side	
		Lumix G 25mm f/1.7	with transmission transmitter	√	-	√	-		
	G9、GH5s、GH5、		with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	1	-	√	-	Focus/Zoom Control Motor installed on either side	
Panasonic	GH6		Camera and Lens	1	-	1	-		Can be balanced a
		MACRO 30mm f/2.8	with Focus/Zoom Control Motor (For Focus Control)	√	-	√	-	Focus/Zoom Control Motor installed on either side	
			with transmission transmitter	1	-	\checkmark	-		
			with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	√	-	√	-	Focus/Zoom Control Motor installed on either side	
			Camera and Lens	√	-	√	-		
			with Focus/Zoom Control Motor (For Focus Control)	-	-	-	-		
			with Focus/Zoom Control Motor (For Zoom Control)	-	-	-	-		
		sigma 18-35mm f/1.8 DC HSM Art (+adapter)	with transmission transmitter	-	-	-	-		
			with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	-	-	-	-		
			with transmission transmitter and Focus/Zoom Control Motor (For Zoom Control)	-	-	-	-		

Installation Remark

d at any focal length, no need to remove eyepiece cap

Need to remove eyepiece cap

				Balance A	djustment	Camera Ba	cking Base		
Camera Brand	Model	Lens Model	Mounting Status	Horizontal	Vertical	Horizontal	Vertical	Focus/Zoom Control Motor	
			Camera and Lens	1	-	1	-		
			with Focus/Zoom Control Motor (For Focus Control)	√	-	1	-	Focus/Zoom Control Motor installed on either side	
			with Focus/Zoom Control Motor (For Zoom Control)	√	-	1	-	Focus/Zoom Control Motor installed on either side	
		LUMIX S 24-105mm F/4 Macro OIS	with transmission transmitter	1	-	1	-		
			with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	1	-	V	-	Focus/Zoom Control Motor installed on either side	
	S5		with transmission transmitter and Focus/Zoom Control Motor (For Zoom Control)	√	-	√	-	Focus/Zoom Control Motor installed on either side	Can be balanced
	55		Camera and Lens	√	-	\checkmark	-		can be balanced
			with Focus/Zoom Control Motor (For Focus Control)	√	-	√	-	Focus/Zoom Control Motor installed on either side	
			with Focus/Zoom Control Motor (For Zoom Control)	√	-	√	-	Focus/Zoom Control Motor installed on either side	
		LUMIX S PRO 24-70mm f/2.8	with transmission transmitter	√	-	√	-		
Panasonic			with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	√	-	V	-	Focus/Zoom Control Motor installed on either side	
			with transmission transmitter and Focus/Zoom Control Motor (For Zoom Control)	1	-	V	-	Focus/Zoom Control Motor installed on either side	
			Camera and Lens	-	-	-	-		
			with Focus/Zoom Control Motor (For Focus Control)	-	-	-	-		
			with Focus/Zoom Control Motor (For Zoom Control)	-	-	-	-		
	S1、S1H	LUMIX S 24-105mm F/4 Macro OIS	with transmission transmitter	-	-	-	-		
		LUMIX S 24-10511111 F/4 Macro OIS	with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	-	-	-	-		
			with transmission transmitter and Focus/Zoom Control Motor (For Zoom Control)	-	-	-	-		

Installation Remark

		Leve Medel	Mauntine Status	Balance A	djustment	Camera Ba	cking Base	
Camera Brand	Model	Lens Model	Mounting Status	Horizontal	Vertical	Horizontal	Vertical	Focus/Zoom Control Motor
			Camera and Lens	-	-	-	-	
			with Focus/Zoom Control Motor (For Focus Control)	-	-	-	-	
			with Focus/Zoom Control Motor (For Zoom Control)	-	-	-	-	
		Vario-Elmarit 8-18mm f/2.8-4.0	with transmission transmitter	-	-	-	-	
			with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	-	-	-	-	
			with transmission transmitter and Focus/Zoom Control Motor (For Zoom Control)	-	-	-	-	
			Camera and Lens	-	-	-	-	
			with Focus/Zoom Control Motor (For Focus Control)	-	-	-	-	
		Vario 12-35mm f/2.8 II	with Focus/Zoom Control Motor (For Zoom Control)	-	-	-	-	
			with transmission transmitter	-	-	-	-	
BMD	ВМРСС 4К		with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	-	-	-	-	
			with transmission transmitter and Focus/Zoom Control Motor (For Zoom Control)	-	-	-	-	
		G Vario 12-32mm 0.2m/0.66ft	Camera and Lens	-	-	-	-	
			with Focus/Zoom Control Motor (For Zoom Control)	-	-	-	-	
			with transmission transmitter	-	-	-	-	
			with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	-	-	-	-	
			with transmission transmitter and Focus/Zoom Control Motor (For Zoom Control)	-	-	-	-	
			Camera and Lens	-	-	-	-	
		25mm f/1.7	with Focus/Zoom Control Motor (For Focus Control)	-	-	-	-	
			with transmission transmitter	-	-	-	-	
			with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	-	-	-	-	

Installation Remark

			Maunting Status	Balance Ad	djustment	Camera Ba	cking Base		
Camera Brand	Model	Lens Model	Mounting Status	Horizontal	Vertical	Horizontal	Vertical	Focus/Zoom Control Motor	
			Camera and Lens	-	-	-	-		
			with Focus/Zoom Control Motor (For Focus Control)	-	-	-	-		
		MACRO 30mm f/2.8	with transmission transmitter	-	-	-	-		
BMD	BMPCC 4K		with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	-	-	-	-		
ВМО	BMPCC 4K		Camera and Lens	-	-	-	-		
			with Focus/Zoom Control Motor (For Focus Control)	-	-	-	-		
		D-Dreamer 12mm F2.8	with transmission transmitter	-	-	-	-		
			with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	-	-	-	-		
			Camera and Lens	-	-	-	-		
		EF 24mm f/1.4L II USM	with Focus/Zoom Control Motor (For Focus Control)	-		-	-		
			with transmission transmitter	-	-	-	-		
			with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	-	-	-	-		
			Camera and Lens	-	-	-	-		
		EF 35mm f/1.4L II USM	with Focus/Zoom Control Motor (For Focus Control)	-	-	-	-		
			with transmission transmitter	-	-	-	-		
BMD			with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	_	-	-	-		
BMD	BMPCC 6K		Camera and Lens	-	-	-	-		
			with Focus/Zoom Control Motor (For Focus Control)	-	-	-	-		
		EF 50mm f/1.4L USM	with transmission transmitter	-	-	-	-		
			with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	-	-	-	-		
			Camera and Lens	-	-	-	-		
		EF 85mm f/1.8L USM	with Focus/Zoom Control Motor (For Focus Control)	-	-	-	-		
			with transmission transmitter	-	-	-	-		
			with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	-	-	-	-		

Installation Remark

Comoro Drond	Madal	Lens Model	Mounting Status	Balance A	djustment	Camera Bao	cking Base	Forma / Zooma Constant Mater	Installation Remark
Camera Brand	Model		Mounting Status	Horizontal	Vertical	Horizontal	Vertical	Focus/Zoom Control Motor	Installation Remark
			Camera and Lens	\checkmark	-	\checkmark	-		
			with Focus/Zoom Control Motor (For Focus Control)	1	-	√	-		
			with Focus/Zoom Control Motor (For Zoom Control)	\checkmark	-	√	-		
ZCAM	E2	LUMIX G X Vario 12-35mm f/2.8 II	with transmission transmitter	\checkmark	-	\checkmark	-		
		ASPH POWER OIS	with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	V	-	√	-		
			with transmission transmitter and Focus/Zoom Control Motor (For Zoom Control)	V	-	√	-		
			Camera and Lens	1	-	√	-		
			with Focus/Zoom Control Motor (For Focus Control)	\checkmark	-	√	-	Focus/Zoom Control Motor installed on either side	
SIGMA	fp	45mm F2.8	with transmission transmitter	\checkmark	-	\checkmark	-		
			with transmission transmitter and Focus/Zoom Control Motor (For Focus Control)	√	-	\checkmark	-	Focus/Zoom Control Motor installed on either side	