WEEBILL 2 Camera Compatibility List

Update Time: March 11th, 2022 (the corresponding stabilizer firmware version is V1.84)

Camera		Photo		Video	Live	Shutter Adjus		Aper Adjus		ISO Adj	ustment	EV Adju	istment	Electronic	Halfway Press	Electronic Follow	HDMI	Camera Control Cable	Camera	
Model	Save	Playback	Save	Playback	Preview	Photo Mode	Video Mode	Photo Mode	Video Mode	Photo Mode	Video Mode	Photo Mode	Video Mode	Zoom	Shutter Button to Autofocus	Focus (Focus Wheel)	Cable Type	Туре	Firmware Version	Note
Sony a1	7	J	J	J	-	V	V	\checkmark	\checkmark	\checkmark	V	-	-	-	J	\checkmark	-	Type-C to Multi USB / Type-C to Type-C USB	V1.10	 Please select "PC Remote" for your camera's "USB Connection". If using electronic focusing, set the "zoom setting" into "on: Digital zoom" in the menu and set the photo format into "JPEG". For Sony cameras, after connecting stabilizer and camera with control cable, power on the stabilizer and then the camera. Make sure the camera is fully charged. Optical zoom control is available on the stabilizer when used with motorized lens. Digital zoom control is available on the stabilizer when used with non- motorized lens. Please select zoom option in your camera's settings. Please use Type-C to Type-C USB camera control cable if you need to supply power to the camera.
Sony a9 II	V	J	V	V	-	J	J	J	V	V	Y	_	-	-	J	J	-	Type-C to Multi USB	V2.00	 Please select "PC Remote" for your camera's "USB Connection". If using electronic focusing, set the "zoom setting" into "on: Digital zoom" in the menu and set the photo format into "JPEG". For Sony cameras, after connecting stabilizer and camera with control cable, power on the stabilizer and then the camera. Make sure the camera is fully charged. Optical zoom control is available on the stabilizer when used with motorized lens. Digital zoom control is available on the stabilizer when used with non- motorized lens. Please select zoom option in your camera's settings.



V1.10

Camera		Photo	,	Video	Live	Shutter Adjus		Aper Adjus		ISO Adj	ustment	EV Adju	stment	Electronic	Halfway Press	Electronic Follow	HDMI	Camera Control Cable	Camera	
Model	Save	Playback	Save	Playback	Preview	Photo Mode	Video Mode	Photo Mode	Video Mode	Photo Mode	Video Mode	Photo Mode	Video Mode	Zoom	Shutter Button to Autofocus	Focus (Focus Wheel)	Cable Type	Туре	Firmware Version	Note
Sony α9	V	J	V	J	-	Ŷ	V	V	Ŷ	V	V	-	-	-	V	V	-	Type-C to Multi USB	V6.00	 Please select "PC Remote" for your camera's "USB Connection". For Sony cameras, after connecting stabilizer and camera with control cable, power on the stabilizer and then the camera. Make sure the camera is fully charged. When shooting Panorama or Timelapse, it is recommended to turn off the Sony camera's auto review. To trigger electronic focus, please set "Manual Focus (MF)" under "focus mode".
Sony a7R4	1	V	V	V	-	V	V	V	V	V	V	-	-	-	V	V	-	Type-C to Multi USB	V1.20	
Sony ILME-FX3	~	J	V	V	-	V	V	V	V	V	V	-	-	-	V	V	-	Type-C to Multi USB	V1.00	 Please select "PC Remote" for your camera's "USB Connection". For Sony cameras, after connecting stabilizer and camera with control cable, power on the stabilizer and
Sony a7R3	√	V	V	V	-	-	-	-	-	-	-	-	-	-	V	-	-	Type-C to Multi USB	V3.01	then the camera. Make sure the camera is fully charged.3. When shooting Panorama or Timelapse, it is recommended to turn off the Sony camera's auto review.
Sony a7M3	1	V	V	\checkmark	-	-	-	-	-	-	-	-	-	-	V	-	-	Type-C to Multi USB	V3.10	

Camera	F	Photo	V	/ideo	Live	Shutter Adjus		Aper Adjus	rture tment	ISO Adj	ustment	EV Adju	istment	Electronic	Halfway Press	Electronic Follow	HDMI	Camera Control Cable	Camera	
Model	Save	Playback	Save	Playback	Preview	Photo Mode	Video Mode	Photo Mode	Video Mode	Photo Mode	Video Mode	Photo Mode	Video Mode	Zoom	Shutter Button to Autofocus	Focus (Focus Wheel)	Cable Type	Туре	Firmware Version	Note
Sony a7S3	J	V	J	V	-	Ŷ	J	J	V	V	V	-	-	-	J	V	-	Type-C to Multi USB / Type-C to Type-C USB	V1.01	 Please select "PC Remote" for your camera's "USB Connection". (To open a7s3 PC remote control, go to "Menu" and do the following selection : "Network" - "Transfer / Remote" - "PC remote control" - "Open") For Sony cameras, after connecting stabilizer and camera with control cable, power on the stabilizer and then the camera. Make sure the camera is fully charged. When shooting Panorama or Timelapse, it is recommended to turn off the Sony camera's auto review. To trigger electronic focus, please set "Manual Focus (MF)" under "focus mode". Please use Type-C to Type-C USB camera control cable if you need to supply power to the camera.
Sony a7M4	V	J	J	V	-	-	-	-	-	-	-	-	-	-	J	-		Type-C to Multi USB / Type-C to Type-C USB (Only for charging, not for controlling)	v1.0	 Please select "PC Remote" for your camera's "USB Connection". For Sony cameras, after connecting the gimbal and camera with the control cable, Please first power on the gimbal and then the camera. Make sure the camera has sufficient power to operate. When shooting panorama or timelapse, it's recommended to turn off auto review in the Sony camera. To charge the camera, please use a Type-C to Type-C camera control cable.
Sony a7R2	V	7	J	J	-	-	-	-	-	-	-	-	-	-	J	-	_	Type-C to Multi USB	V4.01	 Please select "PC Remote" for your camera's "USB Connection". For Sony cameras, after connecting stabilizer and camera with control cable, power on the stabilizer and then the camera. Make sure the camera is fully charged. When shooting Panorama or Timelapse, it is recommended to turn off the Sony camera's auto review.

Camera	F	Photo	V	/ideo	Live	Shutter Adjust		Aper Adjus		ISO Adj	ustment	EV Adju	istment	Electronic	Halfway Press	Electronic Follow	HDMI	Camera Control Cable	Camera	
Model	Save	Playback	Save	Playback	Preview	Photo Mode	Video Mode	Photo Mode	Video Mode	Photo Mode	Video Mode	Photo Mode	Video Mode	Zoom	Shutter Button to Autofocus	Focus (Focus Wheel)	Cable Type	Туре	Firmware Version	Note
Sony a7M2	Ŷ	J	ſ	J	-	-	-	-	-	-	-	-	-	-	J	-	-	Type-C to Multi USB	V4.00	 Please select "PC Remote" for your camera's "USB Connection". If using electronic focusing, set the "zoom setting" into "on: Digital zoom" in the menu and set the photo format into "JPEG". For Sony cameras, after connecting stabilizer and camera with control cable, power on the stabilizer and then the camera. Make sure the camera is fully charged. Optical
Sony a7S2	V	J	J	J	-	-	-	-	-	-	-	-	-	-	J	-	-	Type-C to Multi USB	V3.01	 zoom control is available on the stabilizer when used with motorized lens. Digital zoom control is available on the stabilizer when used with non-motorized lens. Please select zoom option in your camera's settings. 4. When shooting Panorama or Timelapse, it is recommended to turn off the Sony camera's auto review.
Sony a7C	V	J	J	J	-	V	J	V	V	V	V	-	-	-	J	J	-	Type-C to Type-C USB	V1.00	 Please select "PC Remote" for your camera's "USB Connection". For Sony cameras, after connecting stabilizer and camera with control cable, power on the stabilizer and then the camera. Make sure the camera is fully charged. When shooting Panorama or Timelapse, it is recommended to turn off the Sony camera's auto review. To trigger electronic focus, please set "Manual Focus (MF)" under "focus mode".

Camera	F	Photo	\ \	/ideo	Live	Shutter Adjus		Ape Adjus		ISO Adj	ustment	EV Adju	stment	Electronic	Halfway Press	Electronic Follow	HDMI	Camera Control Cable	Camera	
Model	Save	Playback	Save	Playback	Preview	Photo Mode	Video Mode	Photo Mode	Video Mode	Photo Mode	Video Mode	Photo Mode	Video Mode	Zoom	Shutter Button to Autofocus	Focus (Focus Wheel)	Cable Type	Туре	Firmware Version	Note
Sony a6600	1	√	V	V	-	-	-	-	-	-	-	-	-	-	\checkmark	-	-	Type-C to Multi USB	V1.10	
Sony a6500	1	V	V	V	-	-	-	-	-	-	-	-	-	-	V	-	-	Type-C to Multi USB	V1.06	 Please select "PC Remote" for your camera's "USB Connection". For Sony cameras, after connecting stabilizer and camera with control
Sony a6400	V	√	V	V	-	-	-	-	-	-	-	-	-	-	V	-	-	Type-C to Multi USB	V2.00	cable, power on the stabilizer and then the camera. Make sure the camera is fully charged.
Sony a6300	1	V	V	V	-	-	-	-	-	-	-	-	-	-	V	-	-	Type-C to Multi USB	V2.01	3. When shooting Panorama or Timelapse, it is recommended to turn off the Sony camera's auto review.
Sony a6100	V	V	V	V	-	-	-	-	-	-	-	-	-	-	V	-	-	Type-C to Multi USB	V1.00	
Panasonic G9	1	1	\checkmark	\checkmark	-	\checkmark	\checkmark	V	V	\checkmark	\checkmark	-	-	-	V	-	-	Type-C to Micro USB	V2.1	1. Please select "PC (Tether)" for your
Panasonic GH5	1	1	1	\checkmark	-	\checkmark	\checkmark	\checkmark	V	\checkmark	\checkmark	-	-	-	1	1	-	Type-C to Type-C USB	V2.6	camera's "USB Connection". 2. When using electronic focusing, the camera lens should be in "MF"
Panasonic GH5S	1	1	1	\checkmark	-	\checkmark	\checkmark	\checkmark	V	V	\checkmark	-	-	-	\checkmark	1	-	Type-C to Type-C USB	V1.3	mode. 3. Before connecting with a control
Panasonic S1	1	1	1	\checkmark	-	\checkmark	\checkmark	\checkmark	V	V	\checkmark	-	-	-	1	1	-	Type-C to Type-C USB	V1.2	cable, please first turn off the USB Power Supply in camera settings. 4. When shooting Panorama or
Panasonic S5	1	1	1	1	-	\checkmark	1	V	V	V	1	-	-	-	1	1	-	Type-C to Type-C USB	V1.0	Timelapse, it is recommended to turn off auto review and duration time(photo) in the Panasonic
Panasonic S1H	1	1	1	1	-	\checkmark	\checkmark	\checkmark	V	V	\checkmark	-	-	-	1	1	-	Type-C to Type-C USB	V0.53	camera.
Panasonic DC-BGH1	-	-	V	V	-	-	V	-	-	-	\checkmark	-	-	-	-	V	-	Type-C to Type-C USB	V1.0	In the camera IN/OUT setting, please choose PC (Tether) for the USB mode.

Camera	F	Photo	١	/ideo	Live	Shutter Adjust		Aper Adjust		ISO Adj	ustment	EV Adju	stment	Electronic	Halfway Press	Electronic Follow	HDMI	Camera Control Cable	Camera	
Model	Save	Playback	Save	Playback	Preview	Photo Mode	Video Mode	Photo Mode	Video Mode	Photo Mode	Video Mode	Photo Mode	Video Mode	Zoom	Shutter Button to Autofocus	Focus (Focus Wheel)	Cable Type	Туре	Firmware Version	Note
Canon 5D Mark III	1	J	J	J	V	V	J	V	V	J	J	-	_	_	J	J	_	Type-C to Mini USB	V1.3.6	 Please apply electronic follow focus function in AF mode of the lens and live view mode of the camera. If using electronic focusing when recording a video, please "Disable" the " Movie Servo AF ". The Canon DSLR cannot realize the halfway press shutter button to autofocus in Live Preview. If the feature is used, the camera Live Preview mode should be turned off. When shooting Panorama or Timelapse, it is recommended to turn off image confirmation in the Canon camera. The "Real-time Preview" feature is for users to switch between electronic viewfinder and optical viewfinder in DSLR by single- clicking the LV button of the stabilizer.
Canon 5D Mark IV	1	J	J	J	J	V	J	V	V	J	J	-	-	-	J	J	-	Type-C to Micro USB	V1.0.4	 Please apply electronic follow focus function in AF mode of the lens and live view mode of the camera. If using electronic focusing when recording a video, please "Disable" the " Movie Servo AF ". The Canon DSLR cannot realize the halfway press shutter button to autofocus in Live Preview. If the feature is used, the camera Live Preview mode should be turned off. When shooting Panorama or Timelapse, it is recommended to turn off image confirmation in the Canon camera. For Canon 5D Mark IV, switch the shooting mode to photo mode before taking photos. When shooting a video is needed, switch the shooting mode to movie mode. (Please turn off your camera before switching modes) Otherwise, the camera may freeze. (In this case please take out the camera batteries and reinstall and turn on the camera again)

Camera	F	Photo	\ \	/ideo	Live	Shutter Adjust		Aper Adjus		ISO Adj	ustment	EV Adju	istment	Electronic	Halfway Press	Electronic Follow	HDMI	Camera Control Cable	Camera	
Model	Save	Playback	Save	Playback	Preview	Photo Mode	Video Mode	Photo Mode	Video Mode	Photo Mode	Video Mode	Photo Mode	Video Mode	Zoom	Shutter Button to Autofocus	Focus (Focus Wheel)	Cable Type	Туре	Firmware Version	Note
Canon 5DS	J	J	J	J	V	V	V	V	V	V	V	-	-	-	J	V	-	Type-C to Micro USB	V1.1.1	 Please apply electronic follow focus function in AF mode of the lens and live view mode of the camera. If using electronic focusing when recording a video, please "Disable" the " Movie Servo AF ". The Canon DSLR cannot realize the halfway press shutter button to autofocus in Live Preview. If the feature is used, the camera Live Preview mode should be turned off.
Canon 5DS R	1	J	V	J	V	Ŷ	V	V	Ŷ	Ŷ	Y	-	-	-	J	Ŷ	-	Type-C to Micro USB	V1.1.2R	 When shooting Panorama or Timelapse, it is recommended to turn off image confirmation in the Canon camera. The "Real-time Preview" feature is for users to switch between electronic viewfinder and optical viewfinder in DSLR by single- clicking the LV button of the stabilizer.
Canon 6D Mark II	J	J	J	J	J	J	J	J	J	J	J	-	-	-	J	J	-	Type-C to Mini USB	V1.0.4	 Please apply electronic follow focus function in AF mode of the lens and live view mode of the camera. If using electronic focusing when recording a video, please "Disable" the " Movie Servo AF ". The Canon DSLR cannot realize the halfway press shutter button to autofocus in Live Preview. If the feature is used, the camera Live Preview mode should be turned off. When shooting Panorama or Timelapse, it is recommended to turn off image confirmation in the Canon camera. For Canon 5D Mark IV, switch the shooting mode to photo mode before taking photos. When shooting a video is needed, switch the shooting mode to movie mode. (Please turn off your camera before switching modes) Otherwise, the camera may freeze. (In this case please take out the camera batteries and reinstall and turn on the camera again)

Camera		Photo	V	/ideo	Live	Shutter Adjus		Aper Adjus		ISO Adj	ustment	EV Adju	ustment	Electronic	Halfway Press	Electronic Follow	HDMI	Camera Control Cable	Camera	
Model	Save	Playback	Save	Playback	Preview	Photo Mode	Video Mode	Photo Mode	Video Mode	Photo Mode	Video Mode	Photo Mode	Video Mode	Zoom	Shutter Button to Autofocus	Focus (Focus Wheel)	Cable Type	Туре	Firmware Version	Note
Canon 80D	J	Ą	J	J	J	J	J	J	J	Y	J	-	-	-	J	J	-	Type-C to Mini USB	V1.0.2	 Please apply electronic follow focus function in AF mode of the lens and live view mode of the camera. If using electronic focusing when recording a video, please "Disable" the " Movie Servo AF ". The Canon DSLR cannot realize the halfway press shutter button to autofocus in Live Preview. If the feature is used, the camera Live
Canon 90D	J	J	J	J	J	J	J	Y	J	Y	J	-	-	-	J	V	-	Type-C to Micro USB	V1.1.1	 Preview mode should be turned off. 4. When shooting Panorama or Timelapse, it is recommended to turn off image confirmation in the Canon camera. 5. The "Real-time Preview" feature is for users to switch between electronic viewfinder and optical viewfinder in DSLR by single-clicking the LV button of the stabilizer.
Canon M50	1	1	V	1	-	1	1	1	V	V	1	-	-	-	-	-	-	Type-C to Micro USB	V1.0.3	1. Please apply electronic follow focus
Canon EOS M6 Mark 11	1	√	V	1	1	V	V	√	V	V	V	-	-	-	-	V	-	Type-C to Type-C USB	V1.1.1	function in AF mode of the lens 2. If using electronic focusing when recording a video, please "Disable" the " Movie Servo AF ".
Canon EOS R5	V	√	V	1	-	1	1	1	V	V	1	-	-	-	1	1	-	Type-C to Type-C USB	V1.10	3. When shooting Panorama or Timelapse, it is recommended to turn off image confirmation in the Canon
Canon EOS R6	V	1	V	1	-	1	1	1	\checkmark	\checkmark	V	-	-	-	1	\checkmark	-	Type-C to Type-C USB	V1.3.1	camera.4. For Canon mirrorless cameras, switch the shooting mode to photo
Canon EOS R	V	1	V	1	-	1	V	1	V	V	V	-	-	-	1	V	-	Type-C to Type-C USB	V1.3.0	mode before taking photos. When shooting a video is needed, switch the shooting mode to movie mode. Please turn off your camera before
Canon EOS RP	J	J	V	J	-	J	J	J	Y	Y	J	-	-	-	V	J	-	Type-C to Type-C USB	V1.3.0	switching modes. For EOS R/RP/R5/ R6, shutter release can't be used to control video shooting in photo mode otherwise the camera may freeze. (In this case please take out the camera batteries and reinstall and turn on the camera again)

Camera	F	Photo	v	lideo	Live	Shutter Adjus		Aper Adjus		ISO Adj	ustment	EV Adju	istment	Electronic	Halfway Press	Electronic Follow	HDMI	Camera Control Cable	Camera	
Model	Save	Playback	Save	Playback	Proviow	Photo Mode	Video Mode	Photo Mode	Video Mode	Photo Mode	Video Mode	Photo Mode	Video Mode	Zoom	Shutter Button to Autofocus	Focus (Focus Wheel)	Cable Type	Туре	Firmware Version	Note
Nikon D850	V	J	\checkmark	J	-	J	\checkmark	V	J	Ŷ	Ŷ	-	-	-	Ż	Ŷ	-	Type-C to Micro USB	V1.11	 When using electronic focusing, the camera lens should be in A(AF) mode and select AF-S or AF-C in focusing mode. Nikon cameras don't support electronic focusing when recording. When shooting Panorama or Timepaga it is recommended to turn
Nikon D780	V	J	Y	J	-	J	Y	J	V	Y	Y	_	-	-	Y	J	-	Type-C to Type-C USB	V1.01	 Timelapse, it is recommended to turn off image review in the Nikon camera to reduce system latency. 4. The "Real-time Preview" feature is for users to switch between electronic viewfinder and optical viewfinder in DSLR by single-clicking the LV button of the stabilizer.
Nikon Z5	1	1	\checkmark	\checkmark	-	1	\checkmark	V	V	V	\checkmark	-	-	-	\checkmark	1	-	Type-C to Type-C USB	V1.00	
Nikon Z6	1	1	\checkmark	1	-	1	\checkmark	V	V	\checkmark	\checkmark	-	-	-	1	1	-	Type-C to Type-C USB	V3.00	1. When using electronic focusing, the
Nikon Z6 II	1	1	\checkmark	V	-	1	\checkmark	V	V	\checkmark	V	-	-	-	V	1	-	Type-C to Type-C USB	V1.00	camera lens should be in A(AF) mode and select AF-S or AF-C in focusing
Nikon Z7	1	1	V	1	-	1	V	V	V	V	V	-	-	-	\checkmark	1	-	Type-C to Type-C USB	V2.01	 mode. 2. Nikon cameras don't support electronic focusing when recording.
Nikon Z7 II	1	1	V	1	-	1	V	V	V	V	V	-	-	-	V	√	-	Type-C to Type-C USB	V1.00	3. When shooting Panorama or Timelapse, it is recommended to turn off image review in the Nikon camera
Nikon Z50	1	1	V	1	-	V	V	V	V	V	V	-	-	-	V	1	-	Type-C to Micro USB	V1.00	to reduce system latency.
Nikon Zfc	1	1	V	V	-	-	-	1	1	-	-	-	-	-	\checkmark	1	-	Type-C to Type-C USB	V1.00	

Camera		Photo	\	/ideo	Live	Shutter Adjust	-	Aper Adjus		ISO Adj	ustment	EV Adju	stment	Electronic	Halfway Press	Electronic Follow	HDMI	Camera Control Cable	Camera	
Model	Save	Playback	Save	Playback	Preview	Photo Mode	Video Mode	Photo Mode	Video Mode	Photo Mode	Video Mode	Photo Mode	Video Mode	Zoom	Shutter Button to Autofocus	Focus (Focus Wheel)	Cable Type	Туре	Firmware Version	Note
Fujifilm X-T3	V	V	V	V	-	V	-	-	-	V	V	-	-	-	J	-		Type-C to Type-C USB	V3.10	 Please set the "connection mode" into "USB TETHER shooting auto" for camera connection settings. In Photo mode of Fujifilm, camera parameter control from camera is disabled and you can only adjust
Fujifilm X-T4	V	V	V	V	-	V	-	-	-	Ŷ	V	-	-	-	J	-	-	Type-C to Type-C USB	V1.01	camera parameters via stabilizer. Restart the camera to resume parameter control of your camera. Plug in and out the camera control cable to return to stabilizer control; Fujifilm doesn't support saving photos in RAW format.
ZCAM E2	-	-	V	V	-	-	-	-	V	-	V	-	-	-	-	-	-	Type-C to Type-C USB	V0.95.0	1. Click [MENU], select [connect] and set [USB] to [serial]; Set [serial] to [controller].
BMPCC 4K	-	-	V	\checkmark	-	-	\checkmark	-	\checkmark	-	\checkmark	-	-	-	-	V	-	Type-C to Type-C USB	V7.3	
BMPCC 6K	-	-	V	\checkmark	-	-	\checkmark	-	\checkmark	-	\checkmark	-	-	-	-	V	-	Type-C to Type-C USB	V6.9.1	
SIGMA fp	1	-	\checkmark	-	-	-	-	-	-	-	-	-	-	-	V	-	-	Type-C to Type-C USB	V2.00	

Note:

1. This table will be updated in line with firmware update and is subject to change without prior notice;

2. For Sony cameras, after connecting the gimbal and camera with control cable, Please first power on the gimbal and then the camera. Make sure the camera has sufficient power to operate. Can set in the camera menu, Sony A7R3 should be set to auto power off starting at 30min.

3. When shooting Panorama or Timelapse, it is recommended to turn off the camera's auto review (Sony), image confirmation (Canon), auto review (Panasonic), image review (Nikon) to reduce system latency.

4. The Canon DSLR cannot realize the halfway press shutter button to autofocus in Live Preview. If the feature is used, the camera Live Preview mode should be turned off.

5. Before connecting Panasonic G9 with a control cable, please first turn off the USB Power Supply in camera settings.

6. When connecting an Olympus camera to the stabilizer, USB Mode will automatically pops up on the camera. Please select [$\Box_{j} \Delta$] (PC (Tether)) and dial the mode to P, A, S, or M mode.

7. "\" means the camera can realize the function after connecting to the stabilizer; "x" means the camera currently cannot realize the function after connecting to the stabilizer, but there're possibilities that the function may open by a firmware update or other ways. "-" means the uncontrollable functions after connecting to the stabilizer is because the camera control protocol is not opened.

Camera	Model	Lens Model	Mounting Status	Balance Adjustment	Balance Adjustment	Camera Backing Base	Camera Backing Base	Servo Zoom/Focus Motor	Installation Remark
Brand	woder	Lens Moder	Mounting Status	Horizontal	Vertical	Horizontal	Vertical	Servo Zoom/Pocus Motor	Installation Remark
			Camera and Lens	\checkmark	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
			with Servo Motor (For Focus Control)	\checkmark	-	-	-	Servo zoom & focus motor installed on left side	Can be balanced at any focal length; No need to remove eyepiece cap
		EF 16-35mm f/4L IS USM	with Servo Motor (For Zoom Control)	\checkmark	-	-	-	Servo zoom & focus motor installed on left side	Can be balanced at any focal length; No need to remove eyepiece cap
		LI 10-3311111 //4L 13 03101	with Video Transmission Transmitter	\checkmark	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	\checkmark	-	-	-	Servo zoom & focus motor installed on left side	Can be balanced at any focal length; No need to remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Zoom Control)	\checkmark	-	-	-	Servo zoom & focus motor installed on left side	Can be balanced at any focal length; No need to remove eyepiece cap
			Camera and Lens	\checkmark	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
			with Servo Motor (For Focus Control)	\checkmark	-	-	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap
		EF 16-35mm f/2.8L III USM	with Servo Motor (For Zoom Control)	\checkmark	-	-	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap
		LI 10-33HITH/2.0L III 03W	with Video Transmission Transmitter	\checkmark	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
	5DS、5DS R、 5D Mark III、		with Video Transmission Transmitter and Servo Motor (For Focus Control)	\checkmark	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
Canon	5D Mark IV、 6D Mark II、		with Video Transmission Transmitter and Servo Motor (For Zoom Control)	\checkmark	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
Callon	6D、90D、		Camera and Lens	\checkmark	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
	80D、6D、 90D、80D		with Servo Motor (For Focus Control)	\checkmark	-	-	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap
		EF 17-40mm f/4L USM	with Servo Motor (For Zoom Control)	\checkmark	-	-	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap
			with Video Transmission Transmitter	\checkmark	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	\checkmark	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Zoom Control)	\checkmark	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
			Camera and Lens	\checkmark	-	\checkmark	-		Can be balanced at any focal length; No need to remove eyepiece cap
			with Servo Motor (For Focus Control)	\checkmark	-	\checkmark	-	Servo zoom & focus motor installed on left side	Can be balanced at any focal length; No need to remove eyepiece cap
		EF 24-70mm f/2.8L II USM	with Servo Motor (For Zoom Control)	\checkmark	-	1	-	Servo zoom & focus motor installed on left side	Can be balanced at any focal length; No need to remove eyepiece cap
			with Video Transmission Transmitter	\checkmark	-	\checkmark	-		Can be balanced at any focal length; No need to remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	\checkmark	-	\checkmark	-	Servo zoom & focus motor installed on left side	Can be balanced at any focal length; No need to remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Zoom Control)	\checkmark	-	\checkmark	-	Servo zoom & focus motor installed on left side	Can be balanced at any focal length; No need to remove eyepiece cap

Camera	Model	Lens Model	Mounting Status	Balance Adjustment	Balance Adjustment	Camera Backing Base	Camera Backing Base	Servo Zoom/Focus Motor	Installation Remark
Brand	Model	Lens Model	wounting status	Horizontal	Vertical	Horizontal	Vertical	Servo Zoom/Pocus Motor	Installation Remark
			Camera and Lens	1	-	1	-		Can be balanced at any focal length; No need to remove eyepiece cap
			with Servo Motor (For Focus Control)	\checkmark	-	1	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap
		EF 24-70mm f/4L IS USM	with Servo Motor (For Zoom Control)	V	-	V	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap
		EF 24-70111111/4L 13 03101	with Video Transmission Transmitter	1	-	1	-		Can be balanced at any focal length; No need to remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	1	-	1	-		Can be balanced at any focal length; No need to remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Zoom Control)	1	-	1	-		Can be balanced at any focal length; No need to remove eyepiece cap
			Camera and Lens	1	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
			with Servo Motor (For Focus Control)	1	-	-	-	Servo zoom & focus motor installed on left side	Can be balanced at any focal length; No need to remove eyepiece cap
		EF 24-105mm f/4L IS II USM	with Servo Motor (For Zoom Control)	-	-	-	-		
			with Video Transmission Transmitter	-	-	-	-		
	5DS、5DS R、 5D Mark III、		with Video Transmission Transmitter and Servo Motor (For Focus Control)	-	-	-	-		
	5D Mark IV		with Video Transmission Transmitter and Servo Motor (For Zoom Control)	-	-	-	-		
Canon	6D Mark II、 6D、90D、		Camera and Lens	1	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
	80D、6D、 90D、80D		with Servo Motor (For Focus Control)	1	-	-	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap
			with Servo Motor (For Zoom Control)	-	-		-		
		EF 24-105mm f/3.5-5.6 IS STM	with Video Transmission Transmitter	1	-	1	-		Can be balanced at any focal length; No need to remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	1	-	1	-		Can be balanced at any focal length; No need to remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Zoom Control)	-	-	-	-		
			Camera and Lens	√	-	-	-		No need to remove eyepiece cap
		EF 24mm f/1.4L II USM	with Servo Motor (For Focus Control)	1	-	-	-	Servo zoom & focus motor installed on either side	No need to remove eyepiece cap
		2. 2	with Video Transmission Transmitter	√	-	√	-		No need to remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	1	-	1	-		No need to remove eyepiece cap
			Camera and Lens	√	-	-	-		No need to remove eyepiece cap
		EF 35mm f/1.4L II USM	with Servo Motor (For Focus Control)	1	-	-	-	Servo zoom & focus motor installed on either side	No need to remove eyepiece cap
			with Video Transmission Transmitter	√	-	-	-		No need to remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	\checkmark	-	\checkmark	-		No need to remove eyepiece cap

Camera	Model	Lens Model	Mounting Status	Balance Adjustment	Balance Adjustment	Camera Backing Base	Camera Backing Base	Servo Zoom/Focus Motor	Installation Remark
Brand	Model	Lens Moder	Mounting Status	Horizontal	Vertical	Horizontal	Vertical	Servo 20011/Pocus Motor	
			Camera and Lens	\checkmark	-	-	-		No need to remove eyepiece cap
		EF 50mm f/1.4 USM	with Servo Motor (For Focus Control)	1	-	-	-	Servo zoom & focus motor installed on either side	No need to remove eyepiece cap
			with Video Transmission Transmitter	√	-	-	-		No need to remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	1	-	1	-		No need to remove eyepiece cap
			Camera and Lens	√	-	-	-		No need to remove eyepiece cap
		EF 85mm f/1.4L IS USM	with Servo Motor (For Focus Control)	1	-	-	-	Servo zoom & focus motor installed on either side	No need to remove eyepiece cap
			with Video Transmission Transmitter	√	-	-	-		No need to remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	1	-	1	-		No need to remove eyepiece cap
			Camera and Lens	1	-	-	-		No need to remove eyepiece cap
		EF 85mm f/1.8 USM	with Servo Motor (For Focus Control)	1	-	-	-	Servo zoom & focus motor installed on either side	No need to remove eyepiece cap
	5DS, 5DS R,		with Video Transmission Transmitter	√	-	-	-		No need to remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	1	-	1	-		No need to remove eyepiece cap
	5D Mark III、 5D Mark IV、		Camera and Lens	1	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
Canon	6D Mark II、 6D、90D、		with Servo Motor (For Focus Control)	\checkmark	-	1	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap
	80D、6D、		with Servo Motor (For Zoom Control)	\checkmark	-	J	-	Servo zoom & focus motor installed on right side	Can be balanced at any focal length; No need to remove eyepiece cap
	90D、80D	Sigma 24-70mm f/2.8 DG HSM Art	with Video Transmission Transmitter	\checkmark	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	1	-	J	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Zoom Control)	1	-	1	-	Servo zoom & focus motor installed on right side	Can be balanced at any focal length; No need to remove eyepiece cap
			Camera and Lens	1	-	-	-		No need to remove eyepiece cap
		Sigma 35mm f/1.4 DG HSM Art	with Servo Motor (For Focus Control)	1	-	-	-	Servo zoom & focus motor installed on either side	No need to remove eyepiece cap
		Signa Sommi / 1.4 DG HSIVI AIT	with Video Transmission Transmitter	√	-	-	-		No need to remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	1	-	-	-		No need to remove eyepiece cap
			Camera and Lens	\checkmark	-	-	-		No need to remove eyepiece cap
		Sigma 50mm f/1.4 DG HSM Art	with Servo Motor (For Focus Control)	1	-	-	-	Servo zoom & focus motor installed on either side	No need to remove eyepiece cap
			with Video Transmission Transmitter	\checkmark	-	-	-		No need to remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	1	-	-	-	Servo zoom & focus motor installed on either side	No need to remove eyepiece cap

Camera	Model	Lens Model	Mounting Status	Balance Adjustment	Balance Adjustment	Camera Backing Base	Camera Backing Base	Servo Zoom/Focus Motor	Installation Remark
Brand	Woder	Lens Model	Mounting Status	Horizontal	Vertical	Horizontal	Vertical		
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	1	-	-	-	Servo zoom & focus motor installed on either side	No need to remove eyepiece cap
			Camera and Lens	1	-	-	-		Can be balanced at any focal length; Do not remove eyepiece cap
			with Servo Motor (For Focus Control)	V	-	-	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; Do not remove eyepiece cap
		EF 16-35mm f/4L IS USM	with Servo Motor (For Zoom Control)	\checkmark	-	\checkmark	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; Do not remove eyepiece cap
			with Video Transmission Transmitter	1	-	-	-		Can be balanced at any focal length; Do not remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	1	-	1	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; Do not remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Zoom Control)	1	-	1	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; Do not remove eyepiece cap
			Camera and Lens	-	-	-	-		
		EF 16-35mm f/2.8L III USM OS R、EOS RP、EOS R5 、EOS R6	with Servo Motor (For Focus Control)	-	-	-	-		
			with Servo Motor (For Zoom Control)	-	-	-	-		
			with Video Transmission Transmitter	-	-	-	-		
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	-	-	-	-		
Canon	RP、EOS R5		with Video Transmission Transmitter and Servo Motor (For Zoom Control)	-	-	-	-		
			Camera and Lens	\checkmark	-	-	-		Can be balanced at any focal length; Do not remove eyepiece cap
			with Servo Motor (For Focus Control)	V	-	-	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; Do not remove eyepiece cap
		EF 17-40mm f/4L USM	with Servo Motor (For Zoom Control)	V	-	\checkmark	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; Do not remove eyepiece cap
		EF 17-401111174L USW	with Video Transmission Transmitter	V	-	-	-		Can be balanced at any focal length; Do not remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	-	-	-	-		
			with Video Transmission Transmitter and Servo Motor (For Zoom Control)	-	-	-	-		
			Camera and Lens	-	-		-		
			with Servo Motor (For Focus Control)	-	-		-		
			with Servo Motor (For Zoom Control)	-	-		-		
		EF 24-70mm f/2.8L II USM	with Video Transmission Transmitter	-	-		-		
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	-	-		-		
			with Video Transmission Transmitter and Servo Motor (For Zoom Control)	-	-		-		

Camera	Model	Lens Model	Mounting Status	Balance Adjustment	Balance Adjustment	Camera Backing Base	Camera Backing Base	Servo Zoom/Focus Motor	Installation Remark
Brand	Woder	Lens model	Mounting Status	Horizontal	Vertical	Horizontal	Vertical	Servo Zoom/Focus Motor	
			Camera and Lens	\checkmark	-	√	-		Can be balanced at 24mm; Do not remove eyepiece cap
		EF 24-70mm f/4L IS USM	with Servo Motor (For Focus Control)	\checkmark	-	1	-	Servo zoom & focus motor installed on either side	Can be balanced at 24mm; Do not remove eyepiece cap
			with Servo Motor (For Zoom Control)	\checkmark	-	1	-	Servo zoom & focus motor installed on left side	Can be balanced at 24mm; Do not remove eyepiece cap
			with Video Transmission Transmitter	-	-		-		
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	-	-		-		
			with Video Transmission Transmitter and Servo Motor (For Zoom Control)	-	-		-		
			Camera and Lens	\checkmark	-	1	-		Can be balanced at any focal length; Do not remove eyepiece cap
			with Servo Motor (For Focus Control)	-	-		-		
			with Servo Motor (For Zoom Control)	-	-		-		
		EF 24-105mm f/4L IS II USM	with Video Transmission Transmitter	-	-		-		
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	-	-		-		
			with Video Transmission Transmitter and Servo Motor (For Zoom Control)	-	-		-		
Canon	EOS R、EOS RP、EOS R5	5	Camera and Lens	\checkmark	-	1	-		Can be balanced at any focal length; Do not remove eyepiece cap
Canon	EOS R5		with Servo Motor (For Focus Control)	\checkmark	-	J	-	Servo zoom & focus motor installed on left side	Can be balanced at any focal length; Do not remove eyepiece cap
			with Servo Motor (For Zoom Control)	\checkmark	-	√	-	Servo zoom & focus motor installed on left side	Can be balanced at any focal length; Do not remove eyepiece cap
			with Video Transmission Transmitter	-	-		-		
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	-	-		-		
			with Video Transmission Transmitter and Servo Motor (For Zoom Control)	-	-		-		
			Camera and Lens	\checkmark	-	-	-		Do not remove eyepiece cap
		EF 24mm f/1.4L II USM	with Servo Motor (For Focus Control)	\checkmark	-	-	-	Servo zoom & focus motor installed on either side	Do not remove eyepiece cap
		EF 2411111/1.4L II USW	with Video Transmission Transmitter	\checkmark	-	-	-		Do not remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	\checkmark	-	-	-	Servo zoom & focus motor installed on either side	Do not remove eyepiece cap
			Camera and Lens	\checkmark	-	-	-		Do not remove eyepiece cap
		EF 35mm f/1.4L II USM	with Servo Motor (For Focus Control)	\checkmark	-	-	-	Servo zoom & focus motor installed on either side	Do not remove eyepiece cap
		LI ⁻ 3011111 / 1.4L II USIVI	with Video Transmission Transmitter	\checkmark	-	-	-		Do not remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	\checkmark	-	-	-	Servo zoom & focus motor installed on either side	Do not remove eyepiece cap

Camera	Model	Long Madel	Mounting Status	Balance Adjustment	Balance Adjustment	Camera Backing Base	Camera Backing Base	Servo Zoom/Focus Motor	Installation Remark
Brand	woder	Lens Model	Mounting Status	Horizontal	Vertical	Horizontal	Vertical	Servo Zoom/Focus Motor	Installation Remark
			Camera and Lens	1	-	-	-		Do not remove eyepiece cap
			with Servo Motor (For Focus Control)	\checkmark	-	-	-	Servo zoom & focus motor installed on either side	Do not remove eyepiece cap
		EF 50mm f/1.2L USM	with Video Transmission Transmitter	1	-	-	-		Do not remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	\checkmark	-	-	-	Servo zoom & focus motor installed on either side	Do not remove eyepiece cap
			Camera and Lens	\checkmark	-	-	-		Do not remove eyepiece cap
		EF 50mm f/1.4 USM	with Servo Motor (For Focus Control)	1	-	-	-	Servo zoom & focus motor installed on either side	Do not remove eyepiece cap
		EF SUMMIT / 1.4 USIVI	with Video Transmission Transmitter	1	-	-	-		Do not remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	\checkmark	-	-	-	Servo zoom & focus motor installed on either side	Do not remove eyepiece cap
			Camera and Lens	1	-	-	-		Do not remove eyepiece cap
			with Servo Motor (For Focus Control)	-	-		-		
		EF 85mm f/1.4L IS USM	with Video Transmission Transmitter	-	-		-		
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	-	-		-		
		EF 85mm f/1.8 USM	Camera and Lens	1	-	-	-		Do not remove eyepiece cap
			with Servo Motor (For Focus Control)	1	-	-	-	Servo zoom & focus motor installed on either side	Do not remove eyepiece cap
	EOS R, EOS		with Video Transmission Transmitter	-	-		-		
Canon	RP、EOS R5 、EOS R6		with Video Transmission Transmitter and Servo Motor (For Focus Control)	-	-		-		
			Camera and Lens	1	-	-	-		Can be balanced at any focal length; Do not remove eyepiece cap
			with Servo Motor (For Focus Control)	-	-		-		
			with Servo Motor (For Zoom Control)	-	-		-		
		Sigma 24-70mm f/2.8 DG HSM Art	with Video Transmission Transmitter	1	-	-	-		Do not remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	-	-	-	-		
			with Video Transmission Transmitter and Servo Motor (For Zoom Control)	-	-	-	-		
			Camera and Lens	1	-	-	-		Do not remove eyepiece cap
		Sigma 35mm f/1.4 DG HSM Art	with Servo Motor (For Focus Control)	\checkmark	-	-	-	Servo zoom & focus motor installed on either side	Do not remove eyepiece cap
		Signa Sommi/ 1.4 DG HSWI Art	with Video Transmission Transmitter	1	-	-	-		Do not remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	\checkmark	-	-	-	Servo zoom & focus motor installed on either side	Do not remove eyepiece cap
			Camera and Lens	1	-	-	-		Do not remove eyepiece cap
		Sigma 50mm f/1.4 DG HSM Art	with Servo Motor (For Focus Control)	\checkmark	-	-	-	Servo zoom & focus motor installed on either side	Do not remove eyepiece cap
		Sigma Summi / 1.4 DG HSIVI AR	with Video Transmission Transmitter	\checkmark	-	-	-		Do not remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	\checkmark	-	-	-	Servo zoom & focus motor installed on either side	Do not remove eyepiece cap

Camera	Model	Lens Model	Mounting Status	Balance Adjustment	Balance Adjustment	Camera Backing Base	Camera Backing Base	Servo Zoom/Focus Motor	Installation Remark
Brand	Woder	Lens Model	Mounting Status	Horizontal	Vertical	Horizontal	Vertical	Servo Zoom/Focus Motor	Installation nethalk
			Camera and Lens	\checkmark	-	1	-		Can be balanced at any focal length; No need to remove eyepiece cap
			with Servo Motor (For Focus Control)	\checkmark	-	1	-	Servo zoom & focus motor installed on right side	Can be balanced at any focal length; No need to remove eyepiece cap
		RF 24-70mm f/2.8 L IS USM	with Servo Motor (For Zoom Control)	V	-	1	-	Servo zoom & focus motor installed on left side	Can be balanced at any focal length; No need to remove eyepiece cap
			with Video Transmission Transmitter	\checkmark	-	√	-		Do not remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	\checkmark	-	1	-	Servo zoom & focus motor installed on right side	Do not remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Zoom Control)	\checkmark	-	1	-	Servo zoom & focus motor installed on left side	Do not remove eyepiece cap
	EOS R、EOS RP、EOS R5 、EOS R6		Camera and Lens	\checkmark	-	1	-		Can be balanced at any focal length; No need to remove eyepiece cap
			with Servo Motor (For Focus Control)	\checkmark	-	1	-	Servo zoom & focus motor installed on right side	Can be balanced at any focal length; No need to remove eyepiece cap
	, LOS 110	RF 15-35mm f/2.8 L IS USM	with Servo Motor (For Zoom Control)	\checkmark	-	1	-	Servo zoom & focus motor installed on left side	Can be balanced at any focal length; No need to remove eyepiece cap
			with Video Transmission Transmitter	\checkmark	-	√	-		Do not remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	\checkmark	-	1	-	Servo zoom & focus motor installed on right side	Do not remove eyepiece cap
Canon			with Video Transmission Transmitter and Servo Motor (For Zoom Control)	\checkmark	-	V	-	Servo zoom & focus motor installed on left side	Do not remove eyepiece cap
		RF50mm F1.2 L USM	Camera and Lens	√	-	√	-		Do not remove eyepiece cap
			with Servo Motor (For Focus Control)	\checkmark	-	1	-	Servo zoom & focus motor installed on either side	Do not remove eyepiece cap
			with Video Transmission Transmitter	-	-	-	-		
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	-	-	-	-		
			Camera and Lens	\checkmark	-	-	-		
			with Servo Motor (For Focus Control)	\checkmark	-	-	-		
		EF-M 32mm f/1.4 STM	with Video Transmission Transmitter	\checkmark	-	-	-		
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	\checkmark	-	-	-		
	EOS M50、		Camera and Lens	\checkmark	-	-	-		
	EOS MOU		with Servo Motor (For Focus Control)	1	-	-	-		
			with Servo Motor (For Zoom Control)	1	-	-	-		
		EF-M 11-22mm f/4-5.6 IS STM	with Video Transmission Transmitter	J	-	-	-		
		2. WH 22111177 0.0 10 0111	with Video Transmission Transmitter and Servo Motor (For Focus Control)	1	-	-	-		
			with Video Transmission Transmitter and Servo Motor (For Zoom Control)	\checkmark	-	-	-		

Camera	Model	Lens Model	Mounting Status	Balance Adjustment	Balance Adjustment	Camera Backing Base	Camera Backing Base	Servo Zoom/Focus Motor	Installation Remark
Brand			J. J	Horizontal	Vertical	Horizontal	Vertical		
			Camera and Lens	√	-	-	-		
			with Servo Motor (For Focus Control)	√	-	-	-		
			with Servo Motor (For Zoom Control)	√	-	-	-		
	EOS M50、	EF-M 15-45mm f/3.5-6.3 IS STM	with Video Transmission Transmitter	√	-	-	-		
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	1	-	-	-		
Canon			with Video Transmission Transmitter and Servo Motor (For Zoom Control)	1	-	-	-		
Canon	EOS M6 Mark II		Camera and Lens	1	-	-	-		
			with Servo Motor (For Focus Control)	√	-	-	-		
			with Servo Motor (For Zoom Control)	1	-	-	-		
		EF-M 18-55mm f/3.5-5.6 IS STM	with Video Transmission Transmitter	1	-	-	-		
		-	with Video Transmission Transmitter and Servo Motor (For Focus Control)	1	-	-	-		
			with Video Transmission Transmitter and Servo Motor (For Zoom Control)	1	-	-	-		

Camera	Model	Lens Model	Mounting Status	Balance Adjustment	Balance Adjustment	Camera Backing Base	Camera Backing Base	Servo Zoom/Focus Motor	Installation Remark
Brand	Model		Wounting Status	Horizontal	Vertical	Horizontal	Vertical	Servo Zoom/1 ocus motor	Installation nemark
			Camera and Lens	1	-	-	-		
			with Servo Motor (For Focus Control)	1	-	-	-		
			with Servo Motor (For Zoom Control)	1	-	-	-		
		EF-M 18-150mm f/3.5-6.3 IS STM	with Video Transmission Transmitter	1	-	-	-		
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	1	-	-	-		
			with Video Transmission Transmitter and Servo Motor (For Zoom Control)	1	-	-	-		
			Camera and Lens	√	-	-	-		
			with Servo Motor (For Focus Control)	1	-	-	-		
			with Servo Motor (For Zoom Control)	1	-	-	-		
	500 1450	EF-M 55-200mm f/4.5-6.3 IS STM	with Video Transmission Transmitter	√	-	-	-		
Canon	EOS M50、 EOS M6 Mark II		with Video Transmission Transmitter and Servo Motor (For Focus Control)	\checkmark	-	-	-		
			with Video Transmission Transmitter and Servo Motor (For Zoom Control)	\checkmark	-	-	-		
		EF-M 22mm f/2 STM	Camera and Lens	√	-	-	-		
			with Servo Motor (For Focus Control)	√	-	-	-		
			with Video Transmission Transmitter	1	-	-	-		
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	1	-	-	-		
			Camera and Lens	1	-	-	-		
			with Servo Motor (For Focus Control)	1	-	-	-		
		EF-M 28mm f/3.5 IS STM	with Video Transmission Transmitter	1	-	-	-		
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	\checkmark	-	-	-		
			Camera and Lens	1	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
			with Servo Motor (For Focus Control)	\checkmark	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
Nilson	D850、D780		with Servo Motor (For Zoom Control)	\checkmark	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
Nikon	D000, D100	AF-S NIKKOR 14-24mm f/2.8G ED	with Video Transmission Transmitter	\checkmark	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	1	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Zoom Control)	V	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap

Camera	Madal	Long Medel	Mounting Status	Balance Adjustment	Balance Adjustment	Camera Backing Base	Camera Backing Base	Convo Zoom/Foous Motor	Installation Domosik
Brand	Model	Lens Model	Mounting Status	Horizontal	Vertical	Horizontal	Vertical	Servo Zoom/Focus Motor	Installation Remark
			Camera and Lens	\checkmark	-	1	-		Can be balanced at any focal length; No need to remove eyepiece cap
		AF-S NIKKOR 16-35mm f/4G ED VR	with Servo Motor (For Focus Control)	\checkmark	-	\checkmark	-		Can be balanced at any focal length; No need to remove eyepiece cap
			with Servo Motor (For Zoom Control)	\checkmark	-	\checkmark	-		Can be balanced at any focal length; No need to remove eyepiece cap
		AF-S NIKKOR 10-3011111/4G ED VR	with Video Transmission Transmitter	\checkmark	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	\checkmark	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Zoom Control)	\checkmark	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
			Camera and Lens	-	-	-	-		
			with Servo Motor (For Focus Control)	-	-	-	-		
		AF-S NIKKOR 24-70mm f	with Servo Motor (For Zoom Control)	-	-		-		
		/	with Video Transmission Transmitter	-	-		-		
		2.8E ED VR	with Video Transmission Transmitter and Servo Motor (For Focus Control)	-	-		-		
			with Video Transmission Transmitter and Servo Motor (For Zoom Control)	-	-		-		
		AF-S NIKKOR 24-70mm f/2.8G ED	Camera and Lens	-	-	-	-		
	D 050 D 700		with Servo Motor (For Focus Control)	-	-	-	-		
Nikon	D850、D780		with Servo Motor (For Zoom Control)	-	-		-		
			with Video Transmission Transmitter	-	-		-		
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	-	-		-		
			with Video Transmission Transmitter and Servo Motor (For Zoom Control)	-	-		-		
			Camera and Lens	\checkmark	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
			with Servo Motor (For Focus Control)	-	-		-		
		AF-S NIKKOR 24-120mm f	with Servo Motor (For Zoom Control)	\checkmark	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
		/ 4G ED VR	with Video Transmission Transmitter	-	-		-		
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	-	-		-		
			with Video Transmission Transmitter and Servo Motor (For Zoom Control)	-	-		-		
			Camera and Lens	\checkmark	-	-	-		No need to remove eyepiece cap
			with Servo Motor (For Focus Control)	\checkmark	-	-	-	Servo zoom & focus motor installed on either side	No need to remove eyepiece cap
		AF-S NIKKOR 24mm f/1.4G ED	with Video Transmission Transmitter	\checkmark	-	-	-		No need to remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	\checkmark	-	-	-	Servo zoom & focus motor installed on either side	No need to remove eyepiece cap

Camera	Model	Lens Model	Mounting Status	Balance Adjustment	Balance Adjustment	Camera Backing Base	Camera Backing Base	Servo Zoom/Focus Motor	Installation Remark
Brand	Wodel	Lens Moder	Mounting Status	Horizontal	Vertical	Horizontal	Vertical	Servo Zoom/Pocus Motor	Instantion Remark
			Camera and Lens	1	-	-	-		No need to remove eyepiece cap
		AF-S NIKKOR 24mm f/1.8G ED	with Servo Motor (For Focus Control)	1	-	-	-	Servo zoom & focus motor installed on either side	No need to remove eyepiece cap
		AF-3 NIRRON 24IIIIII/ 1.0G ED	with Video Transmission Transmitter	1	-	-	-		No need to remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	1	-	-	-	Servo zoom & focus motor installed on either side	No need to remove eyepiece cap
			Camera and Lens	1	-	-	-		No need to remove eyepiece cap
		AF-S NIKKOR 35mm f/1.4G	with Servo Motor (For Focus Control)	1	-	-	-	Servo zoom & focus motor installed on either side	No need to remove eyepiece cap
		AF-3 NIRKON 33IIIII / 1.40	with Video Transmission Transmitter	1	-	-	-		No need to remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	1	-	-	-	Servo zoom & focus motor installed on either side	No need to remove eyepiece cap
			Camera and Lens	1	-	-	-		No need to remove eyepiece cap
		AF-S NIKKOR 50mm f/1.4G	with Servo Motor (For Focus Control)	1	-	-	-	Servo zoom & focus motor installed on either side	No need to remove eyepiece cap
		AF-S NIKKOR SUMM 1/ 1.4G	with Video Transmission Transmitter	1	-	-	-		No need to remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	\checkmark	-	-	-	Servo zoom & focus motor installed on either side	No need to remove eyepiece cap
			Camera and Lens	√ √	-	-	-		No need to remove eyepiece cap
Nikon	D850、D780	AF-S NIKKOR 85mm f/1.4G	with Servo Motor (For Focus Control)	\checkmark	-	-	-	Servo zoom & focus motor installed on either side	No need to remove eyepiece cap
			with Video Transmission Transmitter	-	-	-	-		
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	-	-	-	-		
			Camera and Lens	1	-	-	-		No need to remove eyepiece cap
		AF-S NIKKOR 85mm f/1.8G	with Servo Motor (For Focus Control)	\checkmark	-	-	-	Servo zoom & focus motor installed on either side	No need to remove eyepiece cap
		AF-S NIKKON 65ITIITI/ 1.6G	with Video Transmission Transmitter	-	-	-	-		
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	-	-	-	-		
			Camera and Lens	√	-	-	-		No need to remove eyepiece cap
			with Servo Motor (For Focus Control)	1	-	-	-	Servo zoom & focus motor installed on either side	No need to remove eyepiece cap
			with Servo Motor (For Zoom Control)	\checkmark	-	-	-	Servo zoom & focus motor installed on either side	No need to remove eyepiece cap
		Sigma 24 70mm f/2.8L DG	with Video Transmission Transmitter	1	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	1	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Zoom Control)	\checkmark	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap

Camera	Model	Lens Model	Mounting Status	Balance Adjustment	Balance Adjustment	Camera Backing Base	Camera Backing Base	Servo Zoom/Focus Motor	Installation Remark
Brand	Woder	Lens Woder		Horizontal	Vertical	Horizontal	Vertical	Serve Zoom/Focus Motor	Installation Remark
			Camera and Lens	V	-	-	-		No need to remove eyepiece cap
			with Servo Motor (For Focus Control)	V	-	-	-	Servo zoom & focus motor installed on either side	No need to remove eyepiece cap
		Sigma 35mm F1.4 DG	with Video Transmission Transmitter	\checkmark	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
	D050 D700		with Video Transmission Transmitter and Servo Motor (For Focus Control)	V	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
	D850、D780		Camera and Lens	\checkmark	-	-	-		No need to remove eyepiece cap
			with Servo Motor (For Focus Control)	\checkmark	-	-	-	Servo zoom & focus motor installed on either side	No need to remove eyepiece cap
		Sigma 50mm F1.4 DG	with Video Transmission Transmitter	\checkmark	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	\checkmark	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
		NIKKOR Z 24-70mm f/2.8S	Camera and Lens	\checkmark	-	1	-		Can be balanced at any focal length; No need to remove eyepiece cap
			with Servo Motor (For Focus Control)	\checkmark	-	1	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap
			with Servo Motor (For Zoom Control)	\checkmark	-	1	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap
Nikon			with Video Transmission Transmitter	\checkmark	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	\checkmark	-	1	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Zoom Control)	\checkmark	-	1	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap
	Z50、Z5、		Camera and Lens	\checkmark	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
	Z6、Z6 II、		with Servo Motor (For Focus Control)	-	-	-	-		
	Z7、Z7 II、 Zfc		with Servo Motor (For Zoom Control)	\checkmark	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
		NIKKOR Z 24-70mm f/4S	with Video Transmission Transmitter	\checkmark	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	-	-	-	-		
			with Video Transmission Transmitter and Servo Motor (For Zoom Control)	\checkmark	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
			Camera and Lens	\checkmark	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
		NIKKOR Z 35mm f/1.8S	with Servo Motor (For Focus Control)	\checkmark	-	-	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap
		NIKKUH 2 JOITIITI 1/ 1.85	with Video Transmission Transmitter	\checkmark	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	\checkmark	-	-	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap

Camera	Model	Lens Model	Mounting Status	Balance Adjustment	Balance Adjustment	Camera Backing Base	Camera Backing Base	Servo Zoom/Focus Motor	Installation Remark
Brand	woder		mounting Status	Horizontal	Vertical	Horizontal	Vertical	Servo Zoom/Focus Motor	Installation Remark
			Camera and Lens	1	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
			with Servo Motor (For Focus Control)	\checkmark	-	1	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap
		NIKKOR Z 50mm f/1.8S	with Video Transmission Transmitter	V	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	1	-	√	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap
			Camera and Lens	\checkmark	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
			with Servo Motor (For Focus Control)	-	-		-		
			with Servo Motor (For Zoom Control)	-	-		-		
		AF-S NIKKOR 14-24mm f/2.8G ED	with Video Transmission Transmitter	1	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	-	-	-	-		
			with Video Transmission Transmitter and Servo Motor (For Zoom Control)	-	-	-	-		
	Z50、Z5、 Z6、Z6 II、	AF-S NIKKOR 16-35mm f/4G ED VR	Camera and Lens	1	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
			with Servo Motor (For Focus Control)	1	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
Nikon			with Servo Motor (For Zoom Control)	1	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
	Z7、Z7 II、 Zfc		with Video Transmission Transmitter	1	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	-	-	-	-		
			with Video Transmission Transmitter and Servo Motor (For Zoom Control)	-	-	-	-		
			Camera and Lens	-	-		-		
			with Servo Motor (For Focus Control)	-	-		-		
		AF-S NIKKOR 24-70mm f	with Servo Motor (For Zoom Control)	-	-		-		
		/	with Video Transmission Transmitter	-	-		-		
		2.8E ED VR	with Video Transmission Transmitter and Servo Motor (For Focus Control)	-	-	-	-		
			with Video Transmission Transmitter and Servo Motor (For Zoom Control)	-	-	-	-		
			Camera and Lens	-	-	-	-		
			with Servo Motor (For Focus Control)	-	-	-	-		
			with Servo Motor (For Zoom Control)	-	-	-	-		
		AF-S NIKKOR 24-70mm f/2.8G ED	with Video Transmission Transmitter	-	-	-	-		
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	-	-	-	-		
			with Video Transmission Transmitter and Servo Motor (For Zoom Control)	-	-	-	-		

Camera	Model	Lens Model	Mounting Status	Balance Adjustment	Balance Adjustment	Camera Backing Base	Camera Backing Base	Servo Zoom/Focus Motor	Installation Remark
Brand	Model	Lens Model	Mounting Status	Horizontal	Vertical	Horizontal	Vertical	Servo Zoom/Focus Motor	Installation Remark
			Camera and Lens	-	-	-	-		
			with Servo Motor (For Focus Control)	-	-	-	-		
		AF-S NIKKOR 24-120mm f	with Servo Motor (For Zoom Control)	-	-	-	-		
		AF-3 NIKKON 24-12011111 /	with Video Transmission Transmitter	-	-	-	-		
	4G ED VR	4G ED VR	with Video Transmission Transmitter and Servo Motor (For Focus Control)	-	-	-	-		
			with Video Transmission Transmitter and Servo Motor (For Zoom Control)	-	-	-	-		
			Camera and Lens	1	-	-	-		Can be balanced at any focal length; Need to remove eyepiece cap
		AF-S NIKKOR 24mm f/1.4G ED	with Servo Motor (For Focus Control)	1	-	-	-		Can be balanced at any focal length; Need to remove eyepiece cap
		AI -3 NIKKON 2411111 / 1.40 LD	with Video Transmission Transmitter	1	-	-	-		Can be balanced at any focal length; Need to remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	1	-	-	-		Can be balanced at any focal length; Need to remove eyepiece cap
			Camera and Lens	1	-	-	-		Can be balanced at any focal length; Need to remove eyepiece cap
			with Servo Motor (For Focus Control)	1	-	-	-		Can be balanced at any focal length; Need to remove eyepiece cap
		AF-S NIKKOR 24mm f/1.8G ED	with Video Transmission Transmitter	1	-	-	-		Can be balanced at any focal length; Need to remove eyepiece cap
	Z50、Z5、		with Video Transmission Transmitter and Servo Motor (For Focus Control)	1	-	-	-		Can be balanced at any focal length; Need to remove eyepiece cap
Nikon	Z6、Z6 II、 Z7、Z7 II、	AF-S NIKKOR 35mm f/1.4G	Camera and Lens	1	-	-	-		Can be balanced at any focal length; Need to remove eyepiece cap
	Zfc		with Servo Motor (For Focus Control)	1	-	-	-		Can be balanced at any focal length; Need to remove eyepiece cap
			with Video Transmission Transmitter	1	-	-	-		Can be balanced at any focal length; Need to remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	1	-	-	-		Can be balanced at any focal length; Need to remove eyepiece cap
			Camera and Lens	1	-	-	-		Can be balanced at any focal length; Need to remove eyepiece cap
		AF-S NIKKOR 50mm f/1.4G	with Servo Motor (For Focus Control)	1	-	-	-		Can be balanced at any focal length; Need to remove eyepiece cap
		AF-S NIKKOK SUMMI/ 1.4G	with Video Transmission Transmitter	1	-	-	-		Can be balanced at any focal length; Need to remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	1	-	-	-		Can be balanced at any focal length; Need to remove eyepiece cap
			Camera and Lens	1	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
			with Servo Motor (For Focus Control)	-	-	-	-		
			with Servo Motor (For Zoom Control)	-	-	-	-		
		Sigma 24 70mm f/2.8L DG	with Video Transmission Transmitter	1	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	-	-	-	-		
			with Video Transmission Transmitter and Servo Motor (For Zoom Control)	-	-	-	-		-24-

-24-

Camera	Model	Lens Model	Mounting Status	Balance Adjustment	Balance Adjustment	Camera Backing Base	Camera Backing Base	Servo Zoom/Focus Motor	Installation Remark
Brand	Model	Lens Moder	Mounting Status	Horizontal	Vertical	Horizontal	Vertical	Servo Zoom/Pocus Motor	Installation Remark
			Camera and Lens	\checkmark	-	-	-		Can be balanced at any focal length; Need to remove eyepiece cap
			with Servo Motor (For Focus Control)	\checkmark	-	-	-		Can be balanced at any focal length; Need to remove eyepiece cap
		Sigma 35mm F1.4 DG	with Video Transmission Transmitter	\checkmark	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
Nikon	Z50、Z5、 Z6、Z6 II、	with Video Transmission Transmitter and Servo Motor (For Focus Control)	\checkmark	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap	
NIKOII	Z7、Z7 II、 Zfc		Camera and Lens	\checkmark	-	-	-		Can be balanced at any focal length; Need to remove eyepiece cap
		Sigma 50mm F1.4 DG	with Servo Motor (For Focus Control)	\checkmark	-	-	-		Can be balanced at any focal length; Need to remove eyepiece cap
		Sigina Somini 1.4 Da	with Video Transmission Transmitter	\checkmark	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	\checkmark	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
			Camera and Lens	V	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
	α1,		with Servo Motor (For Focus Control)	V	-	-	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap
	a9, a9 ,	FE 10.05 F0.0.0M	with Servo Motor (For Zoom Control)	V	-	-	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap
	α7M2、	FE 16-35mm F2.8 GM	with Video Transmission Transmitter	1	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
	α7R2、 α7S2、		with Video Transmission Transmitter and Servo Motor (For Focus Control)	\checkmark	-	-	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap
Com	α7M4、 α7M3、		with Video Transmission Transmitter and Servo Motor (For Zoom Control)	V	-	-	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap
Sony	a7R3, a7S3, a7R4, a7C,		Camera and Lens	V	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
			with Servo Motor (For Focus Control)	V	-	-	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap
	α6600、	FE 40.05 v v F4.74100	with Servo Motor (For Zoom Control)	1	-	-	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap
	α6500、 α6400、	FE 16-35mm F4 ZAISS	with Video Transmission Transmitter	1	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
	a6300, a6100		with Video Transmission Transmitter and Servo Motor (For Focus Control)	\checkmark	-	-	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap
		-	with Video Transmission Transmitter and Servo Motor (For Zoom Control)	\checkmark	-	-	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap

ZHIYUN

Camera	Model	Lens Model	Mounting Status	Balance Adjustment	Balance Adjustment	Camera Backing Base	Camera Backing Base	Servo Zoom/Focus Motor	Installation Demork
Brand	Model	Lens model	Mounting Status	Horizontal	Vertical	Horizontal	Vertical	Servo Zoom/Pocus Motor	Installation Remark
			Camera and Lens	\checkmark	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
			with Servo Motor (For Focus Control)	1	-	-	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap
		FE 12-24mm F4 G	with Servo Motor (For Zoom Control)	\checkmark	-	-	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap
		FE 12-24mm F4 G	with Video Transmission Transmitter	V	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	1	-	-	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Zoom Control)	1	-	-	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap
			Camera and Lens	√ √	-	-	-		No need to remove eyepiece cap
	α1、		with Servo Motor (For Focus Control)	1	-	-	-	Servo zoom & focus motor installed on either side	No need to remove eyepiece cap
	α9、 α9 ΙΙ、	FE 24mm f1.4GM	with Video Transmission Transmitter	V	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
	α7M2、 α7R2、		with Video Transmission Transmitter and Servo Motor (For Focus Control)	V	-	-	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap
	a7S2、 a7M4、		with Video Transmission Transmitter and Servo Motor (For Focus Control)	V	-	-	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap
Sony	α7M3、 α7R3、		Camera and Lens	V	-	\checkmark	-		Can be balanced at any focal length; Need to remove eyepiece cap (Roll axis slightly rub against the camera)
	α7S3、		with Servo Motor (For Focus Control)	V	-	\checkmark	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; Need to remove eyepiece cap (Roll axis slightly rub against the camera)
	α7R4、 α7C、	FE 24-70mm F2.8 GM	with Servo Motor (For Zoom Control)	V	-	V	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; Need to remove eyepiece cap (Roll axis slightly rub against the camera)
	α6600、 α6500、		with Video Transmission Transmitter	V	-	-	-		Can be balanced at any focal length; Need to remove eyepiece cap (Roll axis slightly rub against the camera)
	a6400、 a6300、a6100		with Video Transmission Transmitter and Servo Motor (For Focus Control)	1	-	\checkmark	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; Need to remove eyepiece cap (Roll axis slightly rub against the camera)
			with Video Transmission Transmitter and Servo Motor (For Zoom Control)	V	-	V	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; Need to remove eyepiece cap (Roll axis slightly rub against the camera)
			Camera and Lens	V	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
			with Servo Motor (For Focus Control)	V	-	-	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap
		EE 04 70mm E4 74 000	with Servo Motor (For Zoom Control)	V	-	-	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap
		FE 24–70mm F4 ZA OSS	with Video Transmission Transmitter	1	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	1	-	-	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Zoom Control)	\checkmark	-	-	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap

Camera	Madal	Louis Marial	Mauritica Otatua	Balance Adjustment	Balance Adjustment	Camera Backing Base	Camera Backing Base	Come Zoom / Soone Madar	lastellation Demode
Brand	Model	Lens Model	Mounting Status	Horizontal	Vertical	Horizontal	Vertical	Servo Zoom/Focus Motor	Installation Remark
			Camera and Lens	1	-	-	-		No need to remove eyepiece cap
		FE 28mm F2	with Servo Motor (For Focus Control)	V	-	-	-	Servo zoom & focus motor installed on either side	No need to remove eyepiece cap
		FE 28mm F2	with Video Transmission Transmitter	√	-	-	-		No need to remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	V	-	-	-	Servo zoom & focus motor installed on either side	No need to remove eyepiece cap
	[Camera and Lens	\checkmark	-	-	-		No need to remove eyepiece cap
		FE 50mm F1.8	with Servo Motor (For Focus Control)	1	-	-	-	Servo zoom & focus motor installed on either side	No need to remove eyepiece cap
		FE JUITITI FT.0	with Video Transmission Transmitter	1	-	-	-		No need to remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	1	-	-	-	Servo zoom & focus motor installed on either side	No need to remove eyepiece cap
			Camera and Lens	√	-	-	-		No need to remove eyepiece cap
		FE 85mm F1.4 GM	with Servo Motor (For Focus Control)	1	-	-	-	Servo zoom & focus motor installed on either side	No need to remove eyepiece cap
	α1、		with Video Transmission Transmitter	1	-	-	-		No need to remove eyepiece cap
	α9、 α9 ΙΙ,		with Video Transmission Transmitter and Servo Motor (For Focus Control)	1	-	-	-	Servo zoom & focus motor installed on either side	No need to remove eyepiece cap
	α7M2,	Distagon T* FE 35mm F1.4 ZA	Camera and Lens	√	-	-	-		No need to remove eyepiece cap
	a7R2、 a7S2、		with Servo Motor (For Focus Control)	1	-	-	-	Servo zoom & focus motor installed on left side	No need to remove eyepiece cap
	a7M4,		with Video Transmission Transmitter	√	-	-	-		No need to remove eyepiece cap
Sony	α7Μ3、		with Video Transmission Transmitter and Servo Motor (For Focus Control)	1	-	-	-	Servo zoom & focus motor installed on left side	No need to remove eyepiece cap
	α7R3、 α7S3、		Camera and Lens	√	-	-	-		No need to remove eyepiece cap
	α7R4、	Sonnar T* FE 35mm F2.8 ZA	with Servo Motor (For Focus Control)	1	-	-	-	Servo zoom & focus motor installed on right side	No need to remove eyepiece cap
	α7C、 α6600、		with Video Transmission Transmitter	√	-	-	-		No need to remove eyepiece cap
	α6500、		with Video Transmission Transmitter and Servo Motor (For Focus Control)	V	-	-	-	Servo zoom & focus motor installed on right side	No need to remove eyepiece cap
	a6400、 a6300、a6100		Camera and Lens	1	-	-	-		No need to remove eyepiece cap
	00000, 00100	Sonnar® T* FE 55mm F1.8 ZA	with Servo Motor (For Focus Control)	V	-	-	-	Servo zoom & focus motor installed on either side	No need to remove eyepiece cap
			with Video Transmission Transmitter	√	-	-	-		No need to remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	1	-	-	-	Servo zoom & focus motor installed on either side	No need to remove eyepiece cap
			Camera and Lens	1	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
			with Servo Motor (For Focus Control)	1	-	-	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap
		E 10–18mm F4 OSS	with Servo Motor (For Zoom Control)	\checkmark	-	-	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap
			with Video Transmission Transmitter	V	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	V	-	-	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Zoom Control)	\checkmark	-	-	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap

Camera	Model	Lens Model	Mounting Status	Balance Adjustment	Balance Adjustment	Camera Backing Base	Camera Backing Base	Servo Zoom/Focus Motor	Installation Remark
Brand				Horizontal	Vertical	Horizontal	Vertical		
			Camera and Lens	\checkmark	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
		E PZ 18–105mm F4 G OSS	with Servo Motor (For Focus Control)	\checkmark	-	-	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap
	E PZ 18–105mm F4 G C		with Servo Motor (For Zoom Control)	1	-	-	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap
			with Video Transmission Transmitter	\checkmark	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	\checkmark	-	-	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap
	α1、		with Video Transmission Transmitter and Servo Motor (For Zoom Control)	1	-	-	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap
	α9、 α9 ΙΙ、		Camera and Lens	\checkmark	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
	α7M2、 α7R2、		with Servo Motor (For Focus Control)	\checkmark	-	1	-	Servo zoom & focus motor installed on left side	Can be balanced at any focal length; No need to remove eyepiece cap
	α7S2、	E 18–200mm F3.5–6.3 OSS LE	with Servo Motor (For Zoom Control)	\checkmark	-	1	-	Servo zoom & focus motor installed on left side	Can be balanced at any focal length; No need to remove eyepiece cap
Sony	α7M4、 α7M3、		with Video Transmission Transmitter	\checkmark	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
	α7R3、 α7S3、		with Video Transmission Transmitter and Servo Motor (For Focus Control)	\checkmark	-	1	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap
	α7R4、 α7C、		with Video Transmission Transmitter and Servo Motor (For Zoom Control)	\checkmark	-	1	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap
	a6600、 a6500、		Camera and Lens	\checkmark	-	-	-		No need to remove eyepiece cap
	α6400、	Sigma 20mm f/1 4 DO DN	with Servo Motor (For Focus Control)	\checkmark	-	-	-	Servo zoom & focus motor installed on either side	No need to remove eyepiece cap
	α6300、α6100	Sigma 30mm f/1.4 DC DN	with Video Transmission Transmitter	\checkmark	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	\checkmark	-	1	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap
			Camera and Lens	\checkmark	-	-	-		No need to remove eyepiece cap
		0	with Servo Motor (For Focus Control)	\checkmark	-	-	-	Servo zoom & focus motor installed on left side	No need to remove eyepiece cap
		Sigma 50mm f/1.4 DG	with Video Transmission Transmitter	\checkmark	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	\checkmark	-	1	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap

Camera	Model	Long Media	Mounting Status	Balance Adjustment	Balance Adjustment	Camera Backing Base	Camera Backing Base	Servo Zoom/Focus Motor	Installation Remark
Brand	woder	Lens Model	Mounting Status	Horizontal	Vertical	Horizontal	Vertical	Servo Zoom/Focus Motor	Instantion Remark
			Camera and Lens	1	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
	α1、 α9、		with Servo Motor (For Focus Control)	1	-	1	-	Servo zoom & focus motor installed on left side	Can be balanced at any focal length; No need to remove eyepiece cap
	α9 II , α7M2, Tamron 28-75mm f/2.8 α7R2, α7S2,	with Servo Motor (For Zoom Control)	\checkmark	-	1	-	Servo zoom & focus motor installed on left side	Can be balanced at any focal length; No need to remove eyepiece cap	
		with Video Transmission Transmitter	\checkmark	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap	
	α7M4、		with Video Transmission Transmitter and Servo Motor (For Focus Control)	\checkmark	-	\checkmark	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap
Sony	α7M3、 α7R3、		with Video Transmission Transmitter and Servo Motor (For Zoom Control)	\checkmark	-	1	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap
	α7S3、 α7R4、		Camera and Lens	\checkmark	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
	α7C、		with Servo Motor (For Focus Control)	-	-	-	-		
	α6600、	sigma18-35mm f/1.8 DC HSM Art	with Servo Motor (For Zoom Control)	-	-	-	-		
	α6500、	(+佳能转接环)	with Video Transmission Transmitter	-	-	-	-		
	a6400、 a6300、a6100		with Video Transmission Transmitter and Servo Motor (For Focus Control)						
			with Video Transmission Transmitter and Servo Motor (For Zoom Control)						
	1		1					1	
			Camera and Lens	\checkmark	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
			with Servo Motor (For Focus Control)	\checkmark	-	-	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap
		XF 16-55mm f/2.8 R LM WR	with Servo Motor (For Zoom Control)	\checkmark	-	-	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap
		XI 10-33111172.011 LIVI WIT	with Video Transmission Transmitter	\checkmark	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	\checkmark	-	-	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap
	X-H1、X-T2、		with Video Transmission Transmitter and Servo Motor (For Zoom Control)	\checkmark	-	-	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap
FUJIFILM	X-T3、X-T4、 X-T30		Camera and Lens	\checkmark	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
			with Servo Motor (For Focus Control)	\checkmark	-	-	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap
		VE 19 55mm f/0.0.4 D OIO	with Servo Motor (For Zoom Control)	\checkmark	-	-	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap
		XF 18-55mm f/2.8-4 R OIS	with Video Transmission Transmitter	\checkmark	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	\checkmark	-	-	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Zoom Control)	\checkmark	-	-	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap

Camera	Model	Lens Model	Mounting Status	Balance Adjustment	Balance Adjustment	Camera Backing Base	Camera Backing Base	Servo Zoom/Focus Motor	Installation Remark
Brand	Model		Mounting Status	Horizontal	Vertical	Horizontal	Vertical	Servo Zoom/Focus Motor	Installation nethark
			Camera and Lens	1	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
			with Servo Motor (For Focus Control)	V	-	-	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap
		XF 18-135mm f/3.5-5.6 R LM OIS	with Servo Motor (For Zoom Control)	V	-	-	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap
		WR	with Video Transmission Transmitter	\checkmark	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	\checkmark	-	-	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Zoom Control)	\checkmark	-	-	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap
			Camera and Lens	1	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
		XF 35mm f/2 R WR	with Servo Motor (For Focus Control)	1	-	-	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap
			with Video Transmission Transmitter	1	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	1	-	-	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap
			Camera and Lens	1	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
FUJIFILM	X-H1、X-T2、 X-T3、X-T4、	XF 56mm f/1.2 R	with Servo Motor (For Focus Control)	1	-	-	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap
	X-T30	XI 3011111/1.2 11	with Video Transmission Transmitter	1	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	1	-	-	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap
			Camera and Lens	1	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
			with Servo Motor (For Focus Control)	1	-	-	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap
		XC 15-45mm f/3.5-5.6 OIS	with Servo Motor (For Zoom Control)	1	-	-	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap
		XC 10-40Hitti/0.0-0.0 Old	with Video Transmission Transmitter	1	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	1	-	-	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Zoom Control)	1	-	-	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap
			Camera and Lens	1	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
		Super EBC XF 23mm f/1.4 R	with Servo Motor (For Focus Control)	1	-	-	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap
			with Video Transmission Transmitter	1	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	1	-	-	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap

Camera	Model	Lens Model	Mounting Status	Balance Adjustment	Balance Adjustment	Camera Backing Base	Camera Backing Base	Servo Zoom/Focus Motor	Installation Remark
Brand	Moder		Mounting Status	Horizontal	Vertical	Horizontal	Vertical	Servo Zoom/Focus Motor	Installation nethalk
			Camera and Lens	V	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
			with Servo Motor (For Focus Control)	\checkmark	-	-	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap
	Vario-Elmarit 8	Vario-Elmarit 8-18mm f/2.8-4.0	with Servo Motor (For Zoom Control)	\checkmark	-	-	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap
			with Video Transmission Transmitter	\checkmark	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	\checkmark	-	-	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Zoom Control)	\checkmark	-	-	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap
			Camera and Lens	\checkmark	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
			with Servo Motor (For Focus Control)	\checkmark	-	-	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap
		Vario 12-35mm f/2.8 II	with Servo Motor (For Zoom Control)	\checkmark	-	-	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap
		Valio 12-3311111/2.011	with Video Transmission Transmitter	\checkmark	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	\checkmark	-	-	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap
	G9、		with Video Transmission Transmitter and Servo Motor (For Zoom Control)	\checkmark	-	-	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap
Panasonic	GH5s、GH5、 DC-BGH1		Camera and Lens	\checkmark	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
		Lumix G 25mm f/1.7	with Servo Motor (For Focus Control)	\checkmark	-	-	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap
			with Video Transmission Transmitter	\checkmark	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	\checkmark	-	-	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap
			Camera and Lens	\checkmark	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
		MACRO 30mm f/2.8	with Servo Motor (For Focus Control)	\checkmark	-	-	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap
		MACRO SUMM 1/2.8	with Video Transmission Transmitter	V	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	V	-	-	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap
			Camera and Lens	\checkmark	-	-	-		Need to remove eyepiece cap
			with Servo Motor (For Focus Control)	-	-	-	-		
			with Servo Motor (For Zoom Control)	-	-	-	-		
		sigma 18-35mm f/1.8 DC HSM Art	with Video Transmission Transmitter	-	-	-	-		
		(+ adapter)	with Video Transmission Transmitter and Servo Motor (For Focus Control)	-	-	-	-		
			with Video Transmission Transmitter and Servo Motor (For Zoom Control)	-	-	-	-		

Camera	Model	Long Model	Mounting Status	Balance Adjustment	Balance Adjustment	Camera Backing Base	Camera Backing Base	Servo Zoom/Focus Motor	Installation Remark
Brand	Wodei	Lens Model	Mounting Status	Horizontal	Vertical	Horizontal	Vertical	Servo Zoom/Focus Motor	Installation Remark
			Camera and Lens	\checkmark	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
			with Servo Motor (For Focus Control)	\checkmark	-	-	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap
	S1、S5	LUMIX S 24-105mm F/4 Macro OIS	with Servo Motor (For Zoom Control)	\checkmark	-	-	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap
	01, 00		with Video Transmission Transmitter	\checkmark	-	-	-		Can be balanced at any focal length; No need to remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	\checkmark	-	-	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap
Panasonic			with Video Transmission Transmitter and Servo Motor (For Zoom Control)	\checkmark	-	-	-	Servo zoom & focus motor installed on either side	Can be balanced at any focal length; No need to remove eyepiece cap
			Camera and Lens	-	-	-	-		
			with Servo Motor (For Focus Control)	-	-	-	-		
			with Servo Motor (For Zoom Control)	-	-	-	-		
	S1H	LUMIX S 24-105mm F/4 Macro OIS	with Video Transmission Transmitter	-	-	-	-		
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	\checkmark	-	-	-	Servo zoom & focus motor installed on right side	Can be balanced at any focal length; No need to remove eyepiece cap
			with Video Transmission Transmitter and Servo Motor (For Zoom Control)	\checkmark	-	-	-	Servo zoom & focus motor installed on right side	Can be balanced at any focal length; No need to remove eyepiece cap
		-							
			Camera and Lens	-	-	-	-		
			with Servo Motor (For Focus Control)	-	-	-	-		
			with Servo Motor (For Zoom Control)	-	-	-	-		
		Vario-Elmarit 8-18mm f/2.8-4.0	with Video Transmission Transmitter	-	-	-	-		
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	-	-	-	-		
			with Video Transmission Transmitter and Servo Motor (For Zoom Control)	-	-	-	-		
			Camera and Lens	\checkmark	-	-	-		
			with Servo Motor (For Focus Control)	\checkmark	-	-	-	Servo zoom & focus motor installed on right side	
BMD	BMPCC 4K	Vario 12-35mm f/2.8 II	with Servo Motor (For Zoom Control)	\checkmark	-	-	-	Servo zoom & focus motor installed on right side	
		Vano 12-30mm // 2.0 m	with Video Transmission Transmitter	\checkmark	-	-	-		
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	\checkmark	-	-	-	Servo zoom & focus motor installed on right side	
			with Video Transmission Transmitter and Servo Motor (For Zoom Control)	\checkmark	-	-	-	Servo zoom & focus motor installed on right side	
			Camera and Lens	\checkmark	-	-	-		
			with Servo Motor (For Zoom Control)	\checkmark	-	-	-	Servo zoom & focus motor installed on right side	
		G Vario 12-32mm 0.2m/0.66ft	with Video Transmission Transmitter	\checkmark	-	-	-		
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	\checkmark	-	-	-	Servo zoom & focus motor installed on right side	
			with Video Transmission Transmitter and Servo Motor (For Zoom Control)	\checkmark	-	-	-	Servo zoom & focus motor installed on right side	

Camera	Model	Lens Model	Mounting Status	Balance Adjustment	Balance Adjustment	Camera Backing Base	Camera Backing Base	Servo Zoom/Focus Motor	Installation Remark
Brand	Model			Horizontal	Vertical	Horizontal	Vertical	Servo Zoom/r ocus motor	Installation Hemark
			Camera and Lens	1	-	-	-		
		25mm f/1.7	with Servo Motor (For Focus Control)	1	-	-	-	Servo zoom & focus motor installed on right side	
		2011111/1.1	with Video Transmission Transmitter	1	-	-	-		
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	1	-	-	-	Servo zoom & focus motor installed on right side	
			Camera and Lens	1	-	-	-		
	BMPCC 4K	MACRO 30mm f/2.8	with Servo Motor (For Focus Control)	1	-	-	-	Servo zoom & focus motor installed on right side	
	DIMFCC 4K	MACHO SUMMIZ.0	with Video Transmission Transmitter	1	-	-	-		
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	1	-	-	-	Servo zoom & focus motor installed on right side	
			Camera and Lens	1	-	-	-		
		D-Dreamer 12mm F2.8	with Servo Motor (For Focus Control)	1	-	-	-	Servo zoom & focus motor installed on right side	
		D-Dreamer 12mm F2.0	with Video Transmission Transmitter	1	-	-	-		
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	1	-	-	-	Servo zoom & focus motor installed on right side	
			Camera and Lens	-	-	-	-		
BMD			with Servo Motor (For Focus Control)	-	-	-	-		
		EF 24mm f/1.4L II USM	with Video Transmission Transmitter	-	-	-	-		
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	-	-	-	-		
			Camera and Lens	-	-	-	-		
			with Servo Motor (For Focus Control)	-	-	-	-		
		EF 35mm f/1.4L II USM	with Video Transmission Transmitter	-	-	-	-		
	BMPCC 6K		with Video Transmission Transmitter and Servo Motor (For Focus Control)	-	-	-	-		
	BINFCCOK		Camera and Lens	-	-	-	-		
			with Servo Motor (For Focus Control)	-	-	-	-		
		EF 50mm f/1.4L USM	with Video Transmission Transmitter	-	-	-	-		
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	-	-	-	-		
			Camera and Lens	-	-	-	-		
			with Servo Motor (For Focus Control)	-	-	-	-		
		EF 85mm f/1.8L USM	with Video Transmission Transmitter	-	-	-	-		
			with Video Transmission Transmitter and Servo Motor (For Focus Control)	-	-	-	-		

ZHIYUN	WEEBILL 2 Camera Compatibility List
--------	-------------------------------------

Camera	Model	Lens Model	Mounting Status	Balance Adjustment	Balance Adjustment	Camera Backing Base	Camera Backing Base	Servo Zoom/Focus Motor	Installation Remark
Brand	Moder		Mounting Status	Horizontal	Vertical	Horizontal	Vertical	Servo Zoom/Pocus Motor	
			Camera and Lens	\checkmark	-	-	-		
			with Servo Motor (For Focus Control)	\checkmark	-	-	-		
	ZCAM E2 LUMIX G X Vario 12-3 ASPH POWER		with Servo Motor (For Zoom Control)	\checkmark	-	-	-		
ZCAM		LUMIX G X Vario 12-35mm f/2.8 II	with Video Transmission Transmitter	\checkmark	-	-	-		
		ASPH POWER OIS	with Video Transmission Transmitter and Servo Motor (For Focus Control)	\checkmark	-	-	-		
			with Video Transmission Transmitter and Servo Motor (For Zoom Control)	\checkmark	-	-	-		
			Camera and Lens	\checkmark	-	-	-		
SIGMA	fa	45mm 50 0	with Servo Motor (For Focus Control)	\checkmark	-	\checkmark	-	Servo zoom & focus motor installed on either side	
SIGMA	fp	45mm F2.8	with Video Transmission Transmitter	\checkmark	-	-	-		
			with Video Transmission Transmitter and Servo Motor (For Focus Control)		-	V	-	Servo zoom & focus motor installed on either side	